



Shenzhen Xtooltech Co., Ltd

Lancia Function List V11.20

Tips and Instructions:

The programming function only supports H6PRO, H6PRO Master Edition products.

- * This feature is new.
- ✓ This feature is supported.
- This feature is not supported.
- ※ This feature is partially supported.

| Vehicle | Model | Year/model | System | Read ECU Information | Read Trouble Code | Clear Trouble Code | Live Data | Action Test | Special Functions |
|---------|-------------|--------------------|--|----------------------|-------------------|--------------------|-----------|-------------|-------------------|
| LANCIA | DEDRA | '96 1.8 16V 115 CV | Bosch 5.3 ABS | ✓ | ✓ | ✓ | | | |
| LANCIA | DEDRA | '96 1.8 16V 115 CV | Hitachi MPI Injection | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DEDRA | '96 1.8 16V 130 CV | Bosch 5.3 ABS | ✓ | ✓ | ✓ | | | |
| LANCIA | DEDRA | '96 1.8 16V 130 CV | Hitachi MPI Injection | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DEDRA | '98 1.6 16V | Bosch 5.3 ABS | ✓ | ✓ | ✓ | | | |
| LANCIA | DEDRA | '98 1.6 16V | Magneti Marelli IAW 49F Injection (1.6 Eng.) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (111) | '96 1.6 16V | Bosch 5.3 ABS | ✓ | ✓ | ✓ | | | |
| LANCIA | DELTA (111) | '96 1.8 16V 115 CV | Bosch 5.3 ABS | ✓ | ✓ | ✓ | | | |
| LANCIA | DELTA (111) | '96 1.8 16V 115 CV | Hitachi MPI Injection | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (111) | '96 1.8 16V 130 CV | Bosch 5.3 ABS | ✓ | ✓ | ✓ | | | |
| LANCIA | DELTA (111) | '96 1.8 16V 130 CV | Hitachi MPI Injection | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (111) | '96 2.0 TURBO 16V | Bosch 5.3 ABS | ✓ | ✓ | ✓ | | | |
| LANCIA | DELTA (111) | '96 TD | Bosch 5.3 ABS | ✓ | ✓ | ✓ | | | |
| LANCIA | DELTA (111) | '98 1.6 16V | Bosch 5.3 ABS | ✓ | ✓ | ✓ | | | |
| LANCIA | DELTA (111) | '98 1.6 16V | Magneti Marelli IAW 49F Injection (1.6 Eng.) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (111) | '98 1.8 16V | Bosch 5.3 ABS | ✓ | ✓ | ✓ | | | |
| LANCIA | DELTA (111) | '98 1.8 16V | Hitachi MPI Injection (Eng. 1.8 16V '98) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.4 TURBO 16V | Bosch Motronic Injection Me7.9.10 CF5/EOBD (Eng. 1.4) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.4 TURBO 16V | Injection Landi Renzo LCO2 Gas | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.4 TURBO 16V | Marelli Instrument Panel 3 | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.4 TURBO 16V | Marelli Radio Navigator | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.4 TURBO 16V | Marelli/Microsoft C3 Convergence | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.4 TURBO 16V | Marelli/Microsoft Convergence | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.4 TURBO 16V | Marelli Body Computer 8 | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.4 TURBO 16V | SIEMENS Airbag 1 (Proxi) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.4 TURBO 16V | TRW ABS ESP | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.4 TURBO 16V | TRW Lane Control Control Unit (HALF) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.4 TURBO 16V | Denso 3 Climate Control (Two-Zone) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.4 TURBO 16V | Driver's Seat Lear 3 | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.4 TURBO 16V | Passenger's Seat Lear 3 | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.4 TURBO 16V | TRW3 Electric Steering | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.4 TURBO 16V | Tyre Pressure Control TRW 2 | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.4 TURBO 16V | Valeo Semi-Automatic Parking Control Unit | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.4 TURBO 16V | Valeo 2 Parking Control Unit | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.6 MJET 16V | Bosch Diese Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 Eng.) | ✓ | ✓ | ✓ | ✓ | | |

| | | | | | | | | | |
|--------|-------------|---------------------|--|---|---|---|---|---|--|
| LANCIA | DELTA (181) | 1.6 MJET 16V | Marelli SELESPEED CFC300 Automatic Gearbox | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.6 MJET 16V | Marelli Instrument Panel 3 | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.6 MJET 16V | Marelli Radio Navigator | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.6 MJET 16V | Marelli/Microsoft C3 Convergence | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.6 MJET 16V | Marelli/Microsoft Convergence | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.6 MJET 16V | Marelli Body Computer 8 | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.6 MJET 16V | SIEMENS Airbag 1 (Proxi) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.6 MJET 16V | TRW ABS ESP | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.6 MJET 16V | TRW Lane Control Control Unit (HALF) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.6 MJET 16V | Denso 3 Climate Control (Two-Zone) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.6 MJET 16V | Driver's Seat Lear 3 | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.6 MJET 16V | Passenger's Seat Lear 3 | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.6 MJET 16V | TRW3 Electric Steering | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.8 JTS TB 16V | Automatic Gearbox AISIN AF40-6 | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.8 JTS TB 16V | Bosch Injection Motronic Med17.3.1 CF5/EOBD (Eng. 1.8) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.8 JTS TB 16V | Marelli Instrument Panel 3 | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.8 JTS TB 16V | Marelli Radio Navigator | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.8 JTS TB 16V | Marelli/Microsoft C3 Convergence | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.8 JTS TB 16V | Marelli/Microsoft Convergence | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.8 JTS TB 16V | Marelli Body Computer 8 | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.8 JTS TB 16V | SIEMENS Airbag 1 (Proxi) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.8 JTS TB 16V | TRW ABS ESP | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.8 JTS TB 16V | TRW Lane Control Control Unit (HALF) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.8 JTS TB 16V | Denso 3 Climate Control (Two-Zone) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.8 JTS TB 16V | Driver's Seat Lear 3 | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.8 JTS TB 16V | Passenger's Seat Lear 3 | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.8 JTS TB 16V | TRW3 Electric Steering | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.9 MJET 16V TWINTB | Bosch Diese Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 Eng.) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.9 MJET 16V TWINTB | Marelli Instrument Panel 3 | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.9 MJET 16V TWINTB | Marelli Radio Navigator | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.9 MJET 16V TWINTB | Marelli/Microsoft C3 Convergence | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.9 MJET 16V TWINTB | Marelli/Microsoft Convergence | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.9 MJET 16V TWINTB | Marelli Body Computer 8 | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.9 MJET 16V TWINTB | SIEMENS Airbag 1 (Proxi) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.9 MJET 16V TWINTB | TRW ABS ESP | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.9 MJET 16V TWINTB | TRW Lane Control Control Unit (HALF) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.9 MJET 16V TWINTB | Denso 3 Climate Control (Two-Zone) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 1.9 MJET 16V TWINTB | Driver's Seat Lear 3 | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.9 MJET 16V TWINTB | Passenger's Seat Lear 3 | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 1.9 MJET 16V TWINTB | TRW3 Electric Steering | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 2.0 MJET 16V | Bosch Diese Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 Eng.) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 2.0 MJET 16V | Marelli Instrument Panel 3 | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 2.0 MJET 16V | Marelli Radio Navigator | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 2.0 MJET 16V | Marelli/Microsoft C3 Convergence | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 2.0 MJET 16V | Marelli/Microsoft Convergence | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 2.0 MJET 16V | Marelli Body Computer 8 | ✓ | ✓ | ✓ | ✓ | ✓ | |

| | | | | | | | | | |
|--------|-------------|--------------|---|---|---|---|---|---|--|
| LANCIA | DELTA (181) | 2.0 MJET 16V | SIEMENS Airbag 1 (Proxi) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 2.0 MJET 16V | TRW ABS ESP | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 2.0 MJET 16V | TRW Lane Control Control Unit (HALF) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 2.0 MJET 16V | Denso 3 Climate Control (Two-Zone) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 2.0 MJET 16V | Driver's Seat Lear 3 | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 2.0 MJET 16V | Passenger's Seat Lear 3 | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | DELTA (181) | 2.0 MJET 16V | TRW3 Electric Steering | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 2.0 MJET 16V | Tyre Pressure Control TRW 2 | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 2.0 MJET 16V | Valeo Semi-Automatic Parking Control Unit | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | DELTA (181) | 2.0 MJET 16V | Valeo 2 Parking Control Unit | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | FLAVIA | 2013 | PCM (Powertrain Control Module) | ✓ | ✓ | ✓ | ✓ | | sp02543, sp02544, sp02545, sp02546, sp02547, sp02548, sp02549, sp02550, sp02551, sp02552 |
| LANCIA | FLAVIA | 2013 | TCM (Transmission Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | FLAVIA | 2013 | ABS (Anti Lock Brakes) | ✓ | ✓ | ✓ | ✓ | | sp02553, sp02554 |
| LANCIA | FLAVIA | 2013 | ORC (Occupant Restraint) | ✓ | ✓ | ✓ | ✓ | | sp02555 |
| LANCIA | FLAVIA | 2013 | WCM (Wireless Control) | ✓ | ✓ | ✓ | ✓ | | sp02556 |
| LANCIA | FLAVIA | 2013 | TIPMCGW (Central Gateway) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | FLAVIA | 2013 | SAS (Steering Angle Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | FLAVIA | 2013 | RADIO (RADIO) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | FLAVIA | 2013 | PTCM (Power Top Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | FLAVIA | 2013 | PDM (Passenger Door Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02557, sp02558, sp02559, sp02560 |
| LANCIA | FLAVIA | 2013 | HVAC (Heat, Ventilation And A/C) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02561 |
| LANCIA | FLAVIA | 2013 | HFM (Hands Free Module (Cell Phone)) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | FLAVIA | 2013 | ESM (Electronic Shifter Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | FLAVIA | 2013 | DDM (Driver Door Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | FLAVIA | 2013 | CCN (Instrument Cluster/Cabin Compartment Node) | ✓ | ✓ | ✓ | ✓ | | sp02562, sp02563, sp02564, sp02565, sp02566, sp02567 |
| LANCIA | FLAVIA | 2013 | AMP (Amplifier) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | FLAVIA | 2012 | PCM (Powertrain Control Module) | ✓ | ✓ | ✓ | ✓ | | sp02568, sp02569, sp02570, sp02571, sp02572, sp02573, sp02574, sp02575, sp02576, sp02577 |
| LANCIA | FLAVIA | 2012 | ABS (Anti Lock Brakes) | ✓ | ✓ | ✓ | ✓ | | sp02578, sp02579 |
| LANCIA | FLAVIA | 2012 | ORC (Occupant Restraint) | ✓ | ✓ | ✓ | ✓ | | sp02580 |
| LANCIA | FLAVIA | 2012 | TIPMCGW (Central Gateway) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | FLAVIA | 2012 | WCM (Wireless Control) | ✓ | ✓ | ✓ | ✓ | | sp02581 |
| LANCIA | FLAVIA | 2012 | SAS (Steering Angle Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | FLAVIA | 2012 | RADIO (RADIO) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | FLAVIA | 2012 | PTCM (Power Top Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | FLAVIA | 2012 | PDM (Passenger Door Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02582, sp02583, sp02584, sp02585 |
| LANCIA | FLAVIA | 2012 | HVAC (Heat, Ventilation And A/C) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02586 |
| LANCIA | FLAVIA | 2012 | HFM (Hands Free Module (Cell Phone)) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | FLAVIA | 2012 | DDM (Driver Door Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | FLAVIA | 2012 | CCN (Instrument Cluster/Cabin Compartment Node) | ✓ | ✓ | ✓ | ✓ | | sp02587, sp02588, sp02589, sp02590, sp02591, sp02592 |
| LANCIA | FLAVIA | 2012 | AMP (Amplifier) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | '98 2.4 JTD | Bosch EDC15 Diesel Injection (2.4 TD D.I. Eng.) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | '98 2.4 JTD | Bosch 5.3 ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | '98 2.4 JTD | TRW MY 97 Air Bag (2F-2P) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | '98 2.4 JTD | TRW MY 97 Air Bag (2F-2P-2L-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | '98 2.4 JTD | TRW MY 97 Air Bag (2F-2P-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | '99 2.0 | Bosch Motronic ME3.1 Injection (Eng. 2.0 20V) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | '99 2.0 | Bosch 5.3 ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | '99 2.0 | TRW MY 97 Air Bag (2F-2P) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | '99 2.0 | TRW MY 97 Air Bag (2F-2P-2L-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | '99 2.0 | TRW MY 97 Air Bag (2F-2P-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | '99 2.0 | TRW MY 97 Airbag (2F-2P-2L) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | '99 2.4 | Bosch Motronic ME3.1 Injection (Eng. 2.0 20V) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | '99 2.4 | Bosch 5.3 ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | '99 2.4 | TRW MY 97 Air Bag (2F-2P) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | '99 2.4 | TRW MY 97 Air Bag (2F-2P-2L-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | '99 2.4 | TRW MY 97 Air Bag (2F-2P-S) | ✓ | ✓ | ✓ | ✓ | | |

| | | | | | | | | | |
|--------|-------|-----------|---|---|---|---|---|--|--|
| LANCIA | K | '99 2.4 | TRW MY 97 Airbag (2F-2P-2L) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | '99 3.0 | Bosch 5.3 ABS | ✓ | ✓ | ✓ | | | |
| LANCIA | K | '99 3.0 | TRW MY 97 Air Bag (2F-2P) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | '99 3.0 | TRW MY 97 Air Bag (2F-2P-2L-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | '99 3.0 | TRW MY 97 Air Bag (2F-2P-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | '99 3.0 | TRW MY 97 Airbag (2F-2P-2L) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | 2 | Bosch 5.3 ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | 2 | TRW MY 97 Air Bag (2F-2P) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | 2 | TRW MY 97 Air Bag (2F-2P-2L-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | 2 | TRW MY 97 Air Bag (2F-2P-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | 2.0 TURBO | Bosch 5.3 ABS | ✓ | ✓ | ✓ | | | |
| LANCIA | K | 2.0 TURBO | TRW MY 97 Air Bag (2F-2P) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | 2.0 TURBO | TRW MY 97 Air Bag (2F-2P-2L-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | 2.0 TURBO | TRW MY 97 Air Bag (2F-2P-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | 2.4 | Bosch 5.3 ABS | ✓ | ✓ | ✓ | | | |
| LANCIA | K | 2.4 | TRW MY 97 Air Bag (2F-2P) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | 2.4 | TRW MY 97 Air Bag (2F-2P-2L-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | 2.4 | TRW MY 97 Air Bag (2F-2P-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | 2.4 TD | Bosch 5.3 ABS | ✓ | ✓ | ✓ | | | |
| LANCIA | K | 2.4 TD | TRW MY 97 Air Bag (2F-2P) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | 2.4 TD | TRW MY 97 Air Bag (2F-2P-2L-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | 2.4 TD | TRW MY 97 Air Bag (2F-2P-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | 3 | Bosch 5.3 ABS | ✓ | ✓ | ✓ | | | |
| LANCIA | K | 3 | TRW MY 97 Air Bag (2F-2P) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | 3 | TRW MY 97 Air Bag (2F-2P-2L-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | K | 3 | TRW MY 97 Air Bag (2F-2P-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.6 | Allied Airbag MY 97 (2F-2P-2L-2T-1) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.6 | Allied MY 97 Air Bag (2F-2P-2L-1-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.6 | Allied MY 97 Airbag (2F-2P-2L-1) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.6 | Allied MY 97 Airbag (2F-2P-1) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.6 | Marelli Code 2 Electronic Key | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.6 | SIEMENS MY 99 Airbag (2F-2P-2L-2T-1) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.6 | Allied MY97 Airbag (2F-2P-1-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.6 | Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.6 | Bosch Discharge Headlamp (Left) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.6 | Bosch Discharge Headlamp (Right) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.6 | Bosch 5.3 ABS | ✓ | ✓ | ✓ | | | |
| LANCIA | LYBRA | 1.6 | VAS 97/3 Door Lock RF Alarm/Receiver | ✓ | ✓ | ✓ | | | |
| LANCIA | LYBRA | 1.6 | TRW Lucas ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.6 | Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.6 | Magneti Marelli IAW 49F Injection (1.6 Eng.) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.6 | ESP TRW Lucas ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.8 | Allied Airbag MY 97 (2F-2P-2L-2T-1) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.8 | Allied MY 97 Air Bag (2F-2P-2L-1-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.8 | Allied MY 97 Airbag (2F-2P-2L-1) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.8 | Allied MY 97 Airbag (2F-2P-1) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.8 | Marelli Code 2 Electronic Key | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.8 | SIEMENS MY 99 Airbag (2F-2P-2L-2T-1) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.8 | Allied MY97 Airbag (2F-2P-1-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.8 | Hitachi MPI Injection (Eng. 1.8 16V '98) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.8 | Hitachi EOBD Injection | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.8 | Bosch Discharge Headlamp (Left) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.8 | Bosch Discharge Headlamp (Right) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.8 | Bosch 5.3 ABS | ✓ | ✓ | ✓ | | | |
| LANCIA | LYBRA | 1.8 | VAS 97/3 Door Lock RF Alarm/Receiver | ✓ | ✓ | ✓ | | | |
| LANCIA | LYBRA | 1.8 | TRW Lucas ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.8 | ESP TRW Lucas ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.9 JTD | Allied Airbag MY 97 (2F-2P-2L-2T-1) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.9 JTD | Allied MY 97 Air Bag (2F-2P-2L-1-S) | ✓ | ✓ | ✓ | ✓ | | |

| | | | | | | | | | |
|--------|-------|---------|---|---|---|---|---|---|--|
| LANCIA | LYBRA | 1.9 JTD | Allied MY 97 Airbag (2F-2P-2L-I) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.9 JTD | Allied MY 97 Airbag (2F-2P-I) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.9 JTD | Marelli Code 2 Electronic Key | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.9 JTD | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.9 JTD | Allied MY97 Airbag (2F-2P-I-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.9 JTD | Bosch Diesel EDC 15 Injection (1.9 TD D.I. Engine) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.9 JTD | Bosch Discharge Headlamp (Left) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.9 JTD | Bosch Discharge Headlamp (Right) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.9 JTD | Bosch EDC15 CF3/E0BD Diesel Injection (Eng. 1.9/2.4) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.9 JTD | Bosch 5.3 ABS | ✓ | ✓ | ✓ | | | |
| LANCIA | LYBRA | 1.9 JTD | VAS 97/3 Door Lock RF Alarm/Receiver | ✓ | ✓ | ✓ | | | |
| LANCIA | LYBRA | 1.9 JTD | TRW Lucas ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 1.9 JTD | ESP TRW Lucas ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2 | Allied Airbag MY 97 (2F-2P-2L-2T-I) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2 | Allied MY 97 Air Bag (2F-2P-2L-I-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2 | Allied MY 97 Airbag (2F-2P-2L-I) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2 | Marelli Code 2 Electronic Key | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2 | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2 | Allied MY97 Airbag (2F-2P-I-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2 | Injection-Bosch Motronic Me3.1 (Eng. 2.0/2.4 20V Outside EEC) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2 | Bosch Discharge Headlamp (Left) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2 | Bosch Discharge Headlamp (Right) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2 | Bosch Motronic Me3.1 E0BD Injection (Eng. 2.0/2.4 20V) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2 | Bosch 5.3 ABS | ✓ | ✓ | ✓ | | | |
| LANCIA | LYBRA | 2 | VAS 97/3 Door Lock RF Alarm/Receiver | ✓ | ✓ | ✓ | | | |
| LANCIA | LYBRA | 2 | TRW Lucas ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2 | ESP TRW Lucas ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2 | Allied MY 97 Airbag (2F-2P-I) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2.4 JTD | Allied Airbag MY 97 (2F-2P-2L-2T-I) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2.4 JTD | Allied MY 97 Air Bag (2F-2P-2L-I-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2.4 JTD | Allied MY 97 Airbag (2F-2P-2L-I) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2.4 JTD | Allied MY 97 Airbag (2F-2P-I) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2.4 JTD | Marelli Code 2 Electronic Key | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2.4 JTD | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2.4 JTD | Allied MY97 Airbag (2F-2P-I-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2.4 JTD | Bosch Discharge Headlamp (Left) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2.4 JTD | Bosch Discharge Headlamp (Right) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2.4 JTD | Bosch EDC15 Diesel Injection (2.4 TD D.I. Eng.) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2.4 JTD | Bosch EDC15 CF3/E0BD Diesel Injection (Eng. 1.9/2.4) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2.4 JTD | Bosch 5.3 ABS | ✓ | ✓ | ✓ | | | |
| LANCIA | LYBRA | 2.4 JTD | VAS 97/3 Door Lock RF Alarm/Receiver | ✓ | ✓ | ✓ | | | |
| LANCIA | LYBRA | 2.4 JTD | TRW Lucas ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | LYBRA | 2.4 JTD | ESP TRW Lucas ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.3 JTD | Automatic Gearbox Marelli SELESPEED CFC308F | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.3 JTD | Marelli 6JF E0BD Diesel Injection (Eng. 1.3 JTD) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.3 JTD | Marelli Automatic Gearbox SELESPEED CFC208F (1) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.3 JTD | Marelli Diesel Injection 8DF CF5/E0BD (Eng. 1.3 JTD) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.3 JTD | Marelli Diesel Injection 6F3 E0BD (Eng. 1.3 JTD) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.3 JTD | Marelli 3 Connect (Multi-Model) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.3 JTD | Marelli Instrument Panel (ComFort) | ✓ | ✓ | ✓ | ✓ | ✓ | |

| | | | | | | | | | |
|--------|------|---------|--|---|---|---|---|---|--|
| LANCIA | MUSA | 1.3 JTD | Marelli Instrument Panel (Modal) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.3 JTD | Bosch 8 ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.3 JTD | Bosch 8 VDC ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.3 JTD | Marelli 7 Body Computer | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.3 JTD | Marelli Body Computer 1 | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.3 JTD | TRW MY 03 Airbag (2F-2P-I) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.3 JTD | TRW MY 03 Airbag (2F-2P-2T-I) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.3 JTD | TRW MY 03 Airbag (2F-2P-2L-2T-I) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.3 JTD | Denso Climate Control 1 (Two-Zone) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.3 JTD | Marelli/Microsoft Convergence | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.3 JTD | TRW 1 Power Steering | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.3 JTD | TRW3 Electric Steering | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.3 JTD | G.E. PROCOND Boot | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.3 JTD | G.E. PROCOND Driver's Door | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.3 JTD | Single Driver's Door G.E. PROCOND | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.3 JTD | G.E. PROCOND Passenger Door | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.3 JTD | Valeo Parking Control Unit | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.3 JTD | Single Bitron Driver's Door | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 16V | Bosch Motronic Injection Me7.9.10 CF5/EOBD (Eng. 1.4) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.4 16V | Bosch Motronic ME7.3H4M EOBD Injection | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.4 16V | Marelli SELESPEED CFC228F Automatic Gearbox | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.4 16V | Marelli SELESPEED CFC328 Automatic Gearbox | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.4 16V | Marelli 3 Connect (Multi-Model) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 16V | Marelli Instrument Panel (Comfort) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 16V | Marelli Instrument Panel (Modal) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 16V | Bosch 8 ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.4 16V | Bosch 8 VDC ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.4 16V | Marelli 7 Body Computer | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 16V | Marelli Body Computer 1 | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 16V | TRW MY 03 Airbag (2F-2P-I) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 16V | TRW MY 03 Airbag (2F-2P-2T-I) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 16V | TRW MY 03 Airbag (2F-2P-2L-2T-I) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 16V | Denso Climate Control 1 (Two-Zone) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 16V | Marelli/Microsoft Convergence | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 16V | TRW 1 Power Steering | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.4 16V | TRW3 Electric Steering | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.4 16V | G.E. PROCOND Boot | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 16V | G.E. PROCOND Driver's Door | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 16V | Single Driver's Door G.E. PROCOND | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 16V | G.E. PROCOND Passenger Door | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 16V | Valeo Parking Control Unit | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 16V | Single Bitron Driver's Door | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 8V | Injection Landi Renzo LC02 Gas | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.4 8V | Magneti Marelli Injection IAW 5SF CF4/EOBD (Eng. 1.4 8V) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.4 8V | Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.4 8V | Marelli 3 Connect (Multi-Model) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 8V | Marelli Instrument Panel (Comfort) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 8V | Marelli Instrument Panel (Modal) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 8V | Bosch 8 ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.4 8V | Bosch 8 VDC ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.4 8V | Marelli 7 Body Computer | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 8V | Marelli Body Computer 1 | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 8V | TRW MY 03 Airbag (2F-2P-I) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 8V | TRW MY 03 Airbag (2F-2P-2T-I) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 8V | TRW MY 03 Airbag (2F-2P-2L-2T-I) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 8V | Denso Climate Control 1 (Two-Zone) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 8V | Marelli/Microsoft Convergence | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 8V | TRW 1 Power Steering | ✓ | ✓ | ✓ | ✓ | | |

| | | | | | | | | | |
|--------|--------|--------------|---|---|---|---|---|---|--|
| LANCIA | MUSA | 1.4 8V | TRW3 Electric Steering | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.4 8V | G.E. PROCOND Boot | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 8V | G.E. PROCOND Driver's Door | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 8V | Single Driver's Door G.E. PROCOND | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 8V | G.E. PROCOND Passenger Door | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.4 8V | Valeo Parking Control Unit | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.6 MJET 16V | Bosch Diese Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 Eng) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.6 MJET 16V | Marelli 3 Connect (Multi-Model) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.6 MJET 16V | Marelli Instrument Panel (Comfort) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.6 MJET 16V | Marelli Instrument Panel (Modal) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.6 MJET 16V | Bosch 8 ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.6 MJET 16V | Bosch 8 VDC ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.6 MJET 16V | Marelli Body Computer | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.6 MJET 16V | TRW MY 03 Airbag (2F-2P-I) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.6 MJET 16V | TRW MY 03 Airbag (2F-2P-2T-I) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.6 MJET 16V | TRW MY 03 Airbag (2F-2P-2L-2T-I) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.6 MJET 16V | Denso Climate Control 1 (Two-Zone) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.6 MJET 16V | Marelli/Microsoft Convergence | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.6 MJET 16V | TRW 1 Power Steering | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.6 MJET 16V | TRW3 Electric Steering | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.6 MJET 16V | G.E. PROCOND Boot | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.6 MJET 16V | G.E. PROCOND Driver's Door | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.6 MJET 16V | Single Driver's Door G.E. PROCOND | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.6 MJET 16V | G.E. PROCOND Passenger Door | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.6 MJET 16V | Valeo Parking Control Unit | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.9 JTD | Bosch EDC16C9 CF3/EOBD Diesel Injection (1.9 Eng.) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.9 JTD | Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 Eng.) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.9 JTD | Marelli 3 Connect (Multi-Model) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.9 JTD | Marelli Instrument Panel (Comfort) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.9 JTD | Marelli Instrument Panel (Modal) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.9 JTD | Bosch 8 ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.9 JTD | Bosch 8 VDC ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.9 JTD | Marelli 7 Body Computer | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.9 JTD | Marelli Body Computer 1 | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.9 JTD | TRW MY 03 Airbag (2F-2P-I) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.9 JTD | TRW MY 03 Airbag (2F-2P-2T-I) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.9 JTD | TRW MY 03 Airbag (2F-2P-2L-2T-I) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.9 JTD | Denso Climate Control 1 (Two-Zone) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.9 JTD | Marelli/Microsoft Convergence | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.9 JTD | TRW 1 Power Steering | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.9 JTD | TRW3 Electric Steering | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.9 JTD | G.E. PROCOND Boot | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.9 JTD | G.E. PROCOND Driver's Door | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.9 JTD | Single Driver's Door G.E. PROCOND | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.9 JTD | G.E. PROCOND Passenger Door | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | MUSA | 1.9 JTD | Valeo Parking Control Unit | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | MUSA | 1.9 JTD | Single Bitron Driver's Door | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA | 2.0 16V | Magneti Marelli MM4MP2 PSA Injection | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 16V | Magneti Marelli MM6LP PSA Injection | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 16V | Siemens AL4 TA2000 V PSA Automatic Gearbox | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 16V | Marelli DAV PSA Connect Control | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 16V | Marelli Odometer W. Lamps (BTO) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 16V | Marelli PSA Connect | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 16V | Marelli PSA Instrument Panel | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 16V | Sagem Multi-Function Screen | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 16V | Bosch 5.7 ESP PSA ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 16V | Bitron PSA Driver's Seat | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 16V | Clarion CD Changer | ✓ | ✓ | ✓ | ✓ | | |

| | | | | | | | | | |
|--------|--------|-------------|---|---|---|---|---|--|--|
| LANCIA | PHEDRA | 2.0 16V | Clarion/Philips Sound System | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 16V | Marelli PSA Climate Control | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 16V | Eaton Multi-Switch Stalk Unit (COM2000) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 16V | Inalfa Central Sunroof | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 16V | Inalfa Front Sunroof | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 16V | Inalfa Rear Sunroof | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 16V | Marelli PSA Driver's Door | ✓ | | | | | |
| LANCIA | PHEDRA | 2.0 16V | Marelli PSA Passenger's Door | ✓ | | | | | |
| LANCIA | PHEDRA | 2.0 16V | Valeo PSA Parking Control Unit | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 16V | Valeo PSA Discharge Headlamp (LH) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 16V | Valeo PSA Discharge Headlamp (RH) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 16V | Texton Sliding Doors | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Bosch EDC15 PSA Diesel Injection (Eng. 16V) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Siemens AL4 TA2000 V PSA Automatic Gearbox | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Marelli DAV PSA Connect Control | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Marelli Odometer W. Lamps (BTO) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Marelli PSA Connect | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Marelli PSA Instrument Panel | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Sagem Multi-Function Screen | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Bosch 5.7 ESP PSA ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Bitron PSA Driver's Seat | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Clarion CD Changer | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Clarion/Philips Sound System | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Marelli PSA Climate Control | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | WEBASTO Heater (PSA) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Eaton Multi-Switch Stalk Unit (COM2000) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Inalfa Central Sunroof | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Inalfa Front Sunroof | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Inalfa Rear Sunroof | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Marelli Diesel Additive Check | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Marelli PSA Driver's Door | ✓ | | | | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Marelli PSA Passenger's Door | ✓ | | | | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Valeo PSA Parking Control Unit | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Valeo PSA Discharge Headlamp (LH) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Valeo PSA Discharge Headlamp (RH) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.0 JTD 16V | Texton Sliding Doors | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | Bosch EDC15 PSA Diesel Injection (Eng. 16V) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | Marelli DAV PSA Connect Control | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | Marelli Odometer W. Lamps (BTO) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | Marelli PSA Connect | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | Marelli PSA Instrument Panel | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | Sagem Multi-Function Screen | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | Bosch 5.7 ESP PSA ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | Bitron PSA Driver's Seat | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | Clarion CD Changer | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | Clarion/Philips Sound System | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | Marelli PSA Climate Control | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | WEBASTO Heater (PSA) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | Eaton Multi-Switch Stalk Unit (COM2000) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | Inalfa Central Sunroof | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | Inalfa Front Sunroof | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | Inalfa Rear Sunroof | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | Marelli Diesel Additive Check | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | Marelli PSA Driver's Door | ✓ | | | | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | Marelli PSA Passenger's Door | ✓ | | | | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | Valeo PSA Parking Control Unit | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | Valeo PSA Discharge Headlamp (LH) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | Valeo PSA Discharge Headlamp (RH) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 2.2 JTD 16V | Texton Sliding Doors | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 3.0 V6 24V | Bosch Motronic Me7.4.6 PSA Injection | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 3.0 V6 24V | ZF 4HP20 PSA Automatic Gearbox | ✓ | ✓ | ✓ | ✓ | | |

| | | | | | | | | | |
|--------|--------------|-------------|--|---|---|---|---|---|--|
| LANCIA | PHEDRA | 3.0 V6 24V | Marelli DAV PSA Connect Control | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 3.0 V6 24V | Marelli Odometer W. Lamps (BTO) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 3.0 V6 24V | Marelli PSA Connect | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 3.0 V6 24V | Marelli PSA Instrument Panel | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 3.0 V6 24V | Sagem Multi-Function Screen | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 3.0 V6 24V | Bosch 5.7 ESP PSA ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 3.0 V6 24V | Bitron PSA Driver's Seat | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 3.0 V6 24V | Clarion CD Changer | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 3.0 V6 24V | Clarion/Philips Sound System | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 3.0 V6 24V | Marelli PSA Climate Control | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 3.0 V6 24V | Eaton Multi-Switch Stalk Unit (COM2000) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 3.0 V6 24V | Inalfa Central Sunroof | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 3.0 V6 24V | Inalfa Front Sunroof | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 3.0 V6 24V | Inalfa Rear Sunroof | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 3.0 V6 24V | Marelli PSA Driver's Door | ✓ | | | ✓ | | |
| LANCIA | PHEDRA | 3.0 V6 24V | Marelli PSA Passenger's Door | ✓ | | | ✓ | | |
| LANCIA | PHEDRA | 3.0 V6 24V | Valeo PSA Parking Control Unit | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 3.0 V6 24V | Valeo PSA Discharge Headlamp (LH) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 3.0 V6 24V | Valeo PSA Discharge Headlamp (RH) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA | 3.0 V6 24V | Texton Sliding Doors | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Bosch EDC15 PSA Diesel Injection (Eng. 16V) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Siemens AL4 TA2000 V PSA Automatic Gearbox | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Siemens Diesel Injection SID803 CF4/EOBD (Eng. 16V) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Johnson/Borg Multi-Function Screen | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Marelli Connect PSA RT5 (CAN) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Siemens Diesel Injection SID803 CF4/EOBD (Eng. 16V) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | PSA Marelli Cluster (CAN) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | PSA Marelli Connect (CAN) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | PSA DAV Connect Command (CAN) | ✓ | | | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Bosch ABS 8.1 ESP PSA (CAN) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | BOSCH/TEMIC Airbag (CAN) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Delphi Alarm | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | PSA Bosch ABS 8 ESP (CAN) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Johnson EV Body Computer (BSI CAN) 2 | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Blaupunkt Radio | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Bosch Luminosity/Rain Sensor | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Clarion CD Magazine (CAN) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | HERMAN BECKER Navigator Auto Radio | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | WEBASTO Heater (PSA) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | PSA Denso Climate Control (CAN) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | HPI Power Steering | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Brose Driver's Door | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Brose Passenger Door | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Delphi Multi-Function Switch (COM2005) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Delphi Multi-Switch (COM2003) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Marelli Diesel Additive Control (CAN) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Siemens Tyre Pressure Control | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Valeo PSA Discharge Headlamp (LH) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Valeo PSA Discharge Headlamp (RH) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Texton Sliding Doors (CAN) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | PSA Valeo Parking Control Unit (CAN) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Inalfa Rear Sunroof (CAN) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Inalfa Front Sunroof (CAN) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.0 JTD 16V | Inalfa Centre Sunroof (CAN) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | AISIN AM6 Automatic Gearbox | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | Bosch Diesel Injection EDC16CP39 CF4/EOBD (2.2 Eng.) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | Bosch EDC15 PSA Diesel Injection (Eng. 16V) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | Johnson/Borg Multi-Function Screen | ✓ | ✓ | ✓ | ✓ | | |

| | | | | | | | | | |
|--------|---|-------------|---|---|---|---|---|---|--|
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | Marelli Connect PSA RT5 (CAN) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | Siemens Diesel Injection SID803 CF4/EOBD (Eng. 16V) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | PSA Marelli Cluster (CAN) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | PSA Marelli Connect (CAN) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | PSA DAV Connect Command (CAN) | ✓ | | | | ✓ | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | Bosch ABS 8.1 ESP PSA (CAN) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | BOSCH/TEMIC Airbag (CAN) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | Delphi Alarm | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | PSA Bosch ABS 8 ESP (CAN) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | Johnson EV Body Computer (BSI CAN) 2 | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | Blaupunkt Radio | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | Bosch Luminosity/Rain Sensor | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | Clarion CD Magazine (CAN) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | HERMAN BECKER Navigator Auto Radio | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | WEBASTO Heater (PSA) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | PSA Denso Climate Control (CAN) | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | HPI Power Steering | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | Brose Driver's Door | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | Brose Passenger Door | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | Delphi Multi-Switch (COM2003) | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | Inalfa Centre Sunroof (CAN) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | Marelli Diesel Additive Control (CAN) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | Siemens Tyre Pressure Control | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | Valeo PSA Discharge Headlamp (LH) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | Valeo PSA Discharge Headlamp (RH) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | Texton Sliding Doors (CAN) | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | PSA Valeo Parking Control Unit (CAN) | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | Inalfa Rear Sunroof (CAN) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | PHEDRA (180) | 2.2 JTD 16V | Inalfa Front Sunroof (CAN) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | RENEGADE | 2014 | ECM (Engine Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02593, sp02594, sp02595, sp02596, sp02597, sp02598, sp02599, sp02600, sp02601, sp02602, sp02603, sp02604, sp02605, sp02606, sp02607, sp02608, sp02609, sp02610, sp02611, sp02612, sp02613, sp02614, sp02615, sp02616 |
| LANCIA | RENEGADE | 2014 | TCM (Transmission Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02617 |
| LANCIA | RENEGADE | 2014 | ABS (Anti Lock Brakes) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02618, sp02619, sp02620 |
| LANCIA | RENEGADE | 2014 | ORC (Occupant Restraint) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | RENEGADE | 2014 | TTM (Trailer Tow Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | RENEGADE | 2014 | RRM (Radio Receiver Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02621, sp02622, sp02623 |
| LANCIA | RENEGADE | 2014 | RFH (Radio Frequency Hub) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02624, sp02625 |
| LANCIA | RENEGADE | 2014 | RBSS (Right Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | RENEGADE | 2014 | PCM (Powertrain Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02626, sp02627, sp02628, sp02629, sp02630, sp02631, sp02632, sp02633, sp02634, sp02635 |
| LANCIA | RENEGADE | 2014 | PAM (Parking Aid Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02636, sp02637 |
| LANCIA | RENEGADE | 2014 | LBSS (Left Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | RENEGADE | 2014 | IPC (Instrument Panel Cluster) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02638, sp02639, sp02640, sp02641, sp02642 |
| LANCIA | RENEGADE | 2014 | HVAC (Heat, Ventilation And A/C) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02643 |
| LANCIA | RENEGADE | 2014 | HALF (Haptical Lane Feedback) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02644 |
| LANCIA | RENEGADE | 2014 | ETM (Entertainment Telematic Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | RENEGADE | 2014 | ESM (Electronic Shifter Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02645, sp02646 |
| LANCIA | RENEGADE | 2014 | ESL (Electronic Steering Lock) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | RENEGADE | 2014 | EPS (Electric Power Steering) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02647 |
| LANCIA | RENEGADE | 2014 | DTCM (Drive Train Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02648, sp02649 |
| LANCIA | RENEGADE | 2014 | CSWM (Comfort Seat Wheel Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02650 |
| LANCIA | RENEGADE | 2014 | BCM (Body Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| LANCIA | RENEGADE | 2014 | AMP (Amplifier) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | RENEGADE | 2014 | ACC (Adaptive Cruise Control) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | PCM (Powertrain Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02651, sp02652, sp02653, sp02654, sp02655, sp02656, sp02657, sp02658, sp02659, sp02660, sp02661 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | TCM (Transmission Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02662, sp02663 |

| | | | | | | | | | |
|--------|---|------|---|---|---|---|---|---|---|
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | ABS (Anti-Lock Braking System) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02664, sp02665 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | SRS (Supplemental Inflatable Restraint System, ORC) | ✓ | ✓ | ✓ | ✓ | | sp02666 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | BCM (Body Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | ESM (Electronic Shifter Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02667, sp02668, sp02669, sp02670, sp02671 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | RFH (Radio Frequency Hub) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | HSM (Heated Seat Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | LBSS (Left Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | ICS (Integrated Center Stack) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | HVAC (Heat, Ventilation And A/C) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | Parking Electronic Module (PTS) | ✓ | ✓ | ✓ | ✓ | | sp02672 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | TPM (Tire Pressure Monitor) | ✓ | ✓ | ✓ | ✓ | | sp02673 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | SCCM (Steering Column Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | RBSS (Right Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | DDM (Driver Door Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | MSM (Memory Seat Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | FFCM (Forward Facing Camera Module) | ✓ | ✓ | ✓ | ✓ | | sp02674 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | ADCM (Active Damping Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | EPS (Electric Power Steering) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | AMP (Amplifier) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | DTCM (Drive Train Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | IPC (Instrument Panel Cluster) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02675 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | RADIO (RADIO) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | ACC (Adaptive Cruise Control) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | ITM (Intrusion) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | AFLS (Adaptive Front Lighting System) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02676 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2022 | PDM (Passenger Door Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | PCM (Powertrain Control Module) | ✓ | ✓ | ✓ | ✓ | | sp02677, sp02678, sp02679, sp02680, sp02681, sp02682, sp02683, sp02684, sp02685, sp02686, sp02687 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | TCM (Transmission Control Module) | ✓ | ✓ | ✓ | ✓ | | sp02688, sp02689 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | ABS (Anti-Lock Braking System) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02690, sp02691 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | SRS (Supplemental Inflatable Restraint System, ORC) | ✓ | ✓ | ✓ | ✓ | | sp02692 |

| | | | | | | | | | |
|--------|---|------|---|---|---|---|---|---|---|
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | BCM (Body Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | ESM (Electronic Shifter Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02693, sp02694, sp02695, sp02696, sp02697 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | RFH (Radio Frequency Hub) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | HSM (Heated Seat Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | LBSS (Left Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | ICS (Integrated Center Stack) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | HVAC (Heat, Ventilation And A/C) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | Parking Electronic Module(PTS) | ✓ | ✓ | ✓ | ✓ | | sp02698 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | TPM (Tire Pressure Monitor) | ✓ | ✓ | ✓ | ✓ | | sp02699 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | SCCM (Steering Column Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | RBSS (Right Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | DDM (Driver Door Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | MSM (Memory Seat Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | FFCM (Forward Facing Camera Module) | ✓ | ✓ | ✓ | ✓ | | sp02700 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | ADCM (Active Damping Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | EPS (Electric Power Steering) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | AMP (Amplifier) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | DTCM (Drive Train Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | IPC (Instrument Panel Cluster) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02701 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | RADIO (RADIO) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | ACC (Adaptive Cruise Control) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | ITM (Intrusion) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | AFLS (Adaptive Front Lighting System) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02702 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2021 | PDM (Passenger Door Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | PCM (Powertrain Control Module) | ✓ | ✓ | ✓ | ✓ | | sp02703, sp02704, sp02705, sp02706, sp02707, sp02708, sp02709, sp02710, sp02711, sp02712, sp02713 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | TCM (Transmission Control Module) | ✓ | ✓ | ✓ | ✓ | | sp02714, sp02715 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | ABS (Anti-Lock Braking System) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02716, sp02717 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | SRS (Supplemental Inflatable Restraint System, ORC) | ✓ | ✓ | ✓ | ✓ | | sp02718 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | BCM (Body Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | ESM (Electronic Shifter Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02719, sp02720, sp02721, sp02722, sp02723 |

| | | | | | | | | | |
|--------|---|------|---|---|---|---|---|---|---|
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | RFH (Radio Frequency Hub) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | HSM (Heated Seat Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | LBSS (Left Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | ICS (Integrated Center Stack) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | HVAC (Heat, Ventilation And A/C) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | Parking Electronic Module(PTS) | ✓ | ✓ | ✓ | ✓ | | sp02724 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | TPM (Tire Pressure Monitor) | ✓ | ✓ | ✓ | ✓ | | sp02725 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | SCCM (Steering Column Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | RBSS (Right Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | DDM (Driver Door Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | MSM (Memory Seat Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | FFCM (Forward Facing Camera Module) | ✓ | ✓ | ✓ | ✓ | | sp02726 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | ADCM (Active Damping Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | EPS (Electric Power Steering) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | AMP (Amplifier) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | DTCM (Drive Train Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | IPC (Instrument Panel Cluster) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02727 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | RADIO (RADIO) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | ACC (Adaptive Cruise Control) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | ITM (Intrusion) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | AFLS (Adaptive Front Lighting System) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02728 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2020 | PDM (Passenger Door Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | PCM (Powertrain Control Module) | ✓ | ✓ | ✓ | ✓ | | sp02729, sp02730, sp02731, sp02732, sp02733, sp02734, sp02735, sp02736, sp02737, sp02738, sp02739 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | TCM (Transmission Control Module) | ✓ | ✓ | ✓ | ✓ | | sp02740, sp02741 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | ABS (Anti-Lock Braking System) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02742, sp02743 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | SRS (Supplemental Inflatable Restraint System, ORC) | ✓ | ✓ | ✓ | ✓ | | sp02744 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | BCM (Body Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | ESM (Electronic Shifter Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02745, sp02746, sp02747, sp02748, sp02749 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | RFH (Radio Frequency Hub) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | HSM (Heated Seat Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |

| | | | | | | | | | |
|--------|---|------|---|---|---|---|---|---|---|
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | LBSS (Left Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | ICS (Integrated Center Stack) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | HVAC (Heat, Ventilation And A/C) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | Parking Electronic Module(PTS) | ✓ | ✓ | ✓ | ✓ | | sp02750 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | TPM (Tire Pressure Monitor) | ✓ | ✓ | ✓ | ✓ | | sp02751 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | SCCM (Steering Column Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | RBSS (Right Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | DDM (Driver Door Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | MSM (Memory Seat Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | FFCM (Forward Facing Camera Module) | ✓ | ✓ | ✓ | ✓ | | sp02752 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | ADCM (Active Damping Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | EPS (Electric Power Steering) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | AMP (Amplifier) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | DTCM (Drive Train Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | IPC (Instrument Panel Cluster) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02753 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | RADIO (RADIO) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | ACC (Adaptive Cruise Control) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | ITM (Intrusion) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | AFLS (Adaptive Front Lighting System) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02754 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2019 | PDM (Passenger Door Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | PCM (Powertrain Control Module) | ✓ | ✓ | ✓ | ✓ | | sp02755, sp02756, sp02757, sp02758, sp02759, sp02760, sp02761, sp02762, sp02763, sp02764, sp02765 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | TCM (Transmission Control Module) | ✓ | ✓ | ✓ | ✓ | | sp02766, sp02767 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | ABS (Anti-Lock Braking System) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02768, sp02769 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | SRS (Supplemental Inflatable Restraint System, ORC) | ✓ | ✓ | ✓ | ✓ | | sp02770 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | BCM (Body Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | ESM (Electronic Shifter Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02771, sp02772, sp02773, sp02774, sp02775 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | RFH (Radio Frequency Hub) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | HSM (Heated Seat Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | LBSS (Left Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | ICS (Integrated Center Stack) | ✓ | ✓ | ✓ | ✓ | ✓ | |

| | | | | | | | | | |
|--------|---|------|---|---|---|---|---|---|---|
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | HVAC (Heat, Ventilation And A/C) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | Parking Electronic Module(PTS) | ✓ | ✓ | ✓ | ✓ | | sp02776 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | TPM (Tire Pressure Monitor) | ✓ | ✓ | ✓ | ✓ | | sp02777 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | SCCM (Steering Column Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | RBSS (Right Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | DDM (Driver Door Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | MSM (Memory Seat Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | FFCM (Forward Facing Camera Module) | ✓ | ✓ | ✓ | ✓ | | sp02778 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | ADCM (Active Damping Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | EPS (Electric Power Steering) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | AMP (Amplifier) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | DTCM (Drive Train Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | IPC (Instrument Panel Cluster) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02779 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | RADIO (RADIO) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | ACC (Adaptive Cruise Control) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | ITM (Intrusion) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | AFLS (Adaptive Front Lighting System) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02780 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2018 | PDM (Passenger Door Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | PCM (Powertrain Control Module) | ✓ | ✓ | ✓ | ✓ | | sp02781, sp02782, sp02783, sp02784, sp02785, sp02786, sp02787, sp02788, sp02789, sp02790, sp02791 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | TCM (Transmission Control Module) | ✓ | ✓ | ✓ | ✓ | | sp02792, sp02793 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | ABS (Anti-Lock Braking System) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02794, sp02795 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | SRS (Supplemental Inflatable Restraint System, ORC) | ✓ | ✓ | ✓ | ✓ | | sp02796 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | BCM (Body Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | ESM (Electronic Shifter Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02797, sp02798, sp02799, sp02800, sp02801 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | RFH (Radio Frequency Hub) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | HSM (Heated Seat Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | LBSS (Left Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |

| | | | | | | | | | |
|--------|---|------|---------------------------------------|---|---|---|---|---|---|
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | ICS (Integrated Center Stack) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | HVAC (Heat, Ventilation And A/C) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | Parking Electronic Module (PTS) | ✓ | ✓ | ✓ | ✓ | | sp02802 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | TPM (Tire Pressure Monitor) | ✓ | ✓ | ✓ | ✓ | | sp02803 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | SCCM (Steering Column Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | RBSS (Right Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | DDM (Driver Door Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | MSM (Memory Seat Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | FFCM (Forward Facing Camera Module) | ✓ | ✓ | ✓ | ✓ | | sp02804 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | ADCM (Active Damping Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | EPS (Electric Power Steering) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | AMP (Amplifier) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | DTCM (Drive Train Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | IPC (Instrument Panel Cluster) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02805 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | RADIO (RADIO) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | ACC (Adaptive Cruise Control) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | ITM (Intrusion) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | AFLS (Adaptive Front Lighting System) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02806 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2017 | PDM (Passenger Door Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | PCM (Powertrain Control Module) | ✓ | ✓ | ✓ | ✓ | | sp02807, sp02808, sp02809, sp02810, sp02811, sp02812, sp02813, sp02814, sp02815, sp02816, sp02817 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | TCM (Transmission Control Module) | ✓ | ✓ | ✓ | ✓ | | sp02818, sp02819 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | ABS (Anti Lock Brakes) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02820, sp02821 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | ORC (Occupant Restraint) | ✓ | ✓ | ✓ | ✓ | | sp02822 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | TPM (Tire Pressure Monitor) | ✓ | ✓ | ✓ | ✓ | | sp02823 |

| | | | | | | | | | |
|--------|---|------|---------------------------------------|---|---|---|---|---|---|
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | SCCM (Steering Column Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | RFH (Radio Frequency Hub) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | RBSS (Right Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | RADIO (RADIO) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | PTS (Parktronic) | ✓ | ✓ | ✓ | ✓ | | sp02824 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | PDM (Passenger Door Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | MSM (Memory Seat Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | LBSS (Left Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | ITM (Intrusion) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | IPC (Instrument Panel Cluster) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02825 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | ICS (Integrated Center Stack) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | HVAC (Heat, Ventilation And A/C) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | HSM (Heated Seat Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | FFCM (Forward Facing Camera Module) | ✓ | ✓ | ✓ | ✓ | | sp02826 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | ESM (Electronic Shifter Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02827, sp02828, sp02829, sp02830, sp02831 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | EPS (Electric Power Steering) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | DTCM (Drive Train Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | DDM (Driver Door Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | BCM (Body Control Module) | | ✓ | ✓ | ✓ | ✓ | ✓ |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | AMP (Amplifier) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | AFLS (Adaptive Front Lighting System) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02832 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | ADCM (Active Damping Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2016 | ACC (Adaptive Cruise Control) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | PCM (Powertrain Control Module) | ✓ | ✓ | ✓ | ✓ | | sp02833, sp02834, sp02835, sp02836, sp02837, sp02838, sp02839, sp02840, sp02841, sp02842, sp02843 |

| | | | | | | | | | |
|--------|---|------|---------------------------------------|---|---|---|---|---|--|
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | TCM (Transmission Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | ABS (Anti Lock Brakes) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02844, sp02845 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | ORC (Occupant Restraint) | ✓ | ✓ | ✓ | ✓ | | sp02846 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | TPM (Tire Pressure Monitor) | ✓ | ✓ | ✓ | ✓ | | sp02847, sp02848, sp02849, sp02850, sp02851, sp02852, sp02853, sp02854 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | SCCM (Steering Column Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | RFH (Radio Frequency Hub) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | RBSS (Right Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | RADIO (RADIO) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | PTS (Parktronics) | ✓ | ✓ | ✓ | ✓ | | sp02855 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | PDM (Passenger Door Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | MSM (Memory Seat Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | LBSS (Left Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | ITM (Intrusion) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | IPC (Instrument Panel Cluster) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02856 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | ICS (Integrated Center Stack) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | HVAC (Heat, Ventilation And A/C) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | HSM (Heated Seat Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | FFCM (Forward Facing Camera Module) | ✓ | ✓ | ✓ | ✓ | | sp02857 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | ESM (Electronic Shifter Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02858, sp02859, sp02860, sp02861, sp02862 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | EPS (Electric Power Steering) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | DTCM (Drive Train Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | DDM (Driver Door Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | BCM (Body Control Module) | | ✓ | ✓ | ✓ | ✓ | ✓ |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | AMP (Amplifier) | ✓ | ✓ | ✓ | ✓ | | |

| | | | | | | | | | |
|--------|---|------|---------------------------------------|---|---|---|---|---|---|
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | AFLS (Adaptive Front Lighting System) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02863 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | ADCM (Active Damping Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2015 | ACC (Adaptive Cruise Control) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | PCM (Powertrain Control Module) | ✓ | ✓ | ✓ | ✓ | | sp02864, sp02865, sp02866, sp02867, sp02868, sp02869, sp02870, sp02871, sp02872, sp02873, sp02874, sp02875, sp02876 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | TCM (Transmission Control Module) | ✓ | ✓ | ✓ | ✓ | | sp02877 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | ABS (Anti Lock Brakes) | ✓ | ✓ | ✓ | ✓ | | sp02878, sp02879 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | ORC (Occupant Restraint) | ✓ | ✓ | ✓ | ✓ | | sp02880 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | TPM (Tire Pressure Monitor) | ✓ | ✓ | ✓ | ✓ | | sp02881, sp02882, sp02883, sp02884, sp02885, sp02886 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | TGW (Telematic Gateway Radio) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | SCCM (Steering Column Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | RFH (Radio Frequency Hub) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | RBSS (Right Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | PTS (Parktronics) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02887, sp02888 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | PDM (Passenger Door Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | MSM (Memory Seat Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | LBSS (Left Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | ITM (Intrusion) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | IPC (Instrument Panel Cluster) | ✓ | ✓ | ✓ | ✓ | | sp02889 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | ICS (Integrated Center Stack) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | HVAC (Heat, Ventilation And A/C) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | HSM (Heated Seat Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | HFM (Hands Free Module (Cell Phone)) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | ESM (Electronic Shifter Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | EPS (Electric Power Steering) | ✓ | ✓ | ✓ | ✓ | | |

| | | | | | | | | | |
|--------|---|------|---------------------------------------|---|---|---|---|---|--|
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | DTCM (Drive Train Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | DDM (Driver Door Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | BCM (Body Control Module) | | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | AMP (Amplifier) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | AFLS (Adaptive Front Lighting System) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02893 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | ADCM (Active Damping Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2014 | ACC (Adaptive Cruise Control) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | PCM (Powertrain Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02894, sp02895, sp02896, sp02897, sp02898, sp02899, sp02900, sp02901 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | TCM (Transmission Control Module) | ✓ | ✓ | ✓ | ✓ | | sp02902 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | ABS (Anti Lock Brakes) | ✓ | ✓ | ✓ | ✓ | | sp02903, sp02904 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | ORC (Occupant Restraint) | ✓ | ✓ | ✓ | ✓ | | sp02905 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | TPM (Tire Pressure Monitor) | ✓ | ✓ | ✓ | ✓ | | sp02906, sp02907, sp02908, sp02909, sp02910, sp02911 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | TGW (Telematic Gateway Radio) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | SCCM (Steering Column Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | RFH (Radio Frequency Hub) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | RBSS (Right Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | PTS (Parktronics) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02912, sp02913 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | PDM (Passenger Door Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | MSM (Memory Seat Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | LBSS (Left Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | ITM (Intrusion) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | IPC (Instrument Panel Cluster) | ✓ | ✓ | ✓ | ✓ | | sp02914 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | ICS (Integrated Center Stack) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | HVAC (Heat, Ventilation And A/C) | ✓ | ✓ | ✓ | ✓ | ✓ | |

| | | | | | | | | | |
|--------|---|------|---------------------------------------|---|---|---|---|---|--|
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | HSM (Heated Seat Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | HFM (Hands Free Module (Cell Phone)) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | ESM (Electronic Shifter Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | EPS (Electric Power Steering) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | DTCM (Drive Train Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | DDM (Driver Door Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | BCM (Body Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | AMP (Amplifier) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | AFLS (Adaptive Front Lighting System) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02918 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | ADCM (Active Damping Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2013 | ACC (Adaptive Cruise Control) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | PCM (Powertrain Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02919, sp02920, sp02921, sp02922, sp02923, sp02924, sp02925, sp02926 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | TCM (Transmission Control Module) | ✓ | ✓ | ✓ | ✓ | | sp02927 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | ABS (Anti Lock Brakes) | ✓ | ✓ | ✓ | ✓ | | sp02928, sp02929 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | ORC (Occupant Restraint) | ✓ | ✓ | ✓ | ✓ | | sp02930 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | TPM (Tire Pressure Monitor) | ✓ | ✓ | ✓ | ✓ | | sp02931, sp02932, sp02933, sp02934, sp02935, sp02936 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | TGW (Telematic Gateway Radio) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | SCCM (Steering Column Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | RFH (Radio Frequency Hub) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | PTS (Parktronics) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02937, sp02938 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | PDM (Passenger Door Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | MSM (Memory Seat Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | ITM (Intrusion) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | IPC (Instrument Panel Cluster) | ✓ | ✓ | ✓ | ✓ | | sp02939 |

| | | | | | | | | | |
|--------|---|------------|--|---|---|---|---|---|---------|
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | ICS (Integrated Center Stack) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | HVAC (Heat, Ventilation And A/C) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | HSM (Heated Seat Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | HFM (Hands Free Module (Cell Phone)) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | ESM (Electronic Shifter Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | EPS (Electric Power Steering) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | DTCM (Drive Train Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | DDM (Driver Door Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | BSM (Blind Spot Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | BCM (Body Control Module) | | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | AMP (Amplifier) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | AFLS (Adaptive Front Lighting System) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02943 |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | ADCM (Active Damping Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | 300 / MAGNUM / CHARGER (Pre-2011) / THEMA | 2012 | ACC (Adaptive Cruise Control) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.0 20V TB | Bosch Motronic Me7.3.1 EOBD Injection (2 Lambda Sensors) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.0 20V TB | ESP TRW Lucas ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.0 20V TB | Marelli Full Body Computer | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.0 20V TB | Marelli Easy-Go Body Computer | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.0 20V TB | TRW MY 99 Airbag (2F-4P-4L-2T-I-S-C) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.0 20V TB | TRW MY 99 Airbag (2F-4P-2L-2T-I-S-C) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.0 20V TB | Bitron Driving Seat | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.0 20V TB | Bitron Passenger Seat | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.0 20V TB | Borletti/Hella Climate Control | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.0 20V TB | Bosch Adaptive Cruise Control | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.0 20V TB | SAGEM Speedpro Power Steering | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.0 20V TB | Marelli Driver's Door | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.0 20V TB | Marelli Boot | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.0 20V TB | Marelli Passenger Door | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.0 20V TB | Valeo Parking Control Unit | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 20V | AISIN YLII 5 Automatic Gearbox | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 20V | Bosch Motronic Me3.1 EOBD Injection (Eng. 2.0/2.4 20V) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 20V | ESP TRW Lucas ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 20V | Marelli Full Body Computer | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 20V | Marelli Easy-Go Body Computer | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 20V | TRW MY 99 Airbag (2F-4P-4L-2T-I-S-C) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 20V | TRW MY 99 Airbag (2F-4P-2L-2T-I-S-C) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 20V | Bitron Driving Seat | ✓ | ✓ | ✓ | ✓ | | |

| | | | | | | | | | |
|--------|---------|-------------|---|---|---|---|---|--|--|
| LANCIA | THESTIS | 2.4 20V | Bitron Passenger Seat | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 20V | Borletti/Hella Climate Control | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 20V | Bosch Adaptive Cruise Control | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 20V | SAGEM Speedpro Power Steering | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 20V | Marelli Driver's Door | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 20V | Marelli Boot | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 20V | Marelli Passenger Door | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 20V | Valeo Parking Control Unit | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 10V | Bosch EDC15 CF3/EOBD Diesel Injection (Eng. 1.9/2.4) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 10V | ESP TRW Lucas ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 10V | Marelli Full Body Computer | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 10V | TRW MY 99 Airbag (2F-4P-4L-2T-I-S-C) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 10V | TRW MY 99 Airbag (2F-4P-2L-2T-I-S-C) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 10V | Bitron Driving Seat | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 10V | Bitron Passenger Seat | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 10V | Borletti/Hella Climate Control | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 10V | Bosch Adaptive Cruise Control | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 10V | SAGEM Speedpro Power Steering | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 10V | Marelli Driver's Door | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 10V | Marelli Boot | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 10V | Marelli Passenger Door | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 10V | Valeo Parking Control Unit | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 20V | AISIN YLII 5 Automatic Gearbox | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 20V | Bosch Diesel Injection EDC16C39 CF4/EOBD (Eng. 1.9/2.4) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 20V | Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 Eng.) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 20V | Nippon Seiki Instrument Panel (Thesis) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 20V | ESP TRW Lucas ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 20V | Marelli Full Body Computer | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 20V | TRW MY 99 Airbag (2F-4P-4L-2T-I-S-C) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 20V | TRW MY 99 Airbag (2F-4P-2L-2T-I-S-C) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 20V | Bitron Driving Seat | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 20V | Bitron Passenger Seat | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 20V | Borletti/Hella Climate Control | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 20V | Bosch Adaptive Cruise Control | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 20V | SAGEM Speedpro Power Steering | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 20V | Marelli Driver's Door | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 20V | Marelli Boot | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 20V | Marelli Passenger Door | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 2.4 JTD 20V | Valeo Parking Control Unit | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 3.0 V6 24V | AISIN YLII 5 Automatic Gearbox | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 3.0 V6 24V | Bosch Motronic EOBD ME3.1 Injection (Eng. V6) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 3.0 V6 24V | Nippon Seiki Instrument Panel (Thesis) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 3.0 V6 24V | ESP TRW Lucas ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 3.0 V6 24V | Marelli Full Body Computer | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 3.0 V6 24V | Marelli Easy-Go Body Computer | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 3.0 V6 24V | TRW MY 99 Airbag (2F-4P-4L-2T-I-S-C) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 3.0 V6 24V | TRW MY 99 Airbag (2F-4P-2L-2T-I-S-C) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 3.0 V6 24V | Bitron Driving Seat | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 3.0 V6 24V | Bitron Passenger Seat | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 3.0 V6 24V | Borletti/Hella Climate Control | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 3.0 V6 24V | Bosch Adaptive Cruise Control | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 3.0 V6 24V | SAGEM Speedpro Power Steering | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESTIS | 3.0 V6 24V | Marelli Driver's Door | ✓ | ✓ | ✓ | ✓ | | |

| | | | | | | | | | |
|--------|------------------------------------|------------|--|---|---|---|---|---|---|
| LANCIA | THESIS | 3.0 V6 24V | Marelli Boot | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESIS | 3.0 V6 24V | Marelli Passenger Door | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESIS | 3.0 V6 24V | Valeo Parking Control Unit | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESIS | 3.2 V6 24V | AISIN VLII 5 Automatic Gearbox | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESIS | 3.2 V6 24V | Bosch Motronic Me7.3.1 E0BD Injection | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESIS | 3.2 V6 24V | Injection Bosch motronic mer.3.1 Outstude | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESIS | 3.2 V6 24V | Nippon Seiki Instrument Panel (Thesis) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESIS | 3.2 V6 24V | ESP TRW Lucas ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESIS | 3.2 V6 24V | Marelli Full Body Computer | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESIS | 3.2 V6 24V | Marelli Easy-Go Body Computer | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESIS | 3.2 V6 24V | TRW MY 99 Airbag (2F-4P-4L-2T-I-S-C) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESIS | 3.2 V6 24V | TRW MY 99 Airbag (2F-4P-2L-2T-I-S-C) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESIS | 3.2 V6 24V | Bitron Driving Seat | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESIS | 3.2 V6 24V | Bitron Passenger Seat | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESIS | 3.2 V6 24V | Borletti/Hella Climate Control | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESIS | 3.2 V6 24V | Bosch Adaptive Cruise Control | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESIS | 3.2 V6 24V | SAGEM Speedpro Power Steering | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESIS | 3.2 V6 24V | Marelli Driver's Door | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESIS | 3.2 V6 24V | Marelli Boot | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESIS | 3.2 V6 24V | Marelli Passenger Door | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | THESIS | 3.2 V6 24V | Valeo Parking Control Unit | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2016 | PCM (Powertrain Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02944, sp02945, sp02946, sp02947, sp02948 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | PCM (Powertrain Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02949, sp02950, sp02951, sp02952, sp02953 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | DTCM (Drive Train Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | ABS (Anti Lock Brakes) | ✓ | ✓ | ✓ | ✓ | | sp02954 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | ORC (Occupant Restraint) | ✓ | ✓ | ✓ | ✓ | | sp02955, sp02956 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | WCM (Wireless Control) | ✓ | ✓ | ✓ | ✓ | | sp02957, sp02958 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | VES2 (Second Row Screen) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | VES3 (Last Row Screen) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | TPM (Tire Pressure Monitor) | ✓ | ✓ | ✓ | ✓ | | sp02959, sp02960, sp02961, sp02962, sp02963, sp02964, sp02965 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | TIPMGW (Central Gateway) | ✓ | ✓ | ✓ | ✓ | | sp02966, sp02967, sp02968 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | SUNR (Sunroof) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | SAS (Steering Angle Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | RBSS (Right Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | RADIO (RADIO) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | PTS (Parktronics) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02969, sp02970 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | PSDMR (Power Sliding Doors (Right)) | ✓ | ✓ | ✓ | ✓ | | sp02971, sp02972, sp02973 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | PSDML (Power Sliding Doors (Left)) | ✓ | ✓ | ✓ | ✓ | | sp02974, sp02975, sp02976 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | PLGM (Power Liftgate) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | PEM (Passive Entry Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | MSMD (Memory Seat) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | LBSS (Left Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | ITM (Intrusion) | ✓ | ✓ | ✓ | ✓ | | sp02977 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | HVAC (Heat, Ventilation And A/C) | ✓ | ✓ | ✓ | ✓ | | sp02978 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | HSM (Heated Seat Module) | ✓ | ✓ | ✓ | ✓ | | sp02979 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | HIDT (High Intensity Discharge Translator) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | HFM (Hands Free Module (Cell Phone)) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | FSM (Fold Stow Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | EPPM (Electronic Pedestrian Protection Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | DVD (DVD Changer) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | DMRR (Door Module Rear Right) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | DMRL (Door Module Rear Left) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | DMFR (Door Module Front Right) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | DMFL (Door Module Front Left) | ✓ | ✓ | ✓ | ✓ | | |

| | | | | | | | | | |
|--------|------------------------------------|------|---|---|---|---|---|---|--|
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | CCN (Instrument Cluster/Cabin Compartment Node) | ✓ | ✓ | ✓ | ✓ | | sp02980, sp02981, sp02982 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | AMP (Amplifier) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2015 | AHEM (Automatic High Beam) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | PCM (Powertrain Control Module) | ✓ | ✓ | ✓ | ✓ | ✓ | sp02983, sp02984, sp02985, sp02986, sp02987 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | TCM (Transmission Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | ABS (Anti Lock Brakes) | ✓ | ✓ | ✓ | ✓ | | sp02988 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | ORC (Occupant Restraint) | ✓ | ✓ | ✓ | ✓ | | sp02989, sp02990 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | WCM (Wireless Control) | ✓ | ✓ | ✓ | ✓ | | sp02991, sp02992 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | VES2 (Second Row Screen) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | VES3 (Last Row Screen) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | TPM (Tire Pressure Monitor) | ✓ | ✓ | ✓ | ✓ | | sp02993, sp02994, sp02995, sp02996, sp02997, sp02998, sp02999 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | TIPMCGW (Central Gateway) | ✓ | ✓ | ✓ | ✓ | | sp03000, sp03001, sp03002 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | SUNR (Sunroof) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | SAS (Steering Angle Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | RBSS (Right Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | RADIO (RADIO) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | PTS (Parktronics) | ✓ | ✓ | ✓ | ✓ | ✓ | sp03003, sp03004 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | PSDMR (Power Sliding Doors (Right)) | ✓ | ✓ | ✓ | ✓ | | sp03005, sp03006, sp03007 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | PSDML (Power Sliding Doors (Left)) | ✓ | ✓ | ✓ | ✓ | | sp03008, sp03009, sp03010 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | PLGM (Power Liftgate) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | PEM (Passive Entry Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | MSMD (Memory Seat) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | LBSS (Left Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | ITM (Intrusion) | ✓ | ✓ | ✓ | ✓ | | sp03011 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | HVAC (Heat, Ventilation And A/C) | ✓ | ✓ | ✓ | ✓ | | sp03012 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | HSM (Heated Seat Module) | ✓ | ✓ | ✓ | ✓ | | sp03013 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | HIDT (High Intensity Discharge Translator) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | HFM (Hands Free Module (Cell Phone)) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | FSM (Fold Stow Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | EPPM (Electronic Pedestrian Protection Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | DVD (DVD Changer) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | DMRR (Door Module Rear Right) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | DMRL (Door Module Rear Left) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | DMFR (Door Module Front Right) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | DMFL (Door Module Front Left) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | CCN (Instrument Cluster/Cabin Compartment Node) | ✓ | ✓ | ✓ | ✓ | | sp03014, sp03015, sp03016 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | AMP (Amplifier) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2014 | AHEM (Automatic High Beam) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | PCM (Powertrain Control Module) | ✓ | ✓ | ✓ | ✓ | | sp03017, sp03018, sp03019, sp03020, sp03021, sp03022, sp03023, sp03024, sp03025, sp03026 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | TCM (Transmission Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | ABS (Anti Lock Brakes) | ✓ | ✓ | ✓ | ✓ | | sp03027, sp03028 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | ORC (Occupant Restraint) | ✓ | ✓ | ✓ | ✓ | | sp03029, sp03030 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | WCM (Wireless Control) | ✓ | ✓ | ✓ | ✓ | | sp03031, sp03032 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | VES2 (Second Row Screen) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | VES3 (Last Row Screen) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | TPM (Tire Pressure Monitor) | ✓ | ✓ | ✓ | ✓ | | sp03033, sp03034, sp03035, sp03036, sp03037, sp03038, sp03039 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | TIPMCGW (Central Gateway) | ✓ | ✓ | ✓ | ✓ | | sp03040, sp03041, sp03042 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | SUNR (Sunroof) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | SAS (Steering Angle Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | RBSS (Right Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | RADIO (RADIO) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | PTS (Parktronics) | ✓ | ✓ | ✓ | ✓ | ✓ | sp03043, sp03044 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | PSDMR (Power Sliding Doors (Right)) | ✓ | ✓ | ✓ | ✓ | | sp03045, sp03046, sp03047 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | PSDML (Power Sliding Doors (Left)) | ✓ | ✓ | ✓ | ✓ | | sp03048, sp03049, sp03050 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | PLGM (Power Liftgate) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | PEM (Passive Entry Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | MSMD (Memory Seat) | ✓ | ✓ | ✓ | ✓ | | |

| | | | | | | | | | |
|--------|------------------------------------|------|---|---|---|---|---|---|--|
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | LBSS (Left Blind Spot Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | ITM (Intrusion) | ✓ | ✓ | ✓ | ✓ | | sp03051 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | HVAC (Heat, Ventilation And A/C) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | HSM (Heated Seat Module) | ✓ | ✓ | ✓ | ✓ | | sp03052 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | HIDT (High Intensity Discharge Translator) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | HFM (Hands Free Module (Cell Phone)) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | FSM (Fold Stow Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | EPPM (Electronic Pedestrian Protection Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | DVD (DVD Changer) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | DMRR (Door Module Rear Right) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | DMRL (Door Module Rear Left) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | DMFR (Door Module Front Right) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | DMFL (Door Module Front Left) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | CCN (Instrument Cluster/Cabin Compartment Node) | ✓ | ✓ | ✓ | ✓ | | sp03053, sp03054, sp03055 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | AMP (Amplifier) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2013 | AHBM (Automatic High Beam) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | PCM (Powertrain Control Module) | ✓ | ✓ | ✓ | ✓ | | sp03056, sp03057, sp03058, sp03059, sp03060, sp03061, sp03062, sp03063, sp03064, sp03065 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | TCM (Transmission Control Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | ABS (Anti Lock Brakes) | ✓ | ✓ | ✓ | ✓ | | sp03066, sp03067 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | ORC (Occupant Restraint) | ✓ | ✓ | ✓ | ✓ | | sp03068, sp03069, sp03070 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | WCM (Wireless Control) | ✓ | ✓ | ✓ | ✓ | | sp03071, sp03072 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | VES2 (Second Row Screen) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | VES3 (Last Row Screen) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | TPM (Tire Pressure Monitor) | ✓ | ✓ | ✓ | ✓ | | sp03073, sp03074, sp03075, sp03076, sp03077, sp03078, sp03079 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | TIPMCGW (Central Gateway) | ✓ | ✓ | ✓ | ✓ | | sp03080, sp03081, sp03082 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | SUNR (Sunroof) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | SAS (Steering Angle Sensor) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | RADIO (RADIO) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | PTS (Parktronics) | ✓ | ✓ | ✓ | ✓ | ✓ | sp03083, sp03084 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | PSDMR (Power Sliding Doors (Right)) | ✓ | ✓ | ✓ | ✓ | | sp03085, sp03086, sp03087 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | PSDML (Power Sliding Doors (Left)) | ✓ | ✓ | ✓ | ✓ | | sp03088, sp03089, sp03090 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | PLGM (Power Liftgate) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | PEM (Passive Entry Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | MSMD (Memory Seat) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | ITM (Intrusion) | ✓ | ✓ | ✓ | ✓ | | sp03091 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | HVAC (Heat, Ventilation And A/C) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | HSM (Heated Seat Module) | ✓ | ✓ | ✓ | ✓ | | sp03092 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | HIDT (High Intensity Discharge Translator) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | HFM (Hands Free Module (Cell Phone)) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | FSM (Fold Stow Module) | ✓ | ✓ | ✓ | ✓ | ✓ | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | EPPM (Electronic Pedestrian Protection Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | DVD (DVD Changer) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | DMRR (Door Module Rear Right) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | DMRL (Door Module Rear Left) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | DMFR (Door Module Front Right) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | DMFL (Door Module Front Left) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | CCN (Instrument Cluster/Cabin Compartment Node) | ✓ | ✓ | ✓ | ✓ | | sp03093, sp03094, sp03095 |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | BSM (Blind Spot Module) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | AMP (Amplifier) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | TOWM & COUNTRY / CARAVAN / VOYAGER | 2012 | AHBM (Automatic High Beam) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | Y | 1.1 | Allied MY 97 Air Bag (2F-2P-2L-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | Y | 1.1 | Allied MY 97 Airbag (2F-2P-2L-1) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | Y | 1.1 | Bosch 5.3 ABS | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | Y | 1.2 | Allied MY 97 Air Bag (2F-2P-2L-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | Y | 1.2 | Allied MY 97 Airbag (2F-2P-2L-1) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | Y | 1.2 | Bosch 5.3 ABS | ✓ | ✓ | ✓ | ✓ | | |

| | | | | | | | | | |
|--------|---|-------------|---------------------------------------|---|---|---|---|--|--|
| LANCIA | Y | 1.2 16V | Allied MY 97 Air Bag (2F-2P-2L-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | Y | 1.2 16V | Allied MY 97 Airbag (2F-2P-2L-I) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | Y | 1.2 16V | Bosch 5.3 ABS | ✓ | ✓ | ✓ | | | |
| LANCIA | Y | 1.2 16V | Allied MY 97 Airbag (2F-2P-I) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | Y | 1.2 16V CF3 | Allied MY 97 Air Bag (2F-2P-2L-S) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | Y | 1.2 16V CF3 | Allied MY 97 Airbag (2F-2P-2L-I) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | Y | 1.2 16V CF3 | Bosch Motronic ME7.3H4 EOBD Injection | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | Y | 1.2 16V CF3 | Bosch 5.3 ABS | ✓ | ✓ | ✓ | | | |
| LANCIA | Y | 1.2 16V CF3 | Allied MY 97 Airbag (2F-2P-I) | ✓ | ✓ | ✓ | ✓ | | |
| LANCIA | Y | 1.2 CF3 | Allied MY 97 Air Bag (2F-2P-2L-S) | ✓ | ✓ | ✓ | ✓ | | |

XTOOL

Special Functions List

| No. | Functions Name | System Name |
|---------|---|---|
| sp00001 | Air-Conditioning Self Learning | PCM (Powertrain Control Module) |
| sp00002 | Reset Accelerator Pedal Adaptives | PCM (Powertrain Control Module) |
| sp00003 | Brake Switch Learn | PCM (Powertrain Control Module) |
| sp00004 | Clutch Pedal Learn | PCM (Powertrain Control Module) |
| sp00005 | Check PCM Odometer | PCM (Powertrain Control Module) |
| sp00006 | Emissions Rolls Test Mode | PCM (Powertrain Control Module) |
| sp00007 | Air-Conditioning Self Learning | PCM (Powertrain Control Module) |
| sp00008 | Reset ECU | PCM (Powertrain Control Module) |
| sp00009 | Reset Memory | PCM (Powertrain Control Module) |
| sp00010 | Reset Memory | PCM (Powertrain Control Module) |
| sp00011 | ECU Replacement With Value Transfer | TCM (Transmission Control Module) |
| sp00012 | Bleed Hydraulic Circuit | TCM (Transmission Control Module) |
| sp00013 | Hydraulic Circuit Depressurization | TCM (Transmission Control Module) |
| sp00014 | Learn Clutches Contact Point | TCM (Transmission Control Module) |
| sp00015 | Quick Learn | TCM (Transmission Control Module) |
| sp00016 | ABS Static Test | ABS (Anti-Lock Braking System) |
| sp00017 | Longitudinal G-Sensor Calibration Test | ABS (Anti-Lock Braking System) |
| sp00018 | Exit Shipping Mode | BCM (Body Control Module) |
| sp00019 | Self Learning Motor Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp00020 | IPC Enable Seatbelt Minder Chime | IC (Instrument Cluster) |
| sp00021 | Reset Service Information | IC (Instrument Cluster) |
| sp00022 | IPC Disable Seatbelt Minder Chime | IC (Instrument Cluster) |
| sp00023 | IPC Replacement | IC (Instrument Cluster) |
| sp00024 | RADIO Proxi Configuration | RFH (Radio Frequency Hub) |
| sp00025 | Clear Steering Pull Compensation | EPS (Electric Power Steering) |
| sp00026 | Initialize EPS | EPS (Electric Power Steering) |
| sp00027 | CTM Proxi Configuration | CTM (Convergence Telematic Module) |
| sp00028 | Clear TPM Warnings | TPMS (Tire Pressure Monitoring System) |
| sp00029 | Clear TPM Sensor Rolls Test Results | TPMS (Tire Pressure Monitoring System) |
| sp00030 | TPM FGA Proxi Configuration | TPMS (Tire Pressure Monitoring System) |
| sp00031 | Update Front And Rear Axle Nominal Tire Pressure Values | TPMS (Tire Pressure Monitoring System) |
| sp00032 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00033 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00034 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00035 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00036 | TPM Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp00037 | Air-Conditioning Self Learning | PCM (Powertrain Control Module) |
| sp00038 | Reset Accelerator Pedal Adaptives | PCM (Powertrain Control Module) |
| sp00039 | Brake Switch Learn | PCM (Powertrain Control Module) |
| sp00040 | Clutch Pedal Learn | PCM (Powertrain Control Module) |

| | | |
|---------|---|---|
| sp00041 | Check PCM Odometer | PCM (Powertrain Control Module) |
| sp00042 | Emissions Rolls Test Mode | PCM (Powertrain Control Module) |
| sp00043 | Air-Conditioning Self Learning | PCM (Powertrain Control Module) |
| sp00044 | Reset ECU | PCM (Powertrain Control Module) |
| sp00045 | Reset Memory | PCM (Powertrain Control Module) |
| sp00046 | Reset Memory | PCM (Powertrain Control Module) |
| sp00047 | ECU Replacement With Value Transfer | TCM (Transmission Control Module) |
| sp00048 | Bleed Hydraulic Circuit | TCM (Transmission Control Module) |
| sp00049 | Hydraulic Circuit Depressurization | TCM (Transmission Control Module) |
| sp00050 | Learn Clutches Contact Point | TCM (Transmission Control Module) |
| sp00051 | Quick Learn | TCM (Transmission Control Module) |
| sp00052 | ABS Static Test | ABS (Anti-Lock Braking System) |
| sp00053 | Longitudinal G-Sensor Calibration Test | ABS (Anti-Lock Braking System) |
| sp00054 | Exit Shipping Mode | BCM (Body Control Module) |
| sp00055 | Self Learning Motor Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp00056 | IPC Enable Seatbelt Minder Chime | IC (Instrument Cluster) |
| sp00057 | Reset Service Information | IC (Instrument Cluster) |
| sp00058 | IPC Disable Seatbelt Minder Chime | IC (Instrument Cluster) |
| sp00059 | IPC Replacement | IC (Instrument Cluster) |
| sp00060 | RADIO Proxi Configuration | RFH (Radio Frequency Hub) |
| sp00061 | Clear Steering Pull Compensation | EPS (Electric Power Steering) |
| sp00062 | Initialize EPS | EPS (Electric Power Steering) |
| sp00063 | CTM Proxi Configuration | CTM (Convergence Telematic Module) |
| sp00064 | Clear TPM Warnings | TPMS (Tire Pressure Monitoring System) |
| sp00065 | Clear TPM Sensor Rolls Test Results | TPMS (Tire Pressure Monitoring System) |
| sp00066 | TPM FGA Proxi Configuration | TPMS (Tire Pressure Monitoring System) |
| sp00067 | Update Front And Rear Axle Nominal Tire Pressure Values | TPMS (Tire Pressure Monitoring System) |
| sp00068 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00069 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00070 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00071 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00072 | TPM Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp00073 | Air-Conditioning Self Learning | PCM (Powertrain Control Module) |
| sp00074 | Reset Accelerator Pedal Adaptives | PCM (Powertrain Control Module) |
| sp00075 | Brake Switch Learn | PCM (Powertrain Control Module) |
| sp00076 | Clutch Pedal Learn | PCM (Powertrain Control Module) |
| sp00077 | Check PCM Odometer | PCM (Powertrain Control Module) |
| sp00078 | Emissions Rolls Test Mode | PCM (Powertrain Control Module) |
| sp00079 | Air-Conditioning Self Learning | PCM (Powertrain Control Module) |
| sp00080 | Reset ECU | PCM (Powertrain Control Module) |
| sp00081 | Reset Memory | PCM (Powertrain Control Module) |
| sp00082 | Reset Memory | PCM (Powertrain Control Module) |
| sp00083 | ECU Replacement With Value Transfer | TCM (Transmission Control Module) |

| | | |
|---------|---|---|
| sp00084 | Bleed Hydraulic Circuit | TCM (Transmission Control Module) |
| sp00085 | Hydraulic Circuit Depressurization | TCM (Transmission Control Module) |
| sp00086 | Learn Clutches Contact Point | TCM (Transmission Control Module) |
| sp00087 | Quick Learn | TCM (Transmission Control Module) |
| sp00088 | ABS Static Test | ABS (Anti-Lock Braking System) |
| sp00089 | Longitudinal G-Sensor Calibration Test | ABS (Anti-Lock Braking System) |
| sp00090 | Exit Shipping Mode | BCM (Body Control Module) |
| sp00091 | Self Learning Motor Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp00092 | IPC Enable Seatbelt Minder Chime | IC (Instrument Cluster) |
| sp00093 | Reset Service Information | IC (Instrument Cluster) |
| sp00094 | IPC Disable Seatbelt Minder Chime | IC (Instrument Cluster) |
| sp00095 | IPC Replacement | IC (Instrument Cluster) |
| sp00096 | RADIO Proxi Configuration | RFH (Radio Frequency Hub) |
| sp00097 | Clear Steering Pull Compensation | EPS (Electric Power Steering) |
| sp00098 | Initialize EPS | EPS (Electric Power Steering) |
| sp00099 | CTM Proxi Configuration | CTM (Convergence Telematic Module) |
| sp00100 | Clear TPM Warnings | TPMS (Tire Pressure Monitoring System) |
| sp00101 | Clear TPM Sensor Rolls Test Results | TPMS (Tire Pressure Monitoring System) |
| sp00102 | TPM FGA Proxi Configuration | TPMS (Tire Pressure Monitoring System) |
| sp00103 | Update Front And Rear Axle Nominal Tire Pressure Values | TPMS (Tire Pressure Monitoring System) |
| sp00104 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00105 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00106 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00107 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00108 | TPM Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp00109 | Air-Conditioning Self Learning | PCM (Powertrain Control Module) |
| sp00110 | Reset Accelerator Pedal Adaptives | PCM (Powertrain Control Module) |
| sp00111 | Brake Switch Learn | PCM (Powertrain Control Module) |
| sp00112 | Clutch Pedal Learn | PCM (Powertrain Control Module) |
| sp00113 | Check PCM Odometer | PCM (Powertrain Control Module) |
| sp00114 | Emissions Rolls Test Mode | PCM (Powertrain Control Module) |
| sp00115 | Air-Conditioning Self Learning | PCM (Powertrain Control Module) |
| sp00116 | Reset ECU | PCM (Powertrain Control Module) |
| sp00117 | Reset Memory | PCM (Powertrain Control Module) |
| sp00118 | Reset Memory | PCM (Powertrain Control Module) |
| sp00119 | ECU Replacement With Value Transfer | TCM (Transmission Control Module) |
| sp00120 | Bleed Hydraulic Circuit | TCM (Transmission Control Module) |
| sp00121 | Hydraulic Circuit Depressurization | TCM (Transmission Control Module) |
| sp00122 | Learn Clutches Contact Point | TCM (Transmission Control Module) |
| sp00123 | Quick Learn | TCM (Transmission Control Module) |
| sp00124 | ABS Static Test | ABS (Anti-Lock Braking System) |
| sp00125 | Longitudinal G-Sensor Calibration Test | ABS (Anti-Lock Braking System) |
| sp00126 | Exit Shipping Mode | BCM (Body Control Module) |

| | | |
|---------|---|---|
| sp00127 | Self Learning Motor Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp00128 | IPC Enable Seatbelt Minder Chime | IC (Instrument Cluster) |
| sp00129 | Reset Service Information | IC (Instrument Cluster) |
| sp00130 | IPC Disable Seatbelt Minder Chime | IC (Instrument Cluster) |
| sp00131 | IPC Replacement | IC (Instrument Cluster) |
| sp00132 | RADIO Proxi Configuration | RFH (Radio Frequency Hub) |
| sp00133 | Clear Steering Pull Compensation | EPS (Electric Power Steering) |
| sp00134 | Initialize EPS | EPS (Electric Power Steering) |
| sp00135 | CTM Proxi Configuration | CTM (Convergence Telematic Module) |
| sp00136 | Clear TPM Warnings | TPMS (Tire Pressure Monitoring System) |
| sp00137 | Clear TPM Sensor Rolls Test Results | TPMS (Tire Pressure Monitoring System) |
| sp00138 | TPM FGA Proxi Configuration | TPMS (Tire Pressure Monitoring System) |
| sp00139 | Update Front And Rear Axle Nominal Tire Pressure Values | TPMS (Tire Pressure Monitoring System) |
| sp00140 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00141 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00142 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00143 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00144 | TPM Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp00145 | Reset Accelerator Pedal Adaptives | PCM (Powertrain Control Module) |
| sp00146 | Brake Switch Learn | PCM (Powertrain Control Module) |
| sp00147 | Clutch Pedal Learn | PCM (Powertrain Control Module) |
| sp00148 | Air-Conditioning Self Learning | PCM (Powertrain Control Module) |
| sp00149 | Throttle Body Self Learning | PCM (Powertrain Control Module) |
| sp00150 | Reset ECU | PCM (Powertrain Control Module) |
| sp00151 | Reset Learn Flag Wheel Tooth | PCM (Powertrain Control Module) |
| sp00152 | Differential Pressure Sensor Replac. | PCM (Powertrain Control Module) |
| sp00153 | ECU Replacement With Value Transfer | TCM (Transmission Control Module) |
| sp00154 | Bleed Hydraulic Circuit | TCM (Transmission Control Module) |
| sp00155 | Hydraulic Circuit Depressurization | TCM (Transmission Control Module) |
| sp00156 | Learn Clutches Contact Point | TCM (Transmission Control Module) |
| sp00157 | Quick Learn | TCM (Transmission Control Module) |
| sp00158 | ABS Static Test | ABS (Anti-Lock Braking System) |
| sp00159 | Longitudinal G-Sensor Calibration Test | ABS (Anti-Lock Braking System) |
| sp00160 | Clear TPM Warnings | TPMS (Tire Pressure Monitoring System) |
| sp00161 | Clear TPM Sensor Rolls Test Results | TPMS (Tire Pressure Monitoring System) |
| sp00162 | TPM FGA Proxi Configuration | TPMS (Tire Pressure Monitoring System) |
| sp00163 | Update Front And Rear Axle Nominal Tire Pressure Values | TPMS (Tire Pressure Monitoring System) |
| sp00164 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00165 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00166 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00167 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00168 | TPM Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp00169 | RADIO Proxi Configuration | RADIO (RADIO) |

| | | |
|---------|---|---|
| sp00170 | IPC Enable Seatbelt Minder Chime | IC (Instrument Cluster) |
| sp00171 | Reset Service Information | IC (Instrument Cluster) |
| sp00172 | IPC Disable Seatbelt Minder Chime | IC (Instrument Cluster) |
| sp00173 | IPC Replacement | IC (Instrument Cluster) |
| sp00174 | Self Learning Motor Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp00175 | Clear Steering Pull Compensation | EPS (Electric Power Steering) |
| sp00176 | Initialize EPS | EPS (Electric Power Steering) |
| sp00177 | CTM Proxi Configuration | CTM (Convergence Telematic Module) |
| sp00178 | Exit Shipping Mode | BCM (Body Control Module) |
| sp00179 | ECU Replacement With Value Transfer | TCM (Transmission Control Module) |
| sp00180 | Bleed Hydraulic Circuit | TCM (Transmission Control Module) |
| sp00181 | Hydraulic Circuit Depressurization | TCM (Transmission Control Module) |
| sp00182 | Learn Clutches Contact Point | TCM (Transmission Control Module) |
| sp00183 | Quick Learn | TCM (Transmission Control Module) |
| sp00184 | ABS Static Test | ABS (Anti-Lock Braking System) |
| sp00185 | Longitudinal G-Sensor Calibration Test | ABS (Anti-Lock Braking System) |
| sp00186 | Clear TPM Warnings | TPMS (Tire Pressure Monitoring System) |
| sp00187 | Clear TPM Sensor Rolls Test Results | TPMS (Tire Pressure Monitoring System) |
| sp00188 | TPM FGA Proxi Configuration | TPMS (Tire Pressure Monitoring System) |
| sp00189 | Update Front And Rear Axle Nominal Tire Pressure Values | TPMS (Tire Pressure Monitoring System) |
| sp00190 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00191 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00192 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00193 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00194 | TPM Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp00195 | RADIO Proxi Configuration | RADIO (RADIO) |
| sp00196 | IPC Enable Seatbelt Minder Chime | IC (Instrument Cluster) |
| sp00197 | Reset Service Information | IC (Instrument Cluster) |
| sp00198 | IPC Disable Seatbelt Minder Chime | IC (Instrument Cluster) |
| sp00199 | IPC Replacement | IC (Instrument Cluster) |
| sp00200 | Self Learning Motor Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp00201 | Clear Steering Pull Compensation | EPS (Electric Power Steering) |
| sp00202 | Initialize EPS | EPS (Electric Power Steering) |
| sp00203 | CTM Proxi Configuration | CTM (Convergence Telematic Module) |
| sp00204 | Exit Shipping Mode | BCM (Body Control Module) |
| sp00205 | Reset Accelerator Pedal Adaptives | PCM (Powertrain Control Module) |
| sp00206 | Brake Switch Learn | PCM (Powertrain Control Module) |
| sp00207 | Clutch Pedal Learn | PCM (Powertrain Control Module) |
| sp00208 | Check PCM Odometer | PCM (Powertrain Control Module) |
| sp00209 | Emissions Rolls Test Mode | PCM (Powertrain Control Module) |
| sp00210 | Clear Misfire TLC | PCM (Powertrain Control Module) |
| sp00211 | Air-Conditioning Self Learning | PCM (Powertrain Control Module) |
| sp00212 | Throttle Body Self Learning | PCM (Powertrain Control Module) |

| | | |
|---------|---|---|
| sp00213 | Reset ECU | PCM (Powertrain Control Module) |
| sp00214 | Reset Memory | PCM (Powertrain Control Module) |
| sp00215 | ECU Replacement With Value Transfer | TCM (Transmission Control Module) |
| sp00216 | Bleed Hydraulic Circuit | TCM (Transmission Control Module) |
| sp00217 | Hydraulic Circuit Depressurization | TCM (Transmission Control Module) |
| sp00218 | Learn Clutches Contact Point | TCM (Transmission Control Module) |
| sp00219 | Quick Learn | TCM (Transmission Control Module) |
| sp00220 | ABS Static Test | ABS (Anti-Lock Braking System) |
| sp00221 | Longitudinal G-Sensor Calibration Test | ABS (Anti-Lock Braking System) |
| sp00222 | Clear TPM Warnings | TPMS (Tire Pressure Monitoring System) |
| sp00223 | Clear TPM Sensor Rolls Test Results | TPMS (Tire Pressure Monitoring System) |
| sp00224 | TPM FGA Proxi Configuration | TPMS (Tire Pressure Monitoring System) |
| sp00225 | Update Front And Rear Axle Nominal Tire Pressure Values | TPMS (Tire Pressure Monitoring System) |
| sp00226 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00227 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00228 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00229 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00230 | TPM Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp00231 | RADIO Proxi Configuration | RADIO (RADIO) |
| sp00232 | IPC Enable Seatbelt Minder Chime | IC (Instrument Cluster) |
| sp00233 | Reset Service Information | IC (Instrument Cluster) |
| sp00234 | IPC Disable Seatbelt Minder Chime | IC (Instrument Cluster) |
| sp00235 | IPC Replacement | IC (Instrument Cluster) |
| sp00236 | Self Learning Motor Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp00237 | Clear Steering Pull Compensation | EPS (Electric Power Steering) |
| sp00238 | Initialize EPS | EPS (Electric Power Steering) |
| sp00239 | CTM Proxi Configuration | CTM (Convergence Telematic Module) |
| sp00240 | Exit Shipping Mode | BCM (Body Control Module) |
| sp00241 | Reset Accelerator Pedal Adaptives | PCM (Powertrain Control Module) |
| sp00242 | Brake Switch Learn | PCM (Powertrain Control Module) |
| sp00243 | Clutch Pedal Learn | PCM (Powertrain Control Module) |
| sp00244 | Check PCM Odometer | PCM (Powertrain Control Module) |
| sp00245 | Emissions Rolls Test Mode | PCM (Powertrain Control Module) |
| sp00246 | Clear Misfire TLC | PCM (Powertrain Control Module) |
| sp00247 | Air-Conditioning Self Learning | PCM (Powertrain Control Module) |
| sp00248 | Throttle Body Self Learning | PCM (Powertrain Control Module) |
| sp00249 | Reset ECU | PCM (Powertrain Control Module) |
| sp00250 | Reset Memory | PCM (Powertrain Control Module) |
| sp00251 | ECU Replacement With Value Transfer | TCM (Transmission Control Module) |
| sp00252 | Bleed Hydraulic Circuit | TCM (Transmission Control Module) |
| sp00253 | Hydraulic Circuit Depressurization | TCM (Transmission Control Module) |
| sp00254 | Learn Clutches Contact Point | TCM (Transmission Control Module) |
| sp00255 | Quick Learn | TCM (Transmission Control Module) |

| | | |
|---------|---|---|
| sp00256 | ABS Static Test | ABS (Anti-Lock Braking System) |
| sp00257 | Longitudinal G-Sensor Calibration Test | ABS (Anti-Lock Braking System) |
| sp00258 | Clear TPM Warnings | TPMS (Tire Pressure Monitoring System) |
| sp00259 | Clear TPM Sensor Rolls Test Results | TPMS (Tire Pressure Monitoring System) |
| sp00260 | TPM FGA Proxi Configuration | TPMS (Tire Pressure Monitoring System) |
| sp00261 | Update Front And Rear Axle Nominal Tire Pressure Values | TPMS (Tire Pressure Monitoring System) |
| sp00262 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00263 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00264 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00265 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00266 | TPM Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp00267 | RADIO Proxi Configuration | RADIO (RADIO) |
| sp00268 | IPC Enable Seatbelt Minder Chime | IC (Instrument Cluster) |
| sp00269 | Reset Service Information | IC (Instrument Cluster) |
| sp00270 | IPC Disable Seatbelt Minder Chime | IC (Instrument Cluster) |
| sp00271 | IPC Replacement | IC (Instrument Cluster) |
| sp00272 | Self Learning Motor Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp00273 | Clear Steering Pull Compensation | EPS (Electric Power Steering) |
| sp00274 | Initialize EPS | EPS (Electric Power Steering) |
| sp00275 | CTM Proxi Configuration | CTM (Convergence Telematic Module) |
| sp00276 | Exit Shipping Mode | BCM (Body Control Module) |
| sp00277 | Exit Shipping Mode | BCM (Body Control Module) |
| sp00278 | IPC Enable Seatbelt Minder Chime | IC (Instrument Cluster) |
| sp00279 | Reset Service Information | IC (Instrument Cluster) |
| sp00280 | IPC Disable Seatbelt Minder Chime | IC (Instrument Cluster) |
| sp00281 | IPC Replacement | IC (Instrument Cluster) |
| sp00282 | Self Learning Motor Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp00283 | ABS Static Test | ABS (Anti-Lock Braking System) |
| sp00284 | Longitudinal G-Sensor Calibration Test | ABS (Anti-Lock Braking System) |
| sp00285 | Clear TPM Warnings | TPMS (Tire Pressure Monitoring System) |
| sp00286 | Clear TPM Sensor Rolls Test Results | TPMS (Tire Pressure Monitoring System) |
| sp00287 | TPM FGA Proxi Configuration | TPMS (Tire Pressure Monitoring System) |
| sp00288 | Update Front And Rear Axle Nominal Tire Pressure Values | TPMS (Tire Pressure Monitoring System) |
| sp00289 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00290 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00291 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00292 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00293 | TPM Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp00294 | CTM Proxi Configuration | CTM (Convergence Telematic Module) |
| sp00295 | Clear Steering Pull Compensation | EPS (Electric Power Steering) |
| sp00296 | Initialize EPS | EPS (Electric Power Steering) |
| sp00297 | RADIO Proxi Configuration | RFH (Radio Frequency Hub) |
| sp00298 | Exit Shipping Mode | BCM (Body Control Module) |

| | | |
|---------|---|---|
| sp00299 | IPC Enable Seatbelt Minder Chime | IC (Instrument Cluster) |
| sp00300 | Reset Service Information | IC (Instrument Cluster) |
| sp00301 | IPC Disable Seatbelt Minder Chime | IC (Instrument Cluster) |
| sp00302 | IPC Replacement | IC (Instrument Cluster) |
| sp00303 | Self Learning Motor Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp00304 | ABS Static Test | ABS (Anti-Lock Braking System) |
| sp00305 | Longitudinal G-Sensor Calibration Test | ABS (Anti-Lock Braking System) |
| sp00306 | Clear TPM Warnings | TPMS (Tire Pressure Monitoring System) |
| sp00307 | Clear TPM Sensor Rolls Test Results | TPMS (Tire Pressure Monitoring System) |
| sp00308 | TPM FGA Proxi Configuration | TPMS (Tire Pressure Monitoring System) |
| sp00309 | Update Front And Rear Axle Nominal Tire Pressure Values | TPMS (Tire Pressure Monitoring System) |
| sp00310 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00311 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00312 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00313 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00314 | TPM Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp00315 | CTM Proxi Configuration | CTM (Convergence Telematic Module) |
| sp00316 | Clear Steering Pull Compensation | EPS (Electric Power Steering) |
| sp00317 | Initialize EPS | EPS (Electric Power Steering) |
| sp00318 | RADIO Proxi Configuration | RFH (Radio Frequency Hub) |
| sp00319 | Intake Manifold Replacement | ECM (Engine Control Module) |
| sp00320 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp00321 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp00322 | Intelligent Alternator (IAM) Replacement | ECM (Engine Control Module) |
| sp00323 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp00324 | Fuel Supply System Components Replacement | ECM (Engine Control Module) |
| sp00325 | Motorized Throttle Replacement | ECM (Engine Control Module) |
| sp00326 | Factory VIN code lock | ECM (Engine Control Module) |
| sp00327 | Control Unit Reprogramming | ECM (Engine Control Module) |
| sp00328 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00329 | Proxi Alignment Procedure | ECM (Engine Control Module) |
| sp00330 | Injector/S Replacement | ECM (Engine Control Module) |
| sp00331 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00332 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp00333 | Motorized Throttle Self Learning Command | ECM (Engine Control Module) |
| sp00334 | Proxi Alignment Procedure | TCM (Transmission Control Module) |
| sp00335 | ECU Substitution | ABS (Anti-Lock Braking System) |
| sp00336 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00337 | Pressure Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00338 | TPMS Reset Calibration | ABS (Anti-Lock Braking System) |
| sp00339 | Fire Protection System Activate | BCM (Body Control Module) |
| sp00340 | LIN Line Request Check | BCM (Body Control Module) |
| sp00341 | Ultrasonic Sensors Check | BCM (Body Control Module) |

| | | |
|---------|--|---|
| sp00342 | Reset Odometer | IC (Instrument Cluster) |
| sp00343 | Reset Service Information | IC (Instrument Cluster) |
| sp00344 | Last Service Date | IC (Instrument Cluster) |
| sp00345 | Factory VIN code lock | CSWM (Comfort Seat Wheel Module) |
| sp00346 | Factory VIN code lock | DTCM (Drive Train Control Module) |
| sp00347 | Proxi Alignment Procedure | DTCM (Drive Train Control Module) |
| sp00348 | Proxi Alignment Procedure | ESM (Electronic Shifter Module) |
| sp00349 | Factory VIN code lock | ESM (Electronic Shifter Module) |
| sp00350 | Power Down | RRM (Radio Receiver Module) |
| sp00351 | Power On And Disable User Inputs | RRM (Radio Receiver Module) |
| sp00352 | Reset Parameters To Default | RRM (Radio Receiver Module) |
| sp00353 | Self Learning Motors Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp00354 | Clear TPM Sensor Audit | RFH (Radio Frequency Hub) |
| sp00355 | Clear TPM Sensor Warnings | RFH (Radio Frequency Hub) |
| sp00356 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp00357 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp00358 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp00359 | Service Single Pole Calibration | HALF (Haptical Lane Feedback) |
| sp00360 | Intake Manifold Replacement | ECM (Engine Control Module) |
| sp00361 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp00362 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp00363 | Intelligent Alternator (IAM) Replacement | ECM (Engine Control Module) |
| sp00364 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp00365 | Fuel Supply System Components Replacement | ECM (Engine Control Module) |
| sp00366 | Motorized Throttle Replacement | ECM (Engine Control Module) |
| sp00367 | Factory VIN code lock | ECM (Engine Control Module) |
| sp00368 | Control Unit Reprogramming | ECM (Engine Control Module) |
| sp00369 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00370 | Proxi Alignment Procedure | ECM (Engine Control Module) |
| sp00371 | Injector/S Replacement | ECM (Engine Control Module) |
| sp00372 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00373 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp00374 | Motorized Throttle Self Learning Command | ECM (Engine Control Module) |
| sp00375 | Proxi Alignment Procedure | TCM (Transmission Control Module) |
| sp00376 | ECU Substitution | ABS (Anti-Lock Braking System) |
| sp00377 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00378 | Pressure Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00379 | TPMS Reset Calibration | ABS (Anti-Lock Braking System) |
| sp00380 | Fire Protection System Activate | BCM (Body Control Module) |
| sp00381 | LIN Line Request Check | BCM (Body Control Module) |
| sp00382 | Ultrasonic Sensors Check | BCM (Body Control Module) |
| sp00383 | Reset Odometer | IC (Instrument Cluster) |
| sp00384 | Reset Service Information | IC (Instrument Cluster) |

| | | |
|---------|--|---|
| sp00385 | Last Service Date | IC (Instrument Cluster) |
| sp00386 | Factory VIN code lock | CSWM (Comfort Seat Wheel Module) |
| sp00387 | Factory VIN code lock | DTCM (Drive Train Control Module) |
| sp00388 | Proxi Alignment Procedure | DTCM (Drive Train Control Module) |
| sp00389 | Proxi Alignment Procedure | ESM (Electronic Shifter Module) |
| sp00390 | Factory VIN code lock | ESM (Electronic Shifter Module) |
| sp00391 | Power Down | RRM (Radio Receiver Module) |
| sp00392 | Power On And Disable User Inputs | RRM (Radio Receiver Module) |
| sp00393 | Reset Parameters To Default | RRM (Radio Receiver Module) |
| sp00394 | Self Learning Motors Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp00395 | Clear TPM Sensor Audit | RFH (Radio Frequency Hub) |
| sp00396 | Clear TPM Sensor Warnings | RFH (Radio Frequency Hub) |
| sp00397 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp00398 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp00399 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp00400 | Service Single Pole Calibration | HALF (Haptical Lane Feedback) |
| sp00401 | Intake Manifold Replacement | ECM (Engine Control Module) |
| sp00402 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp00403 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp00404 | Intelligent Alternator (IAM) Replacement | ECM (Engine Control Module) |
| sp00405 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp00406 | Fuel Supply System Components Replacement | ECM (Engine Control Module) |
| sp00407 | Motorized Throttle Replacement | ECM (Engine Control Module) |
| sp00408 | Factory VIN code lock | ECM (Engine Control Module) |
| sp00409 | Control Unit Reprogramming | ECM (Engine Control Module) |
| sp00410 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00411 | Proxi Alignment Procedure | ECM (Engine Control Module) |
| sp00412 | Injector/S Replacement | ECM (Engine Control Module) |
| sp00413 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00414 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp00415 | Motorized Throttle Self Learning Command | ECM (Engine Control Module) |
| sp00416 | Proxi Alignment Procedure | TCM (Transmission Control Module) |
| sp00417 | ECU Substitution | ABS (Anti-Lock Braking System) |
| sp00418 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00419 | Pressure Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00420 | TPMS Reset Calibration | ABS (Anti-Lock Braking System) |
| sp00421 | Fire Protection System Activate | BCM (Body Control Module) |
| sp00422 | LIN Line Request Check | BCM (Body Control Module) |
| sp00423 | Ultrasonic Sensors Check | BCM (Body Control Module) |
| sp00424 | Reset Odometer | IC (Instrument Cluster) |
| sp00425 | Reset Service Information | IC (Instrument Cluster) |
| sp00426 | Last Service Date | IC (Instrument Cluster) |
| sp00427 | Factory VIN code lock | CSWM (Comfort Seat Wheel Module) |

| | | |
|---------|--|---|
| sp00428 | Factory VIN code lock | DTCM (Drive Train Control Module) |
| sp00429 | Proxi Alignment Procedure | DTCM (Drive Train Control Module) |
| sp00430 | Proxi Alignment Procedure | ESM (Electronic Shifter Module) |
| sp00431 | Factory VIN code lock | ESM (Electronic Shifter Module) |
| sp00432 | Power Down | RRM (Radio Receiver Module) |
| sp00433 | Power On And Disable User Inputs | RRM (Radio Receiver Module) |
| sp00434 | Reset Parameters To Default | RRM (Radio Receiver Module) |
| sp00435 | Self Learning Motors Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp00436 | Clear TPM Sensor Audit | RFH (Radio Frequency Hub) |
| sp00437 | Clear TPM Sensor Warnings | RFH (Radio Frequency Hub) |
| sp00438 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp00439 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp00440 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp00441 | Service Single Pole Calibration | HALF (Haptical Lane Feedback) |
| sp00442 | Intake Manifold Replacement | ECM (Engine Control Module) |
| sp00443 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp00444 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp00445 | Intelligent Alternator (IAM) Replacement | ECM (Engine Control Module) |
| sp00446 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp00447 | Fuel Supply System Components Replacement | ECM (Engine Control Module) |
| sp00448 | Motorized Throttle Replacement | ECM (Engine Control Module) |
| sp00449 | Factory VIN code lock | ECM (Engine Control Module) |
| sp00450 | Control Unit Reprogramming | ECM (Engine Control Module) |
| sp00451 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00452 | Proxi Alignment Procedure | ECM (Engine Control Module) |
| sp00453 | Injector/S Replacement | ECM (Engine Control Module) |
| sp00454 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00455 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp00456 | Motorized Throttle Self Learning Command | ECM (Engine Control Module) |
| sp00457 | Proxi Alignment Procedure | TCM (Transmission Control Module) |
| sp00458 | ECU Substitution | ABS (Anti-Lock Braking System) |
| sp00459 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00460 | Pressure Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00461 | TPMS Reset Calibration | ABS (Anti-Lock Braking System) |
| sp00462 | Fire Protection System Activate | BCM (Body Control Module) |
| sp00463 | LIN Line Request Check | BCM (Body Control Module) |
| sp00464 | Ultrasonic Sensors Check | BCM (Body Control Module) |
| sp00465 | Reset Odometer | IC (Instrument Cluster) |
| sp00466 | Reset Service Information | IC (Instrument Cluster) |
| sp00467 | Last Service Date | IC (Instrument Cluster) |
| sp00468 | Factory VIN code lock | CSWM (Comfort Seat Wheel Module) |
| sp00469 | Factory VIN code lock | DTCM (Drive Train Control Module) |
| sp00470 | Proxi Alignment Procedure | DTCM (Drive Train Control Module) |

| | | |
|---------|---|---|
| sp00471 | Proxi Alignment Procedure | ESM (Electronic Shifter Module) |
| sp00472 | Factory VIN code lock | ESM (Electronic Shifter Module) |
| sp00473 | Power Down | RRM (Radio Receiver Module) |
| sp00474 | Power On And Disable User Inputs | RRM (Radio Receiver Module) |
| sp00475 | Reset Parameters To Default | RRM (Radio Receiver Module) |
| sp00476 | Self Learning Motors Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp00477 | Clear TPM Sensor Audit | RFH (Radio Frequency Hub) |
| sp00478 | Clear TPM Sensor Warnings | RFH (Radio Frequency Hub) |
| sp00479 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp00480 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp00481 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp00482 | Service Single Pole Calibration | HALF (Haptical Lane Feedback) |
| sp00483 | Deactivation Of The Power Limitation Function | ECM (Engine Control Module) |
| sp00484 | Motorised Throttle Replacement | ECM (Engine Control Module) |
| sp00485 | Supercharging System Components Replacement | ECM (Engine Control Module) |
| sp00486 | Intake Manifold Replacement | ECM (Engine Control Module) |
| sp00487 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp00488 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp00489 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp00490 | Intelligent Alternator (IAM) Replacement | ECM (Engine Control Module) |
| sp00491 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp00492 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00493 | Reset Gear Configuration | ABS (Anti-Lock Braking System) |
| sp00494 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00495 | Pressure Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00496 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp00497 | Reset Odometer | IC (Instrument Cluster) |
| sp00498 | Reset Service Information | IC (Instrument Cluster) |
| sp00499 | Disable Seat Belts Reminder | IC (Instrument Cluster) |
| sp00500 | Enable Seat Belts Reminder | IC (Instrument Cluster) |
| sp00501 | Last Service Date | IC (Instrument Cluster) |
| sp00502 | Power Down | ETM (Entertainment Telematic Module) |
| sp00503 | Power On And Disable User Inputs | ETM (Entertainment Telematic Module) |
| sp00504 | Audio Video Signal Detection | ETM (Entertainment Telematic Module) |
| sp00505 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp00506 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp00507 | Clear TPM Warnings | TPMS (Tire Pressure Monitoring System) |
| sp00508 | Clear TPM Sensor Rolls Test Results | TPMS (Tire Pressure Monitoring System) |
| sp00509 | TPM FGA Proxi Configuration | TPMS (Tire Pressure Monitoring System) |
| sp00510 | Update Front And Rear Axle Nominal Tire Pressure Values | TPMS (Tire Pressure Monitoring System) |
| sp00511 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00512 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00513 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |

| | | |
|---------|---|--|
| sp00514 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00515 | TPM Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp00516 | Deactivation Of The Power Limitation Function | ECM (Engine Control Module) |
| sp00517 | Motorised Throttle Replacement | ECM (Engine Control Module) |
| sp00518 | Supercharging System Components Replacement | ECM (Engine Control Module) |
| sp00519 | Intake Manifold Replacement | ECM (Engine Control Module) |
| sp00520 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp00521 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp00522 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp00523 | Intelligent Alternator (IAM) Replacement | ECM (Engine Control Module) |
| sp00524 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp00525 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00526 | Reset Gear Configuration | ABS (Anti-Lock Braking System) |
| sp00527 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00528 | Pressure Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00529 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp00530 | Reset Odometer | IC (Instrument Cluster) |
| sp00531 | Reset Service Information | IC (Instrument Cluster) |
| sp00532 | Disable Seat Belts Reminder | IC (Instrument Cluster) |
| sp00533 | Enable Seat Belts Reminder | IC (Instrument Cluster) |
| sp00534 | Last Service Date | IC (Instrument Cluster) |
| sp00535 | Power Down | ETM (Entertainment Telematic Module) |
| sp00536 | Power On And Disable User Inputs | ETM (Entertainment Telematic Module) |
| sp00537 | Audio Video Signal Detection | ETM (Entertainment Telematic Module) |
| sp00538 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp00539 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp00540 | Clear TPM Warnings | TPMS (Tire Pressure Monitoring System) |
| sp00541 | Clear TPM Sensor Rolls Test Results | TPMS (Tire Pressure Monitoring System) |
| sp00542 | TPM FGA Proxi Configuration | TPMS (Tire Pressure Monitoring System) |
| sp00543 | Update Front And Rear Axle Nominal Tire Pressure Values | TPMS (Tire Pressure Monitoring System) |
| sp00544 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00545 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00546 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00547 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00548 | TPM Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp00549 | Air-Conditioning Self Learning | ECM (Engine Control Module) |
| sp00550 | Brake Switch Learn | ECM (Engine Control Module) |
| sp00551 | Check PCM Odometer | ECM (Engine Control Module) |
| sp00552 | Clear Misfire TLC | ECM (Engine Control Module) |
| sp00553 | Reset Accelerator Pedal Adaptives | ECM (Engine Control Module) |
| sp00554 | Reset Memory | ECM (Engine Control Module) |
| sp00555 | Throttle Body Self Learning | ECM (Engine Control Module) |
| sp00556 | Reset Gear Configuration | ABS (Anti-Lock Braking System) |

| | | |
|---------|---|--|
| sp00557 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00558 | Pressure Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00559 | Clear TPM Warnings | TPMS (Tire Pressure Monitoring System) |
| sp00560 | Clear TPM Sensor Rolls Test Results | TPMS (Tire Pressure Monitoring System) |
| sp00561 | TPM FGA Proxi Configuration | TPMS (Tire Pressure Monitoring System) |
| sp00562 | Update Front And Rear Axle Nominal Tire Pressure Values | TPMS (Tire Pressure Monitoring System) |
| sp00563 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00564 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00565 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00566 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00567 | TPM Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp00568 | Trailer Hook Presence Disabling | PAM (Parking Assistant Module) |
| sp00569 | Trailer Hook Presence Enabling | PAM (Parking Assistant Module) |
| sp00570 | Reset Odometer | IC (Instrument Cluster) |
| sp00571 | Reset Service Information | IC (Instrument Cluster) |
| sp00572 | Disable Seat Belts Reminder | IC (Instrument Cluster) |
| sp00573 | Enable Seat Belts Reminder | IC (Instrument Cluster) |
| sp00574 | Last Service Date | IC (Instrument Cluster) |
| sp00575 | Power Down | ETM (Entertainment Telematic Module) |
| sp00576 | Power On And Disable User Inputs | ETM (Entertainment Telematic Module) |
| sp00577 | Audio Video Signal Detection | ETM (Entertainment Telematic Module) |
| sp00578 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp00579 | Deactivation Of The Power Limitation Function | ECM (Engine Control Module) |
| sp00580 | Motorised Throttle Replacement | ECM (Engine Control Module) |
| sp00581 | Supercharging System Components Replacement | ECM (Engine Control Module) |
| sp00582 | Intake Manifold Replacement | ECM (Engine Control Module) |
| sp00583 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp00584 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp00585 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp00586 | Intelligent Alternator (IAM) Replacement | ECM (Engine Control Module) |
| sp00587 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp00588 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00589 | Reset Gear Configuration | ABS (Anti-Lock Braking System) |
| sp00590 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00591 | Pressure Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00592 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp00593 | Reset Odometer | IC (Instrument Cluster) |
| sp00594 | Reset Service Information | IC (Instrument Cluster) |
| sp00595 | Disable Seat Belts Reminder | IC (Instrument Cluster) |
| sp00596 | Enable Seat Belts Reminder | IC (Instrument Cluster) |
| sp00597 | Last Service Date | IC (Instrument Cluster) |
| sp00598 | Power Down | ETM (Entertainment Telematic Module) |
| sp00599 | Power On And Disable User Inputs | ETM (Entertainment Telematic Module) |

| | | |
|---------|---|--|
| sp00600 | Audio Video Signal Detection | ETM (Entertainment Telematic Module) |
| sp00601 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp00602 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp00603 | Clear TPM Warnings | TPMS (Tire Pressure Monitoring System) |
| sp00604 | Clear TPM Sensor Rolls Test Results | TPMS (Tire Pressure Monitoring System) |
| sp00605 | TPM FGA Proxi Configuration | TPMS (Tire Pressure Monitoring System) |
| sp00606 | Update Front And Rear Axle Nominal Tire Pressure Values | TPMS (Tire Pressure Monitoring System) |
| sp00607 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00608 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00609 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00610 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00611 | TPM Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp00612 | Deactivation Of The Power Limitation Function | ECM (Engine Control Module) |
| sp00613 | Motorised Throttle Replacement | ECM (Engine Control Module) |
| sp00614 | Supercharging System Components Replacement | ECM (Engine Control Module) |
| sp00615 | Intake Manifold Replacement | ECM (Engine Control Module) |
| sp00616 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp00617 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp00618 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp00619 | Intelligent Alternator (IAM) Replacement | ECM (Engine Control Module) |
| sp00620 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp00621 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00622 | Reset Gear Configuration | ABS (Anti-Lock Braking System) |
| sp00623 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00624 | Pressure Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00625 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp00626 | Reset Odometer | IC (Instrument Cluster) |
| sp00627 | Reset Service Information | IC (Instrument Cluster) |
| sp00628 | Disable Seat Belts Reminder | IC (Instrument Cluster) |
| sp00629 | Enable Seat Belts Reminder | IC (Instrument Cluster) |
| sp00630 | Last Service Date | IC (Instrument Cluster) |
| sp00631 | Power Down | ETM (Entertainment Telematic Module) |
| sp00632 | Power On And Disable User Inputs | ETM (Entertainment Telematic Module) |
| sp00633 | Audio Video Signal Detection | ETM (Entertainment Telematic Module) |
| sp00634 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp00635 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp00636 | Clear TPM Warnings | TPMS (Tire Pressure Monitoring System) |
| sp00637 | Clear TPM Sensor Rolls Test Results | TPMS (Tire Pressure Monitoring System) |
| sp00638 | TPM FGA Proxi Configuration | TPMS (Tire Pressure Monitoring System) |
| sp00639 | Update Front And Rear Axle Nominal Tire Pressure Values | TPMS (Tire Pressure Monitoring System) |
| sp00640 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00641 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00642 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |

| | | |
|---------|---|--|
| sp00643 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00644 | TPM Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp00645 | Air-Conditioning Self Learning | ECM (Engine Control Module) |
| sp00646 | Brake Switch Learn | ECM (Engine Control Module) |
| sp00647 | Check PCM Odometer | ECM (Engine Control Module) |
| sp00648 | Clear Misfire TLC | ECM (Engine Control Module) |
| sp00649 | Reset Accelerator Pedal Adaptives | ECM (Engine Control Module) |
| sp00650 | Reset Memory | ECM (Engine Control Module) |
| sp00651 | Throttle Body Self Learning | ECM (Engine Control Module) |
| sp00652 | Reset Gear Configuration | ABS (Anti-Lock Braking System) |
| sp00653 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00654 | Pressure Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00655 | Clear TPM Warnings | TPMS (Tire Pressure Monitoring System) |
| sp00656 | Clear TPM Sensor Rolls Test Results | TPMS (Tire Pressure Monitoring System) |
| sp00657 | TPM FGA Proxi Configuration | TPMS (Tire Pressure Monitoring System) |
| sp00658 | Update Front And Rear Axle Nominal Tire Pressure Values | TPMS (Tire Pressure Monitoring System) |
| sp00659 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00660 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00661 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00662 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00663 | TPM Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp00664 | Trailer Hook Presence Disabling | PAM (Parking Assistant Module) |
| sp00665 | Trailer Hook Presence Enabling | PAM (Parking Assistant Module) |
| sp00666 | Reset Odometer | IC (Instrument Cluster) |
| sp00667 | Reset Service Information | IC (Instrument Cluster) |
| sp00668 | Disable Seat Belts Reminder | IC (Instrument Cluster) |
| sp00669 | Enable Seat Belts Reminder | IC (Instrument Cluster) |
| sp00670 | Last Service Date | IC (Instrument Cluster) |
| sp00671 | Power Down | ETM (Entertainment Telematic Module) |
| sp00672 | Power On And Disable User Inputs | ETM (Entertainment Telematic Module) |
| sp00673 | Audio Video Signal Detection | ETM (Entertainment Telematic Module) |
| sp00674 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp00675 | Reset Gear Configuration | ABS (Anti-Lock Braking System) |
| sp00676 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00677 | Pressure Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00678 | Clear TPM Warnings | TPMS (Tire Pressure Monitoring System) |
| sp00679 | Clear TPM Sensor Rolls Test Results | TPMS (Tire Pressure Monitoring System) |
| sp00680 | TPM FGA Proxi Configuration | TPMS (Tire Pressure Monitoring System) |
| sp00681 | Update Front And Rear Axle Nominal Tire Pressure Values | TPMS (Tire Pressure Monitoring System) |
| sp00682 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00683 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00684 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00685 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |

| | | |
|---------|---|--|
| sp00686 | TPM Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp00687 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp00688 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp00689 | Reset Odometer | IC (Instrument Cluster) |
| sp00690 | Reset Service Information | IC (Instrument Cluster) |
| sp00691 | Disable Seat Belts Reminder | IC (Instrument Cluster) |
| sp00692 | Enable Seat Belts Reminder | IC (Instrument Cluster) |
| sp00693 | Last Service Date | IC (Instrument Cluster) |
| sp00694 | Power Down | ETM (Entertainment Telematic Module) |
| sp00695 | Power On And Disable User Inputs | ETM (Entertainment Telematic Module) |
| sp00696 | Audio Video Signal Detection | ETM (Entertainment Telematic Module) |
| sp00697 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp00698 | Deactivation Of The Power Limitation Function | ECM (Engine Control Module) |
| sp00699 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp00700 | Motorised Throttle Replacement | ECM (Engine Control Module) |
| sp00701 | Supercharging System Components Replacement | ECM (Engine Control Module) |
| sp00702 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp00703 | Intake Manifold Replacement | ECM (Engine Control Module) |
| sp00704 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp00705 | Clutch Pedal Learning | ECM (Engine Control Module) |
| sp00706 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp00707 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp00708 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00709 | Tunnel Lever Replacement | TCM (Transmission Control Module) |
| sp00710 | Levers At Wheel Replacement | TCM (Transmission Control Module) |
| sp00711 | Pump Relay Replacement | TCM (Transmission Control Module) |
| sp00712 | Self-Learnt Functions Reset | TCM (Transmission Control Module) |
| sp00713 | Reset Gear Configuration | ABS (Anti-Lock Braking System) |
| sp00714 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00715 | Pressure Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00716 | Clear TPM Warnings | TPMS (Tire Pressure Monitoring System) |
| sp00717 | Clear TPM Sensor Rolls Test Results | TPMS (Tire Pressure Monitoring System) |
| sp00718 | TPM FGA Proxi Configuration | TPMS (Tire Pressure Monitoring System) |
| sp00719 | Update Front And Rear Axle Nominal Tire Pressure Values | TPMS (Tire Pressure Monitoring System) |
| sp00720 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00721 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00722 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00723 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp00724 | TPM Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp00725 | Trailer Hook Presence Disabling | PAM (Parking Assistant Module) |
| sp00726 | Trailer Hook Presence Enabling | PAM (Parking Assistant Module) |
| sp00727 | Reset Odometer | IC (Instrument Cluster) |
| sp00728 | Reset Service Information | IC (Instrument Cluster) |

| | | |
|---------|--|---|
| sp00729 | Disable Seat Belts Reminder | IC (Instrument Cluster) |
| sp00730 | Enable Seat Belts Reminder | IC (Instrument Cluster) |
| sp00731 | Last Service Date | IC (Instrument Cluster) |
| sp00732 | Power Down | ETM (Entertainment Telematic Module) |
| sp00733 | Power On And Disable User Inputs | ETM (Entertainment Telematic Module) |
| sp00734 | Audio Video Signal Detection | ETM (Entertainment Telematic Module) |
| sp00735 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp00736 | Intake Manifold Replacement | ECM (Engine Control Module) |
| sp00737 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp00738 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp00739 | Intelligent Alternator (IAM) Replacement | ECM (Engine Control Module) |
| sp00740 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp00741 | Fuel Supply System Components Replacement | ECM (Engine Control Module) |
| sp00742 | Motorized Throttle Replacement | ECM (Engine Control Module) |
| sp00743 | Factory VIN code lock | ECM (Engine Control Module) |
| sp00744 | Control Unit Reprogramming | ECM (Engine Control Module) |
| sp00745 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00746 | Proxi Alignment Procedure | ECM (Engine Control Module) |
| sp00747 | Injector/S Replacement | ECM (Engine Control Module) |
| sp00748 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00749 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp00750 | Motorized Throttle Self Learning Command | ECM (Engine Control Module) |
| sp00751 | Proxi Alignment Procedure | TCM (Transmission Control Module) |
| sp00752 | ECU Substitution | ABS (Anti-Lock Braking System) |
| sp00753 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00754 | Pressure Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00755 | TPMS Reset Calibration | ABS (Anti-Lock Braking System) |
| sp00756 | Fire Protection System Activate | BCM (Body Control Module) |
| sp00757 | LIN Line Request Check | BCM (Body Control Module) |
| sp00758 | Ultrasonic Sensors Check | BCM (Body Control Module) |
| sp00759 | Power Down | RRM (Radio Receiver Module) |
| sp00760 | Power On And Disable User Inputs | RRM (Radio Receiver Module) |
| sp00761 | Reset Parameters To Default | RRM (Radio Receiver Module) |
| sp00762 | Clear TPM Sensor Audit | RFH (Radio Frequency Hub) |
| sp00763 | Clear TPM Sensor Warnings | RFH (Radio Frequency Hub) |
| sp00764 | Factory VIN code lock | DTCM (Drive Train Control Module) |
| sp00765 | Proxi Alignment Procedure | DTCM (Drive Train Control Module) |
| sp00766 | Reset Odometer | IC (Instrument Cluster) |
| sp00767 | Reset Service Information | IC (Instrument Cluster) |
| sp00768 | Last Service Date | IC (Instrument Cluster) |
| sp00769 | Self Learning Motors Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp00770 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp00771 | Proxi Alignment Procedure | ESM (Electronic Shifter Module) |

| | | |
|---------|--|---|
| sp00772 | Factory VIN code lock | ESM (Electronic Shifter Module) |
| sp00773 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp00774 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp00775 | Service Single Pole Calibration | HALF (Haptical Lane Feedback) |
| sp00776 | Factory VIN code lock | CSWM (Comfort Seat Wheel Module) |
| sp00777 | Intake Manifold Replacement | ECM (Engine Control Module) |
| sp00778 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp00779 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp00780 | Intelligent Alternator (IAM) Replacement | ECM (Engine Control Module) |
| sp00781 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp00782 | Fuel Supply System Components Replacement | ECM (Engine Control Module) |
| sp00783 | Motorized Throttle Replacement | ECM (Engine Control Module) |
| sp00784 | Factory VIN code lock | ECM (Engine Control Module) |
| sp00785 | Control Unit Reprogramming | ECM (Engine Control Module) |
| sp00786 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00787 | Proxi Alignment Procedure | ECM (Engine Control Module) |
| sp00788 | Injector/S Replacement | ECM (Engine Control Module) |
| sp00789 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00790 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp00791 | Motorized Throttle Self Learning Command | ECM (Engine Control Module) |
| sp00792 | Proxi Alignment Procedure | TCM (Transmission Control Module) |
| sp00793 | ECU Substitution | ABS (Anti-Lock Braking System) |
| sp00794 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00795 | Pressure Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00796 | TPMS Reset Calibration | ABS (Anti-Lock Braking System) |
| sp00797 | Fire Protection System Activate | BCM (Body Control Module) |
| sp00798 | LIN Line Request Check | BCM (Body Control Module) |
| sp00799 | Ultrasonic Sensors Check | BCM (Body Control Module) |
| sp00800 | Power Down | RRM (Radio Receiver Module) |
| sp00801 | Power On And Disable User Inputs | RRM (Radio Receiver Module) |
| sp00802 | Reset Parameters To Default | RRM (Radio Receiver Module) |
| sp00803 | Clear TPM Sensor Audit | RFH (Radio Frequency Hub) |
| sp00804 | Clear TPM Sensor Warnings | RFH (Radio Frequency Hub) |
| sp00805 | Factory VIN code lock | DTCM (Drive Train Control Module) |
| sp00806 | Proxi Alignment Procedure | DTCM (Drive Train Control Module) |
| sp00807 | Reset Odometer | IC (Instrument Cluster) |
| sp00808 | Reset Service Information | IC (Instrument Cluster) |
| sp00809 | Last Service Date | IC (Instrument Cluster) |
| sp00810 | Self Learning Motors Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp00811 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp00812 | Proxi Alignment Procedure | ESM (Electronic Shifter Module) |
| sp00813 | Factory VIN code lock | ESM (Electronic Shifter Module) |
| sp00814 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |

| | | |
|---------|--|---|
| sp00815 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp00816 | Service Single Pole Calibration | HALF (Haptical Lane Feedback) |
| sp00817 | Factory VIN code lock | CSWM (Comfort Seat Wheel Module) |
| sp00818 | Intake Manifold Replacement | ECM (Engine Control Module) |
| sp00819 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp00820 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp00821 | Intelligent Alternator (IAM) Replacement | ECM (Engine Control Module) |
| sp00822 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp00823 | Fuel Supply System Components Replacement | ECM (Engine Control Module) |
| sp00824 | Motorized Throttle Replacement | ECM (Engine Control Module) |
| sp00825 | Factory VIN code lock | ECM (Engine Control Module) |
| sp00826 | Control Unit Reprogramming | ECM (Engine Control Module) |
| sp00827 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00828 | Proxi Alignment Procedure | ECM (Engine Control Module) |
| sp00829 | Injector/S Replacement | ECM (Engine Control Module) |
| sp00830 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00831 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp00832 | Motorized Throttle Self Learning Command | ECM (Engine Control Module) |
| sp00833 | Proxi Alignment Procedure | TCM (Transmission Control Module) |
| sp00834 | ECU Substitution | ABS (Anti-Lock Braking System) |
| sp00835 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00836 | Pressure Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00837 | TPMS Reset Calibration | ABS (Anti-Lock Braking System) |
| sp00838 | Fire Protection System Activate | BCM (Body Control Module) |
| sp00839 | LIN Line Request Check | BCM (Body Control Module) |
| sp00840 | Ultrasonic Sensors Check | BCM (Body Control Module) |
| sp00841 | Power Down | RRM (Radio Receiver Module) |
| sp00842 | Power On And Disable User Inputs | RRM (Radio Receiver Module) |
| sp00843 | Reset Parameters To Default | RRM (Radio Receiver Module) |
| sp00844 | Clear TPM Sensor Audit | RFH (Radio Frequency Hub) |
| sp00845 | Clear TPM Sensor Warnings | RFH (Radio Frequency Hub) |
| sp00846 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp00847 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp00848 | Reset Odometer | IC (Instrument Cluster) |
| sp00849 | Reset Service Information | IC (Instrument Cluster) |
| sp00850 | Last Service Date | IC (Instrument Cluster) |
| sp00851 | Self Learning Motors Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp00852 | Service Single Pole Calibration | HALF (Haptical Lane Feedback) |
| sp00853 | Proxi Alignment Procedure | ESM (Electronic Shifter Module) |
| sp00854 | Factory VIN code lock | ESM (Electronic Shifter Module) |
| sp00855 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp00856 | Factory VIN code lock | DTCM (Drive Train Control Module) |
| sp00857 | Proxi Alignment Procedure | DTCM (Drive Train Control Module) |

| | | |
|---------|--|---|
| sp00858 | Factory VIN code lock | CSWM (Comfort Seat Wheel Module) |
| sp00859 | Intake Manifold Replacement | ECM (Engine Control Module) |
| sp00860 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp00861 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp00862 | Intelligent Alternator (IAM) Replacement | ECM (Engine Control Module) |
| sp00863 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp00864 | Fuel Supply System Components Replacement | ECM (Engine Control Module) |
| sp00865 | Motorized Throttle Replacement | ECM (Engine Control Module) |
| sp00866 | Factory VIN code lock | ECM (Engine Control Module) |
| sp00867 | Control Unit Reprogramming | ECM (Engine Control Module) |
| sp00868 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00869 | Proxi Alignment Procedure | ECM (Engine Control Module) |
| sp00870 | Injector/S Replacement | ECM (Engine Control Module) |
| sp00871 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00872 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp00873 | Motorized Throttle Self Learning Command | ECM (Engine Control Module) |
| sp00874 | Proxi Alignment Procedure | TCM (Transmission Control Module) |
| sp00875 | ECU Substitution | ABS (Anti-Lock Braking System) |
| sp00876 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00877 | Pressure Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00878 | TPMS Reset Calibration | ABS (Anti-Lock Braking System) |
| sp00879 | Fire Protection System Activate | BCM (Body Control Module) |
| sp00880 | LIN Line Request Check | BCM (Body Control Module) |
| sp00881 | Ultrasonic Sensors Check | BCM (Body Control Module) |
| sp00882 | Power Down | RRM (Radio Receiver Module) |
| sp00883 | Power On And Disable User Inputs | RRM (Radio Receiver Module) |
| sp00884 | Reset Parameters To Default | RRM (Radio Receiver Module) |
| sp00885 | Clear TPM Sensor Audit | RFH (Radio Frequency Hub) |
| sp00886 | Clear TPM Sensor Warnings | RFH (Radio Frequency Hub) |
| sp00887 | Factory VIN code lock | DTCM (Drive Train Control Module) |
| sp00888 | Proxi Alignment Procedure | DTCM (Drive Train Control Module) |
| sp00889 | Reset Odometer | IC (Instrument Cluster) |
| sp00890 | Reset Service Information | IC (Instrument Cluster) |
| sp00891 | Last Service Date | IC (Instrument Cluster) |
| sp00892 | Self Learning Motors Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp00893 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp00894 | Proxi Alignment Procedure | ESM (Electronic Shifter Module) |
| sp00895 | Factory VIN code lock | ESM (Electronic Shifter Module) |
| sp00896 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp00897 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp00898 | Service Single Pole Calibration | HALF (Haptical Lane Feedback) |
| sp00899 | Factory VIN code lock | CSWM (Comfort Seat Wheel Module) |
| sp00900 | Intake Manifold Replacement | ECM (Engine Control Module) |

| | | |
|---------|--|---|
| sp00901 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp00902 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp00903 | Intelligent Alternator (IAM) Replacement | ECM (Engine Control Module) |
| sp00904 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp00905 | Fuel Supply System Components Replacement | ECM (Engine Control Module) |
| sp00906 | Motorized Throttle Replacement | ECM (Engine Control Module) |
| sp00907 | Factory VIN code lock | ECM (Engine Control Module) |
| sp00908 | Control Unit Reprogramming | ECM (Engine Control Module) |
| sp00909 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00910 | Proxi Alignment Procedure | ECM (Engine Control Module) |
| sp00911 | Injector/S Replacement | ECM (Engine Control Module) |
| sp00912 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00913 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp00914 | Motorized Throttle Self Learning Command | ECM (Engine Control Module) |
| sp00915 | Proxi Alignment Procedure | TCM (Transmission Control Module) |
| sp00916 | ECU Substitution | ABS (Anti-Lock Braking System) |
| sp00917 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00918 | Pressure Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00919 | TPMS Reset Calibration | ABS (Anti-Lock Braking System) |
| sp00920 | Fire Protection System Activate | BCM (Body Control Module) |
| sp00921 | LIN Line Request Check | BCM (Body Control Module) |
| sp00922 | Ultrasonic Sensors Check | BCM (Body Control Module) |
| sp00923 | Power Down | RRM (Radio Receiver Module) |
| sp00924 | Power On And Disable User Inputs | RRM (Radio Receiver Module) |
| sp00925 | Reset Parameters To Default | RRM (Radio Receiver Module) |
| sp00926 | Clear TPM Sensor Audit | RFH (Radio Frequency Hub) |
| sp00927 | Clear TPM Sensor Warnings | RFH (Radio Frequency Hub) |
| sp00928 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp00929 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp00930 | Reset Odometer | IC (Instrument Cluster) |
| sp00931 | Reset Service Information | IC (Instrument Cluster) |
| sp00932 | Last Service Date | IC (Instrument Cluster) |
| sp00933 | Self Learning Motors Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp00934 | Service Single Pole Calibration | HALF (Haptical Lane Feedback) |
| sp00935 | Proxi Alignment Procedure | ESM (Electronic Shifter Module) |
| sp00936 | Factory VIN code lock | ESM (Electronic Shifter Module) |
| sp00937 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp00938 | Factory VIN code lock | DTCM (Drive Train Control Module) |
| sp00939 | Proxi Alignment Procedure | DTCM (Drive Train Control Module) |
| sp00940 | Factory VIN code lock | CSWM (Comfort Seat Wheel Module) |
| sp00941 | Intake Manifold Replacement | ECM (Engine Control Module) |
| sp00942 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp00943 | Phonic Wheel Replacement | ECM (Engine Control Module) |

| | | |
|---------|--|---|
| sp00944 | Intelligent Alternator (IAM) Replacement | ECM (Engine Control Module) |
| sp00945 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp00946 | Fuel Supply System Components Replacement | ECM (Engine Control Module) |
| sp00947 | Motorized Throttle Replacement | ECM (Engine Control Module) |
| sp00948 | Factory VIN code lock | ECM (Engine Control Module) |
| sp00949 | Control Unit Reprogramming | ECM (Engine Control Module) |
| sp00950 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00951 | Proxi Alignment Procedure | ECM (Engine Control Module) |
| sp00952 | Injector/S Replacement | ECM (Engine Control Module) |
| sp00953 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00954 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp00955 | Motorized Throttle Self Learning Command | ECM (Engine Control Module) |
| sp00956 | Proxi Alignment Procedure | TCM (Transmission Control Module) |
| sp00957 | ECU Substitution | ABS (Anti-Lock Braking System) |
| sp00958 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00959 | Pressure Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp00960 | TPMS Reset Calibration | ABS (Anti-Lock Braking System) |
| sp00961 | Fire Protection System Activate | BCM (Body Control Module) |
| sp00962 | LIN Line Request Check | BCM (Body Control Module) |
| sp00963 | Ultrasonic Sensors Check | BCM (Body Control Module) |
| sp00964 | Power Down | RRM (Radio Receiver Module) |
| sp00965 | Power On And Disable User Inputs | RRM (Radio Receiver Module) |
| sp00966 | Reset Parameters To Default | RRM (Radio Receiver Module) |
| sp00967 | Clear TPM Sensor Audit | RFH (Radio Frequency Hub) |
| sp00968 | Clear TPM Sensor Warnings | RFH (Radio Frequency Hub) |
| sp00969 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp00970 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp00971 | Reset Odometer | IC (Instrument Cluster) |
| sp00972 | Reset Service Information | IC (Instrument Cluster) |
| sp00973 | Last Service Date | IC (Instrument Cluster) |
| sp00974 | Self Learning Motors Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp00975 | Service Single Pole Calibration | HALF (Haptical Lane Feedback) |
| sp00976 | Proxi Alignment Procedure | ESM (Electronic Shifter Module) |
| sp00977 | Factory VIN code lock | ESM (Electronic Shifter Module) |
| sp00978 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp00979 | Factory VIN code lock | DTCM (Drive Train Control Module) |
| sp00980 | Proxi Alignment Procedure | DTCM (Drive Train Control Module) |
| sp00981 | Factory VIN code lock | CSWM (Comfort Seat Wheel Module) |
| sp00982 | Intake Manifold Replacement | ECM (Engine Control Module) |
| sp00983 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp00984 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp00985 | Intelligent Alternator (IAM) Replacement | ECM (Engine Control Module) |
| sp00986 | Neutral Signal Learn | ECM (Engine Control Module) |

| | | |
|---------|--|---|
| sp00987 | Fuel Supply System Components Replacement | ECM (Engine Control Module) |
| sp00988 | Motorized Throttle Replacement | ECM (Engine Control Module) |
| sp00989 | Factory VIN code lock | ECM (Engine Control Module) |
| sp00990 | Control Unit Reprogramming | ECM (Engine Control Module) |
| sp00991 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00992 | Proxi Alignment Procedure | ECM (Engine Control Module) |
| sp00993 | Injector/S Replacement | ECM (Engine Control Module) |
| sp00994 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp00995 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp00996 | Motorized Throttle Self Learning Command | ECM (Engine Control Module) |
| sp00997 | Proxi Alignment Procedure | TCM (Transmission Control Module) |
| sp00998 | ECU Substitution | ABS (Anti-Lock Braking System) |
| sp00999 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp01000 | Pressure Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp01001 | TPMS Reset Calibration | ABS (Anti-Lock Braking System) |
| sp01002 | Fire Protection System Activate | BCM (Body Control Module) |
| sp01003 | LIN Line Request Check | BCM (Body Control Module) |
| sp01004 | Ultrasonic Sensors Check | BCM (Body Control Module) |
| sp01005 | Power Down | RRM (Radio Receiver Module) |
| sp01006 | Power On And Disable User Inputs | RRM (Radio Receiver Module) |
| sp01007 | Reset Parameters To Default | RRM (Radio Receiver Module) |
| sp01008 | Clear TPM Sensor Audit | RFH (Radio Frequency Hub) |
| sp01009 | Clear TPM Sensor Warnings | RFH (Radio Frequency Hub) |
| sp01010 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp01011 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp01012 | Reset Odometer | IC (Instrument Cluster) |
| sp01013 | Reset Service Information | IC (Instrument Cluster) |
| sp01014 | Last Service Date | IC (Instrument Cluster) |
| sp01015 | Self Learning Motors Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp01016 | Service Single Pole Calibration | HALF (Haptical Lane Feedback) |
| sp01017 | Proxi Alignment Procedure | ESM (Electronic Shifter Module) |
| sp01018 | Factory VIN code lock | ESM (Electronic Shifter Module) |
| sp01019 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp01020 | Factory VIN code lock | DTCM (Drive Train Control Module) |
| sp01021 | Proxi Alignment Procedure | DTCM (Drive Train Control Module) |
| sp01022 | Factory VIN code lock | CSWM (Comfort Seat Wheel Module) |
| sp01023 | Deactivation Of The Power Limitation Function | ECM (Engine Control Module) |
| sp01024 | Motorised Throttle Replacement | ECM (Engine Control Module) |
| sp01025 | Supercharging System Components Replacement | ECM (Engine Control Module) |
| sp01026 | Intake Manifold Replacement | ECM (Engine Control Module) |
| sp01027 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp01028 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp01029 | Intelligent Alternator (IAM) Replacement | ECM (Engine Control Module) |

| | | |
|---------|---|---|
| sp01030 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp01031 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp01032 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp01033 | Tunnel Lever Replacement | TCM (Transmission Control Module) |
| sp01034 | Levers At Wheel Replacement | TCM (Transmission Control Module) |
| sp01035 | Pump Relay Replacement | TCM (Transmission Control Module) |
| sp01036 | Self-Learnt Functions Reset | TCM (Transmission Control Module) |
| sp01037 | Static Test | ABS (Anti-Lock Braking System) |
| sp01038 | Trailer Hook Presence Disabling | PAM (Parking Assistant Module) |
| sp01039 | Trailer Hook Presence Enabling | PAM (Parking Assistant Module) |
| sp01040 | Reset Odometer | IC (Instrument Cluster) |
| sp01041 | Reset Service Information | IC (Instrument Cluster) |
| sp01042 | Disable Seat Belts Reminder | IC (Instrument Cluster) |
| sp01043 | Enable Seat Belts Reminder | IC (Instrument Cluster) |
| sp01044 | Last Service Date | IC (Instrument Cluster) |
| sp01045 | Flap Actuators Learning Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp01046 | Audio Video Signal Detection | ETM (Entertainment Telematic Module) |
| sp01047 | Steering Angle Calibration | EPS (Electric Power Steering) |
| sp01048 | ECU Restart Routine | CTM (Convergence Telematic Module) |
| sp01049 | Fire Protection System Activate | BCM (Body Control Module) |
| sp01050 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp01051 | Intelligent Alternator (IAM) Replacement | ECM (Engine Control Module) |
| sp01052 | Differential Pressure Sensor Replac. | ECM (Engine Control Module) |
| sp01053 | Oil Change | ECM (Engine Control Module) |
| sp01054 | Injector Replacement (Per Bank) | ECM (Engine Control Module) |
| sp01055 | Injector Codes Read | ECM (Engine Control Module) |
| sp01056 | Rail Pressure Sensor Replacement | ECM (Engine Control Module) |
| sp01057 | Cylinder 3 Injector Replacement | ECM (Engine Control Module) |
| sp01058 | Cylinder 2 Injector Replacement | ECM (Engine Control Module) |
| sp01059 | Cylinder 1 Injector Replacement | ECM (Engine Control Module) |
| sp01060 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp01061 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp01062 | Replacement Lambda Sensor | ECM (Engine Control Module) |
| sp01063 | Speed Limit Setting | ECM (Engine Control Module) |
| sp01064 | Speed Limit Setting | ECM (Engine Control Module) |
| sp01065 | EGR Valve Test | ECM (Engine Control Module) |
| sp01066 | Glow Plug Preheating Circuit Test | ECM (Engine Control Module) |
| sp01067 | Resetting Distance Travelled With Water In Diesel W.Lamp ON | ECM (Engine Control Module) |
| sp01068 | Throttle Valve Test | ECM (Engine Control Module) |
| sp01069 | Resetting Distance Travelled With Water Temperature Warning Lamp ON | ECM (Engine Control Module) |
| sp01070 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp01071 | Fan Cooling Activation | ECM (Engine Control Module) |
| sp01072 | Tunnel Lever Replacement | TCM (Transmission Control Module) |

| | | |
|---------|---|---|
| sp01073 | Pump Relay Replacement | TCM (Transmission Control Module) |
| sp01074 | Self-Learnt Functions Reset | TCM (Transmission Control Module) |
| sp01075 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp01076 | Pressure Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp01077 | Steering Angle Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp01078 | Write Front And Rear Nominal Tire Pressure Values | TPMS (Tire Pressure Monitoring System) |
| sp01079 | Clear TPM Warnings | TPMS (Tire Pressure Monitoring System) |
| sp01080 | Clear TPM Sensor Rolls Test Results | TPMS (Tire Pressure Monitoring System) |
| sp01081 | ECU SERIAL NUMBER Management | TPMS (Tire Pressure Monitoring System) |
| sp01082 | TPM Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp01083 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01084 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01085 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01086 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01087 | Power Down | RADIO (RADIO) |
| sp01088 | Power On And Disable User Inputs | RADIO (RADIO) |
| sp01089 | Reset Parameters To Default | RADIO (RADIO) |
| sp01090 | Trailer Hook Presence Disabling | PAM (Parking Assistant Module) |
| sp01091 | Trailer Hook Presence Enabling | PAM (Parking Assistant Module) |
| sp01092 | Disable Seat Belts Reminder | IPC (Instrument Panel Cluster) |
| sp01093 | Reset Odometer | IPC (Instrument Panel Cluster) |
| sp01094 | Reset Service Information | IPC (Instrument Panel Cluster) |
| sp01095 | Last Service Date | IPC (Instrument Panel Cluster) |
| sp01096 | Enable Seat Belts Reminder | IPC (Instrument Panel Cluster) |
| sp01097 | Flap Actuators Learning Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp01098 | Power Down | ETM (Entertainment Telematic Module) |
| sp01099 | Power On And Disable User Inputs | ETM (Entertainment Telematic Module) |
| sp01100 | Reset Parameters To Default | ETM (Entertainment Telematic Module) |
| sp01101 | Audio Video Signal Detection | ETM (Entertainment Telematic Module) |
| sp01102 | ECU Restart Routine | CTM (Convergence Telematic Module) |
| sp01103 | Fire Protection System Activate | BCM (Body Control Module) |
| sp01104 | Speed Limit Setting | ECM (Engine Control Module) |
| sp01105 | Vehicle Configuration Reset | ECM (Engine Control Module) |
| sp01106 | Reset Adaptative Parameter | ECM (Engine Control Module) |
| sp01107 | Tunnel Lever Replacement | TCM (Transmission Control Module) |
| sp01108 | Pump Relay Replacement | TCM (Transmission Control Module) |
| sp01109 | Self-Learnt Functions Reset | TCM (Transmission Control Module) |
| sp01110 | Inlet Valve Calibration | ABS (Anti-Lock Braking System) |
| sp01111 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp01112 | Pilot Valve Calibration | ABS (Anti-Lock Braking System) |
| sp01113 | Brake Pressure Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp01114 | Steering Angle Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp01115 | Write Front And Rear Nominal Tire Pressure Values | TPMS (Tire Pressure Monitoring System) |

| | | |
|---------|---|---|
| sp01116 | Clear TPM Warnings | TPMS (Tire Pressure Monitoring System) |
| sp01117 | Clear TPM Sensor Rolls Test Results | TPMS (Tire Pressure Monitoring System) |
| sp01118 | ECU SERIAL NUMBER Management | TPMS (Tire Pressure Monitoring System) |
| sp01119 | TPM Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp01120 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01121 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01122 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01123 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01124 | Trailer Hook Presence Disabling | PAM (Parking Assistant Module) |
| sp01125 | Trailer Hook Presence Enabling | PAM (Parking Assistant Module) |
| sp01126 | Reset Odometer | IC (Instrument Cluster) |
| sp01127 | Reset Service Information | IC (Instrument Cluster) |
| sp01128 | Disable Seat Belts Reminder | IC (Instrument Cluster) |
| sp01129 | Enable Seat Belts Reminder | IC (Instrument Cluster) |
| sp01130 | Last Service Date | IC (Instrument Cluster) |
| sp01131 | Flap Actuators Learning Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp01132 | Fire Protection System Activate | BCM (Body Control Module) |
| sp01133 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp01134 | Differential Pressure Sensor Replac. | ECM (Engine Control Module) |
| sp01135 | Oil Change | ECM (Engine Control Module) |
| sp01136 | Rail Pressure Sensor Replacement | ECM (Engine Control Module) |
| sp01137 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp01138 | Replacement Lambda Sensor | ECM (Engine Control Module) |
| sp01139 | Injector Replacement (Per Bank) | ECM (Engine Control Module) |
| sp01140 | Injector Codes Read | ECM (Engine Control Module) |
| sp01141 | Cylinder 3 Injector Replacement | ECM (Engine Control Module) |
| sp01142 | Cylinder 2 Injector Replacement | ECM (Engine Control Module) |
| sp01143 | Cylinder 1 Injector Replacement | ECM (Engine Control Module) |
| sp01144 | Speed Limit Setting | ECM (Engine Control Module) |
| sp01145 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp01146 | Fan Cooling Activation | ECM (Engine Control Module) |
| sp01147 | EGR Valve Test | ECM (Engine Control Module) |
| sp01148 | Resetting Distance Travelled With Water In Diesel W.Lamp ON | ECM (Engine Control Module) |
| sp01149 | Throttle Valve Test | ECM (Engine Control Module) |
| sp01150 | Resetting Distance Travelled With Water Temperature Warning Lamp ON | ECM (Engine Control Module) |
| sp01151 | Longitudinal And Lateral Sensor Decalibration | ABS (Anti-Lock Braking System) |
| sp01152 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp01153 | Static Test | ABS (Anti-Lock Braking System) |
| sp01154 | Steering Angle Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp01155 | Clear TPM Warnings | TPMS (Tire Pressure Monitoring System) |
| sp01156 | Clear TPM Sensor Rolls Test Results | TPMS (Tire Pressure Monitoring System) |
| sp01157 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01158 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |

| | | |
|---------|---|---|
| sp01159 | ECU SERIAL NUMBER Management | TPMS (Tire Pressure Monitoring System) |
| sp01160 | TPM Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp01161 | Write Front And Rear Axle Nominal Tire Pressure | TPMS (Tire Pressure Monitoring System) |
| sp01162 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01163 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01164 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01165 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01166 | Power Down | RADIO (RADIO) |
| sp01167 | Power On And Disable User Inputs | RADIO (RADIO) |
| sp01168 | Reset Parameters To Default | RADIO (RADIO) |
| sp01169 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp01170 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp01171 | Reset Odometer | IC (Instrument Cluster) |
| sp01172 | Reset Service Information | IC (Instrument Cluster) |
| sp01173 | Disable Seat Belts Reminder | IC (Instrument Cluster) |
| sp01174 | Enable Seat Belts Reminder | IC (Instrument Cluster) |
| sp01175 | Last Service Date | IC (Instrument Cluster) |
| sp01176 | Self Learning Motors Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp01177 | Power Down | ETM (Entertainment Telematic Module) |
| sp01178 | Power On And Disable User Inputs | ETM (Entertainment Telematic Module) |
| sp01179 | Reset Parameters To Default | ETM (Entertainment Telematic Module) |
| sp01180 | Audio Video Signal Detection | ETM (Entertainment Telematic Module) |
| sp01181 | Service Single Pole Calibration | HALF (Haptical Lane Feedback) |
| sp01182 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp01183 | Differential Pressure Sensor Replac. | ECM (Engine Control Module) |
| sp01184 | Oil Change | ECM (Engine Control Module) |
| sp01185 | Rail Pressure Sensor Replacement | ECM (Engine Control Module) |
| sp01186 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp01187 | Replacement Lambda Sensor | ECM (Engine Control Module) |
| sp01188 | Injector Replacement (Per Bank) | ECM (Engine Control Module) |
| sp01189 | Injector Codes Read | ECM (Engine Control Module) |
| sp01190 | Cylinder 3 Injector Replacement | ECM (Engine Control Module) |
| sp01191 | Cylinder 2 Injector Replacement | ECM (Engine Control Module) |
| sp01192 | Cylinder 1 Injector Replacement | ECM (Engine Control Module) |
| sp01193 | Speed Limit Setting | ECM (Engine Control Module) |
| sp01194 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp01195 | Fan Cooling Activation | ECM (Engine Control Module) |
| sp01196 | EGR Valve Test | ECM (Engine Control Module) |
| sp01197 | Resetting Distance Travelled With Water In Diesel W. Lamp ON | ECM (Engine Control Module) |
| sp01198 | Throttle Valve Test | ECM (Engine Control Module) |
| sp01199 | Resetting Distance Travelled With Water Temperature Warning Lamp ON | ECM (Engine Control Module) |
| sp01200 | Longitudinal And Lateral Sensor Decalibration | ABS (Anti-Lock Braking System) |
| sp01201 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |

| | | |
|---------|---|---|
| sp01202 | Static Test | ABS (Anti-Lock Braking System) |
| sp01203 | Steering Angle Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp01204 | Clear TPM Warnings | TPMS (Tire Pressure Monitoring System) |
| sp01205 | Clear TPM Sensor Rolls Test Results | TPMS (Tire Pressure Monitoring System) |
| sp01206 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01207 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01208 | ECU SERIAL NUMBER Management | TPMS (Tire Pressure Monitoring System) |
| sp01209 | TPM Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp01210 | Write Front And Rear Axle Nominal Tire Pressure | TPMS (Tire Pressure Monitoring System) |
| sp01211 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01212 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01213 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01214 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01215 | Power Down | RADIO (RADIO) |
| sp01216 | Power On And Disable User Inputs | RADIO (RADIO) |
| sp01217 | Reset Parameters To Default | RADIO (RADIO) |
| sp01218 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp01219 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp01220 | Reset Odometer | IC (Instrument Cluster) |
| sp01221 | Reset Service Information | IC (Instrument Cluster) |
| sp01222 | Disable Seat Belts Reminder | IC (Instrument Cluster) |
| sp01223 | Enable Seat Belts Reminder | IC (Instrument Cluster) |
| sp01224 | Last Service Date | IC (Instrument Cluster) |
| sp01225 | Self Learning Motors Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp01226 | Service Single Pole Calibration | HALF (Haptical Lane Feedback) |
| sp01227 | Power Down | ETM (Entertainment Telematic Module) |
| sp01228 | Power On And Disable User Inputs | ETM (Entertainment Telematic Module) |
| sp01229 | Reset Parameters To Default | ETM (Entertainment Telematic Module) |
| sp01230 | Audio Video Signal Detection | ETM (Entertainment Telematic Module) |
| sp01231 | Resetting Distance Travelled With Water In Diesel W.Lamp ON | ECM (Engine Control Module) |
| sp01232 | Resetting Distance Travelled With Water Temperature Warning Lamp ON | ECM (Engine Control Module) |
| sp01233 | Fan Cooling Activation | ECM (Engine Control Module) |
| sp01234 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp01235 | Injector Codes Read | ECM (Engine Control Module) |
| sp01236 | Nox Replacement | ECM (Engine Control Module) |
| sp01237 | Factory VIN code lock | ECM (Engine Control Module) |
| sp01238 | Intelligent Alternator (IAM) Replacement | ECM (Engine Control Module) |
| sp01239 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp01240 | Injector Replacement (Per Bank) | ECM (Engine Control Module) |
| sp01241 | Cylinder 1 Injector Replacement | ECM (Engine Control Module) |
| sp01242 | Cylinder 2 Injector Replacement | ECM (Engine Control Module) |
| sp01243 | Cylinder 3 Injector Replacement | ECM (Engine Control Module) |
| sp01244 | Replacement Lambda Sensor | ECM (Engine Control Module) |

| | | |
|---------|---|---|
| sp01245 | Oil Change | ECM (Engine Control Module) |
| sp01246 | Differential Pressure Sensor Replac. | ECM (Engine Control Module) |
| sp01247 | Rail Pressure Sensor Replacement | ECM (Engine Control Module) |
| sp01248 | Replacement Of EGR Valve | ECM (Engine Control Module) |
| sp01249 | EGR Low Pressure Valve Replacement | ECM (Engine Control Module) |
| sp01250 | Glow Plug Preheating Circuit Test | ECM (Engine Control Module) |
| sp01251 | EGR Valve Test | ECM (Engine Control Module) |
| sp01252 | EGR Low Pressure Valve Test | ECM (Engine Control Module) |
| sp01253 | Throttle Valve Test | ECM (Engine Control Module) |
| sp01254 | Proxi Alignment Procedure | ECM (Engine Control Module) |
| sp01255 | Neutral Position Self Learning. | TCM (Transmission Control Module) |
| sp01256 | Clear Self-Learning Data | TCM (Transmission Control Module) |
| sp01257 | Gearbox Replacement | TCM (Transmission Control Module) |
| sp01258 | Static Test | ABS (Anti-Lock Braking System) |
| sp01259 | Power Down | RRM (Radio Receiver Module) |
| sp01260 | Power On And Disable User Inputs | RRM (Radio Receiver Module) |
| sp01261 | Reset Parameters To Default | RRM (Radio Receiver Module) |
| sp01262 | Trailer Hook Presence Disabling | PAM (Parking Assistant Module) |
| sp01263 | Trailer Hook Presence Enabling | PAM (Parking Assistant Module) |
| sp01264 | Reset Service Information | IC (Instrument Cluster) |
| sp01265 | Reset Odometer | IC (Instrument Cluster) |
| sp01266 | Last Service Date | IC (Instrument Cluster) |
| sp01267 | Self Learning Motors Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp01268 | Proxi Alignment Procedure | ESM (Electronic Shifter Module) |
| sp01269 | Factory VIN code lock | ESM (Electronic Shifter Module) |
| sp01270 | Resetting Distance Travelled With Water In Diesel W.Lamp ON | ECM (Engine Control Module) |
| sp01271 | Resetting Distance Travelled With Water Temperature Warning Lamp ON | ECM (Engine Control Module) |
| sp01272 | Fan Cooling Activation | ECM (Engine Control Module) |
| sp01273 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp01274 | Injector Codes Read | ECM (Engine Control Module) |
| sp01275 | Nox Replacement | ECM (Engine Control Module) |
| sp01276 | Factory VIN code lock | ECM (Engine Control Module) |
| sp01277 | Intelligent Alternator (IAM) Replacement | ECM (Engine Control Module) |
| sp01278 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp01279 | Injector Replacement (Per Bank) | ECM (Engine Control Module) |
| sp01280 | Cylinder 1 Injector Replacement | ECM (Engine Control Module) |
| sp01281 | Cylinder 2 Injector Replacement | ECM (Engine Control Module) |
| sp01282 | Cylinder 3 Injector Replacement | ECM (Engine Control Module) |
| sp01283 | Replacement Lambda Sensor | ECM (Engine Control Module) |
| sp01284 | Oil Change | ECM (Engine Control Module) |
| sp01285 | Differential Pressure Sensor Replac. | ECM (Engine Control Module) |
| sp01286 | Rail Pressure Sensor Replacement | ECM (Engine Control Module) |
| sp01287 | Replacement Of EGR Valve | ECM (Engine Control Module) |

| | | |
|---------|---|---|
| sp01288 | EGR Low Pressure Valve Replacement | ECM (Engine Control Module) |
| sp01289 | Glow Plug Preheating Circuit Test | ECM (Engine Control Module) |
| sp01290 | EGR Valve Test | ECM (Engine Control Module) |
| sp01291 | EGR Low Pressure Valve Test | ECM (Engine Control Module) |
| sp01292 | Throttle Valve Test | ECM (Engine Control Module) |
| sp01293 | Proxi Alignment Procedure | ECM (Engine Control Module) |
| sp01294 | Neutral Position Self Learning. | TCM (Transmission Control Module) |
| sp01295 | Clear Self-Learning Data | TCM (Transmission Control Module) |
| sp01296 | Gearbox Replacement | TCM (Transmission Control Module) |
| sp01297 | Static Test | ABS (Anti-Lock Braking System) |
| sp01298 | Power Down | RRM (Radio Receiver Module) |
| sp01299 | Power On And Disable User Inputs | RRM (Radio Receiver Module) |
| sp01300 | Reset Parameters To Default | RRM (Radio Receiver Module) |
| sp01301 | Trailer Hook Presence Disabling | PAM (Parking Assistant Module) |
| sp01302 | Trailer Hook Presence Enabling | PAM (Parking Assistant Module) |
| sp01303 | Reset Service Information | IC (Instrument Cluster) |
| sp01304 | Reset Odometer | IC (Instrument Cluster) |
| sp01305 | Last Service Date | IC (Instrument Cluster) |
| sp01306 | Self Learning Motors Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp01307 | Proxi Alignment Procedure | ESM (Electronic Shifter Module) |
| sp01308 | Factory VIN code lock | ESM (Electronic Shifter Module) |
| sp01309 | Resetting Distance Travelled With Water In Diesel W. Lamp ON | ECM (Engine Control Module) |
| sp01310 | Resetting Distance Travelled With Water Temperature Warning Lamp ON | ECM (Engine Control Module) |
| sp01311 | Fan Cooling Activation | ECM (Engine Control Module) |
| sp01312 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp01313 | Injector Codes Read | ECM (Engine Control Module) |
| sp01314 | Nox Replacement | ECM (Engine Control Module) |
| sp01315 | Factory VIN code lock | ECM (Engine Control Module) |
| sp01316 | Intelligent Alternator (IAM) Replacement | ECM (Engine Control Module) |
| sp01317 | Clutch Group And/Or Clutch Potentiometer Replacement | ECM (Engine Control Module) |
| sp01318 | Injector Replacement (Per Bank) | ECM (Engine Control Module) |
| sp01319 | Cylinder 1 Injector Replacement | ECM (Engine Control Module) |
| sp01320 | Cylinder 2 Injector Replacement | ECM (Engine Control Module) |
| sp01321 | Cylinder 3 Injector Replacement | ECM (Engine Control Module) |
| sp01322 | Replacement Lambda Sensor | ECM (Engine Control Module) |
| sp01323 | Oil Change | ECM (Engine Control Module) |
| sp01324 | Differential Pressure Sensor Replac. | ECM (Engine Control Module) |
| sp01325 | Rail Pressure Sensor Replacement | ECM (Engine Control Module) |
| sp01326 | Replacement Of EGR Valve | ECM (Engine Control Module) |
| sp01327 | EGR Low Pressure Valve Replacement | ECM (Engine Control Module) |
| sp01328 | Glow Plug Preheating Circuit Test | ECM (Engine Control Module) |
| sp01329 | EGR Valve Test | ECM (Engine Control Module) |
| sp01330 | EGR Low Pressure Valve Test | ECM (Engine Control Module) |

| | | |
|---------|---|---|
| sp01331 | Throttle Valve Test | ECM (Engine Control Module) |
| sp01332 | Proxi Alignment Procedure | ECM (Engine Control Module) |
| sp01333 | Neutral Position Self Learning. | TCM (Transmission Control Module) |
| sp01334 | Clear Self-Learning Data | TCM (Transmission Control Module) |
| sp01335 | Gearbox Replacement | TCM (Transmission Control Module) |
| sp01336 | Static Test | ABS (Anti-Lock Braking System) |
| sp01337 | Power Down | RRM (Radio Receiver Module) |
| sp01338 | Power On And Disable User Inputs | RRM (Radio Receiver Module) |
| sp01339 | Reset Parameters To Default | RRM (Radio Receiver Module) |
| sp01340 | Trailer Hook Presence Disabling | PAM (Parking Assistant Module) |
| sp01341 | Trailer Hook Presence Enabling | PAM (Parking Assistant Module) |
| sp01342 | Reset Service Information | IC (Instrument Cluster) |
| sp01343 | Reset Odometer | IC (Instrument Cluster) |
| sp01344 | Last Service Date | IC (Instrument Cluster) |
| sp01345 | Self Learning Motors Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp01346 | Proxi Alignment Procedure | ESM (Electronic Shifter Module) |
| sp01347 | Factory VIN code lock | ESM (Electronic Shifter Module) |
| sp01348 | Differential Pressure Sensor Replac. | ECM (Engine Control Module) |
| sp01349 | Oil Change | ECM (Engine Control Module) |
| sp01350 | Injector Replacement (Per Bank) | ECM (Engine Control Module) |
| sp01351 | Injector Codes Read | ECM (Engine Control Module) |
| sp01352 | Rail Pressure Sensor Replacement | ECM (Engine Control Module) |
| sp01353 | Cylinder 3 Injector Replacement | ECM (Engine Control Module) |
| sp01354 | Cylinder 2 Injector Replacement | ECM (Engine Control Module) |
| sp01355 | Cylinder 1 Injector Replacement | ECM (Engine Control Module) |
| sp01356 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp01357 | Replacement Lambda Sensor | ECM (Engine Control Module) |
| sp01358 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp01359 | EGR Valve Test | ECM (Engine Control Module) |
| sp01360 | Glow Plug Preheating Circuit Test | ECM (Engine Control Module) |
| sp01361 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp01362 | Resetting Distance Travelled With Water In Diesel W.Lamp ON | ECM (Engine Control Module) |
| sp01363 | Throttle Valve Test | ECM (Engine Control Module) |
| sp01364 | Resetting Distance Travelled With Water Temperature Warning Lamp ON | ECM (Engine Control Module) |
| sp01365 | Fan Cooling Activation | ECM (Engine Control Module) |
| sp01366 | Speed Limit Setting | ECM (Engine Control Module) |
| sp01367 | Tunnel Lever Replacement | TCM (Transmission Control Module) |
| sp01368 | Pump Relay Replacement | TCM (Transmission Control Module) |
| sp01369 | Self-Learnt Functions Reset | TCM (Transmission Control Module) |
| sp01370 | Longitudinal And Lateral Sensor Decalibration | ABS (Anti-Lock Braking System) |
| sp01371 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp01372 | Static Test | ABS (Anti-Lock Braking System) |
| sp01373 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |

| | | |
|---------|---|------------------------------------|
| sp01374 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp01375 | Reset Odometer | IC (Instrument Cluster) |
| sp01376 | Enable Seat Belts Reminder | IC (Instrument Cluster) |
| sp01377 | Disable Seat Belts Reminder | IC (Instrument Cluster) |
| sp01378 | ECU Restart Routine | CTM (Convergence Telematic Module) |
| sp01379 | Differential Pressure Sensor Replac. | ECM (Engine Control Module) |
| sp01380 | Oil Change | ECM (Engine Control Module) |
| sp01381 | Injector Replacement (Per Bank) | ECM (Engine Control Module) |
| sp01382 | Injector Codes Read | ECM (Engine Control Module) |
| sp01383 | Rail Pressure Sensor Replacement | ECM (Engine Control Module) |
| sp01384 | Cylinder 3 Injector Replacement | ECM (Engine Control Module) |
| sp01385 | Cylinder 2 Injector Replacement | ECM (Engine Control Module) |
| sp01386 | Cylinder 1 Injector Replacement | ECM (Engine Control Module) |
| sp01387 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp01388 | Replacement Lambda Sensor | ECM (Engine Control Module) |
| sp01389 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp01390 | EGR Valve Test | ECM (Engine Control Module) |
| sp01391 | Glow Plug Preheating Circuit Test | ECM (Engine Control Module) |
| sp01392 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp01393 | Resetting Distance Travelled With Water In Diesel W.Lamp ON | ECM (Engine Control Module) |
| sp01394 | Throttle Valve Test | ECM (Engine Control Module) |
| sp01395 | Resetting Distance Travelled With Water Temperature Warning Lamp ON | ECM (Engine Control Module) |
| sp01396 | Fan Cooling Activation | ECM (Engine Control Module) |
| sp01397 | Speed Limit Setting | ECM (Engine Control Module) |
| sp01398 | Tunnel Lever Replacement | TCM (Transmission Control Module) |
| sp01399 | Pump Relay Replacement | TCM (Transmission Control Module) |
| sp01400 | Self-Learnt Functions Reset | TCM (Transmission Control Module) |
| sp01401 | Longitudinal And Lateral Sensor Decalibration | ABS (Anti-Lock Braking System) |
| sp01402 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp01403 | Static Test | ABS (Anti-Lock Braking System) |
| sp01404 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp01405 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp01406 | Reset Odometer | IC (Instrument Cluster) |
| sp01407 | Enable Seat Belts Reminder | IC (Instrument Cluster) |
| sp01408 | Disable Seat Belts Reminder | IC (Instrument Cluster) |
| sp01409 | ECU Restart Routine | CTM (Convergence Telematic Module) |
| sp01410 | Air Flow Meter Replacement | PCM (Powertrain Control Module) |
| sp01411 | DPF Reset Option | PCM (Powertrain Control Module) |
| sp01412 | Lambda Sensor Replace | PCM (Powertrain Control Module) |
| sp01413 | Reset Of Lambda Values | PCM (Powertrain Control Module) |
| sp01414 | Reset Oil Change Indicator | PCM (Powertrain Control Module) |
| sp01415 | Reset Zero Fuel Quantity Calibration | PCM (Powertrain Control Module) |
| sp01416 | Service Diesel Particulate Filter Regeneration | PCM (Powertrain Control Module) |

| | | |
|---------|--|---|
| sp01417 | Throttle Valve Learn | PCM (Powertrain Control Module) |
| sp01418 | ABS Bleed Brakes | ABS (Anti-Lock Braking System) |
| sp01419 | Brake Pedal Calibration | ABS (Anti-Lock Braking System) |
| sp01420 | Initialize ORC | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01421 | Rollover Detection | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01422 | Activate Driver And Passenger Head Restraint | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01423 | Program Tire Sensor ID With TPM Tool | TPMS (Tire Pressure Monitoring System) |
| sp01424 | Actuator Calibration Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp01425 | Initialize EPPM | EPPM (Electronic Pedestrian Protection Module) |
| sp01426 | Configure License Plate Size | EPB (Electrical Parking Brake) |
| sp01427 | System Wiring Test | EPB (Electrical Parking Brake) |
| sp01428 | Auto Door Lock | BCM (Body Control Module) |
| sp01429 | Program Tire Size | BCM (Body Control Module) |
| sp01430 | Exit Shipping Mode | BCM (Body Control Module) |
| sp01431 | Air Flow Meter Replacement | PCM (Powertrain Control Module) |
| sp01432 | DPF Reset Option | PCM (Powertrain Control Module) |
| sp01433 | Lambda Sensor Replace | PCM (Powertrain Control Module) |
| sp01434 | Reset Of Lambda Values | PCM (Powertrain Control Module) |
| sp01435 | Reset Oil Change Indicator | PCM (Powertrain Control Module) |
| sp01436 | Reset Zero Fuel Quantity Calibration | PCM (Powertrain Control Module) |
| sp01437 | Service Diesel Particulate Filter Regeneration | PCM (Powertrain Control Module) |
| sp01438 | Throttle Valve Learn | PCM (Powertrain Control Module) |
| sp01439 | ABS Bleed Brakes | ABS (Anti-Lock Braking System) |
| sp01440 | Brake Pedal Calibration | ABS (Anti-Lock Braking System) |
| sp01441 | Initialize ORC | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01442 | Rollover Detection | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01443 | Activate Driver And Passenger Head Restraint | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01444 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01445 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01446 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01447 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01448 | Program Tire Sensor ID With TPM Tool | TPMS (Tire Pressure Monitoring System) |
| sp01449 | Activate TPM High Gain Mode | TPMS (Tire Pressure Monitoring System) |
| sp01450 | TPM Sensor Position Parameter Update | TPMS (Tire Pressure Monitoring System) |
| sp01451 | Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp01452 | Actuator Calibration Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp01453 | Initialize EPPM | EPPM (Electronic Pedestrian Protection Module) |
| sp01454 | Configure License Plate Size | EPB (Electrical Parking Brake) |
| sp01455 | System Wiring Test | EPB (Electrical Parking Brake) |
| sp01456 | Auto Door Lock | BCM (Body Control Module) |
| sp01457 | Program Tire Size | BCM (Body Control Module) |
| sp01458 | Exit Shipping Mode | BCM (Body Control Module) |
| sp01459 | Cam Crank Relearn | PCM (Powertrain Control Module) |

| | | |
|---------|--|---|
| sp01460 | Check PCM Odometer | PCM (Powertrain Control Module) |
| sp01461 | Quicklearn (62TE) | PCM (Powertrain Control Module) |
| sp01462 | Quicklearn (Non-RFE) | PCM (Powertrain Control Module) |
| sp01463 | Reset Memory | PCM (Powertrain Control Module) |
| sp01464 | Write Pinion Factor | PCM (Powertrain Control Module) |
| sp01465 | EGR System Test | PCM (Powertrain Control Module) |
| sp01466 | ETC Throttle Follower Test | PCM (Powertrain Control Module) |
| sp01467 | Set Engine RPM | PCM (Powertrain Control Module) |
| sp01468 | Shift Lever Position Test (62TE) | PCM (Powertrain Control Module) |
| sp01469 | Shift Lever Position Test (Non-RFE) | PCM (Powertrain Control Module) |
| sp01470 | ABS Bleed Brakes | ABS (Anti-Lock Braking System) |
| sp01471 | Brake Pedal Calibration | ABS (Anti-Lock Braking System) |
| sp01472 | Initialize ORC | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01473 | Rollover Detection | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01474 | Activate Driver And Passenger Head Restraint | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01475 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01476 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01477 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01478 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01479 | Program Tire Sensor ID With TPM Tool | TPMS (Tire Pressure Monitoring System) |
| sp01480 | Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp01481 | Actuator Calibration Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp01482 | Initialize EPPM | EPPM (Electronic Pedestrian Protection Module) |
| sp01483 | Configure License Plate Size | EPB (Electrical Parking Brake) |
| sp01484 | System Wiring Test | EPB (Electrical Parking Brake) |
| sp01485 | Auto Door Lock | BCM (Body Control Module) |
| sp01486 | Program Tire Size | BCM (Body Control Module) |
| sp01487 | Exit Shipping Mode | BCM (Body Control Module) |
| sp01488 | Air Flow Meter Replacement | PCM (Powertrain Control Module) |
| sp01489 | DPF Reset Option | PCM (Powertrain Control Module) |
| sp01490 | Lambda Sensor Replace | PCM (Powertrain Control Module) |
| sp01491 | Reset Of Lambda Values | PCM (Powertrain Control Module) |
| sp01492 | Reset Oil Change Indicator | PCM (Powertrain Control Module) |
| sp01493 | Reset Zero Fuel Quantity Calibration | PCM (Powertrain Control Module) |
| sp01494 | Service Diesel Particulate Filter Regeneration | PCM (Powertrain Control Module) |
| sp01495 | Throttle Valve Learn | PCM (Powertrain Control Module) |
| sp01496 | ABS Bleed Brakes | ABS (Anti-Lock Braking System) |
| sp01497 | Brake Pedal Calibration | ABS (Anti-Lock Braking System) |
| sp01498 | Initialize ORC | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01499 | Rollover Detection | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01500 | Activate Driver And Passenger Head Restraint | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01501 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01502 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |

| | | |
|---------|--|---|
| sp01503 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01504 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01505 | Program Tire Sensor ID With TPM Tool | TPMS (Tire Pressure Monitoring System) |
| sp01506 | Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp01507 | Actuator Calibration Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp01508 | Initialize EPPM | EPPM (Electronic Pedestrian Protection Module) |
| sp01509 | Configure License Plate Size | EPB (Electrical Parking Brake) |
| sp01510 | System Wiring Test | EPB (Electrical Parking Brake) |
| sp01511 | Auto Door Lock | BCM (Body Control Module) |
| sp01512 | Program Tire Size | BCM (Body Control Module) |
| sp01513 | Exit Shipping Mode | BCM (Body Control Module) |
| sp01514 | Air Flow Meter Replacement | PCM (Powertrain Control Module) |
| sp01515 | DPF Reset Option | PCM (Powertrain Control Module) |
| sp01516 | Lambda Sensor Replace | PCM (Powertrain Control Module) |
| sp01517 | Reset Of Lambda Values | PCM (Powertrain Control Module) |
| sp01518 | Reset Oil Change Indicator | PCM (Powertrain Control Module) |
| sp01519 | Reset Zero Fuel Quantity Calibration | PCM (Powertrain Control Module) |
| sp01520 | Service Diesel Particulate Filter Regeneration | PCM (Powertrain Control Module) |
| sp01521 | Throttle Valve Learn | PCM (Powertrain Control Module) |
| sp01522 | ABS Bleed Brakes | ABS (Anti-Lock Braking System) |
| sp01523 | Brake Pedal Calibration | ABS (Anti-Lock Braking System) |
| sp01524 | Initialize ORC | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01525 | Rollover Detection | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01526 | Activate Driver And Passenger Head Restraint | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01527 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01528 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01529 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01530 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01531 | Program Tire Sensor ID With TPM Tool | TPMS (Tire Pressure Monitoring System) |
| sp01532 | Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp01533 | Actuator Calibration Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp01534 | Initialize EPPM | EPPM (Electronic Pedestrian Protection Module) |
| sp01535 | Configure License Plate Size | EPB (Electrical Parking Brake) |
| sp01536 | System Wiring Test | EPB (Electrical Parking Brake) |
| sp01537 | Auto Door Lock | BCM (Body Control Module) |
| sp01538 | Program Tire Size | BCM (Body Control Module) |
| sp01539 | Exit Shipping Mode | BCM (Body Control Module) |
| sp01540 | Air Flow Meter Replacement | PCM (Powertrain Control Module) |
| sp01541 | DPF Reset Option | PCM (Powertrain Control Module) |
| sp01542 | Lambda Sensor Replace | PCM (Powertrain Control Module) |
| sp01543 | Reset Of Lambda Values | PCM (Powertrain Control Module) |
| sp01544 | Reset Oil Change Indicator | PCM (Powertrain Control Module) |
| sp01545 | Reset Zero Fuel Quantity Calibration | PCM (Powertrain Control Module) |

| | | |
|---------|--|---|
| sp01546 | Service Diesel Particulate Filter Regeneration | PCM (Powertrain Control Module) |
| sp01547 | Throttle Valve Learn | PCM (Powertrain Control Module) |
| sp01548 | ABS Bleed Brakes | ABS (Anti-Lock Braking System) |
| sp01549 | Brake Pedal Calibration | ABS (Anti-Lock Braking System) |
| sp01550 | Initialize ORC | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01551 | Rollover Detection | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01552 | Activate Driver And Passenger Head Restraint | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01553 | Auto Door Lock | BCM (Body Control Module) |
| sp01554 | Program Tire Size | BCM (Body Control Module) |
| sp01555 | Exit Shipping Mode | BCM (Body Control Module) |
| sp01556 | Program Left Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01557 | Program Left Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01558 | Program Right Front Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01559 | Program Right Rear Tire Sensor ID | TPMS (Tire Pressure Monitoring System) |
| sp01560 | Program Tire Sensor ID With TPM Tool | TPMS (Tire Pressure Monitoring System) |
| sp01561 | Sensor Rolls Test | TPMS (Tire Pressure Monitoring System) |
| sp01562 | Actuator Calibration Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp01563 | Configure License Plate Size | EPB (Electrical Parking Brake) |
| sp01564 | System Wiring Test | EPB (Electrical Parking Brake) |
| sp01565 | Air Flow Meter Replacement | PCM (Powertrain Control Module) |
| sp01566 | DPF Reset Option | PCM (Powertrain Control Module) |
| sp01567 | Lambda Sensor Replace | PCM (Powertrain Control Module) |
| sp01568 | Reset Of Lambda Values | PCM (Powertrain Control Module) |
| sp01569 | Reset Oil Change Indicator | PCM (Powertrain Control Module) |
| sp01570 | Reset Zero Fuel Quantity Calibration | PCM (Powertrain Control Module) |
| sp01571 | Service Diesel Particulate Filter Regeneration | PCM (Powertrain Control Module) |
| sp01572 | Throttle Valve Learn | PCM (Powertrain Control Module) |
| sp01573 | ABS Bleed Brakes | ABS (Anti-Lock Braking System) |
| sp01574 | Brake Pedal Calibration | ABS (Anti-Lock Braking System) |
| sp01575 | Initialize ORC | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01576 | Rollover Detection | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01577 | Activate Driver And Passenger Head Restraint | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01578 | Auto Door Lock | BCM (Body Control Module) |
| sp01579 | Program Tire Size | BCM (Body Control Module) |
| sp01580 | Exit Shipping Mode | BCM (Body Control Module) |
| sp01581 | Initialize EPPM | EPPM (Electronic Pedestrian Protection Module) |
| sp01582 | Program Tire Sensor ID With TPM Tool | TPMS (Tire Pressure Monitoring System) |
| sp01583 | Actuator Calibration Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp01584 | Configure License Plate Size | Electronic Parking (EPB) |
| sp01585 | System Wiring Test | Electronic Parking (EPB) |
| sp01586 | Air Flow Meter Replacement | PCM (Powertrain Control Module) |
| sp01587 | DPF Reset Option | PCM (Powertrain Control Module) |
| sp01588 | Lambda Sensor Replace | PCM (Powertrain Control Module) |

| | | |
|---------|--|---|
| sp01589 | Reset Of Lambda Values | PCM (Powertrain Control Module) |
| sp01590 | Reset Oil Change Indicator | PCM (Powertrain Control Module) |
| sp01591 | Reset Zero Fuel Quantity Calibration | PCM (Powertrain Control Module) |
| sp01592 | Service Diesel Particulate Filter Regeneration | PCM (Powertrain Control Module) |
| sp01593 | Throttle Valve Learn | PCM (Powertrain Control Module) |
| sp01594 | ABS Bleed Brakes | ABS (Anti-Lock Braking System) |
| sp01595 | Brake Pedal Calibration | ABS (Anti-Lock Braking System) |
| sp01596 | Initialize ORC | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01597 | Rollover Detection | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01598 | Activate Driver And Passenger Head Restraint | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01599 | ECM Proxi Alignment | ECM (Engine Control Module) |
| sp01600 | Reset Adaptative Parameter | ECM (Engine Control Module) |
| sp01601 | Vehicle Configuration Reset | ECM (Engine Control Module) |
| sp01602 | Self Learning Throttle Body Activation | ECM (Engine Control Module) |
| sp01603 | General Stop Actuator | ECM (Engine Control Module) |
| sp01604 | Reset Functions Self Learned | TCM (Transmission Control Module) |
| sp01605 | Disabling All Actuators | TCM (Transmission Control Module) |
| sp01606 | Shutdown Actuators | TCM (Transmission Control Module) |
| sp01607 | Learn Clutches Contact Point | TCM (Transmission Control Module) |
| sp01608 | Quick Learn | TCM (Transmission Control Module) |
| sp01609 | Hydraulic Circuit Depressurization | TCM (Transmission Control Module) |
| sp01610 | Bleed Hydraulic Circuit | TCM (Transmission Control Module) |
| sp01611 | MTA Proxi Configuration | TCM (Transmission Control Module) |
| sp01612 | ECU Replacement With Value Transfer | TCM (Transmission Control Module) |
| sp01613 | New Actuators | TCM (Transmission Control Module) |
| sp01614 | Reset TPMS Calibration | ABS (Anti Lock Brakes) |
| sp01615 | ORC Proxi Alignment | ORC (Occupant Restraint) |
| sp01616 | Reset Parameter. | LTM (Low Telematic Module) |
| sp01617 | Reset Parameter. | ETM (Entertainment Telematic Module) |
| sp01618 | Reset Parameter | ETM (Entertainment Telematic Module) |
| sp01619 | Reset Functions Self Learned | DMM (Doors Management Module) |
| sp01620 | Disabling All Actuators | DMM (Doors Management Module) |
| sp01621 | Shutdown Actuators | DMM (Doors Management Module) |
| sp01622 | Learn Clutches Contact Point | DMM (Doors Management Module) |
| sp01623 | Quick Learn | DMM (Doors Management Module) |
| sp01624 | Hydraulic Circuit Depressurization | DMM (Doors Management Module) |
| sp01625 | Bleed Hydraulic Circuit | DMM (Doors Management Module) |
| sp01626 | MTA Proxi Configuration | DMM (Doors Management Module) |
| sp01627 | ECU Replacement With Value Transfer | DMM (Doors Management Module) |
| sp01628 | New Actuators | DMM (Doors Management Module) |
| sp01629 | Lock Doors Command | BCM (Body Control Module) |
| sp01630 | Wind Shield Wiper | BCM (Body Control Module) |
| sp01631 | Rear Window Washer Command | BCM (Body Control Module) |

| | | |
|---------|--|--------------------------------------|
| sp01632 | Unlock Doors Command | BCM (Body Control Module) |
| sp01633 | Rear Window Wiper Command | BCM (Body Control Module) |
| sp01634 | Siren Command | BCM (Body Control Module) |
| sp01635 | ECM Proxi Alignment | ECM (Engine Control Module) |
| sp01636 | Reset Adaptative Parameter | ECM (Engine Control Module) |
| sp01637 | Vehicle Configuration Reset | ECM (Engine Control Module) |
| sp01638 | Self Learning Throttle Body Activation | ECM (Engine Control Module) |
| sp01639 | General Stop Actuator | ECM (Engine Control Module) |
| sp01640 | Reset Functions Self Learned | TCM (Transmission Control Module) |
| sp01641 | Disabling All Actuators | TCM (Transmission Control Module) |
| sp01642 | Shutdown Actuators | TCM (Transmission Control Module) |
| sp01643 | Learn Clutches Contact Point | TCM (Transmission Control Module) |
| sp01644 | Quick Learn | TCM (Transmission Control Module) |
| sp01645 | Hydraulic Circuit Depressurization | TCM (Transmission Control Module) |
| sp01646 | Bleed Hydraulic Circuit | TCM (Transmission Control Module) |
| sp01647 | MTA Proxi Configuration | TCM (Transmission Control Module) |
| sp01648 | ECU Replacement With Value Transfer | TCM (Transmission Control Module) |
| sp01649 | New Actuators | TCM (Transmission Control Module) |
| sp01650 | Reset TPMS Calibration | ABS (Anti Lock Brakes) |
| sp01651 | ORC Proxi Alignment | ORC (Occupant Restraint) |
| sp01652 | Reset Parameter. | LTM (Low Telematic Module) |
| sp01653 | Reset Parameter. | ETM (Entertainment Telematic Module) |
| sp01654 | Reset Parameter | ETM (Entertainment Telematic Module) |
| sp01655 | Reset Functions Self Learned | DMM (Doors Management Module) |
| sp01656 | Disabling All Actuators | DMM (Doors Management Module) |
| sp01657 | Shutdown Actuators | DMM (Doors Management Module) |
| sp01658 | Learn Clutches Contact Point | DMM (Doors Management Module) |
| sp01659 | Quick Learn | DMM (Doors Management Module) |
| sp01660 | Hydraulic Circuit Depressurization | DMM (Doors Management Module) |
| sp01661 | Bleed Hydraulic Circuit | DMM (Doors Management Module) |
| sp01662 | MTA Proxi Configuration | DMM (Doors Management Module) |
| sp01663 | ECU Replacement With Value Transfer | DMM (Doors Management Module) |
| sp01664 | New Actuators | DMM (Doors Management Module) |
| sp01665 | Lock Doors Command | BCM (Body Control Module) |
| sp01666 | Wind Shield Wiper | BCM (Body Control Module) |
| sp01667 | Rear Window Washer Command | BCM (Body Control Module) |
| sp01668 | Unlock Doors Command | BCM (Body Control Module) |
| sp01669 | Rear Window Wiper Command | BCM (Body Control Module) |
| sp01670 | Siren Command | BCM (Body Control Module) |
| sp01671 | ECM Proxi Alignment | ECM (Engine Control Module) |
| sp01672 | Reset Adaptative Parameter | ECM (Engine Control Module) |
| sp01673 | Vehicle Configuration Reset | ECM (Engine Control Module) |
| sp01674 | Self Learning Throttle Body Activation | ECM (Engine Control Module) |

| | | |
|---------|--|--------------------------------------|
| sp01675 | General Stop Actuator | ECM (Engine Control Module) |
| sp01676 | Reset Functions Self Learned | TCM (Transmission Control Module) |
| sp01677 | Disabling All Actuators | TCM (Transmission Control Module) |
| sp01678 | Shutdown Actuators | TCM (Transmission Control Module) |
| sp01679 | Learn Clutches Contact Point | TCM (Transmission Control Module) |
| sp01680 | Quick Learn | TCM (Transmission Control Module) |
| sp01681 | Hydraulic Circuit Depressurization | TCM (Transmission Control Module) |
| sp01682 | Bleed Hydraulic Circuit | TCM (Transmission Control Module) |
| sp01683 | MTA Proxi Configuration | TCM (Transmission Control Module) |
| sp01684 | ECU Replacement With Value Transfer | TCM (Transmission Control Module) |
| sp01685 | New Actuators | TCM (Transmission Control Module) |
| sp01686 | Reset TPMS Calibration | ABS (Anti Lock Brakes) |
| sp01687 | ORC Proxi Alignment | ORC (Occupant Restraint) |
| sp01688 | Reset Parameter. | LTM (Low Telematic Module) |
| sp01689 | Reset Parameter. | ETM (Entertainment Telematic Module) |
| sp01690 | Reset Parameter | ETM (Entertainment Telematic Module) |
| sp01691 | Reset Functions Self Learned | DMM (Doors Management Module) |
| sp01692 | Disabling All Actuators | DMM (Doors Management Module) |
| sp01693 | Shutdown Actuators | DMM (Doors Management Module) |
| sp01694 | Learn Clutches Contact Point | DMM (Doors Management Module) |
| sp01695 | Quick Learn | DMM (Doors Management Module) |
| sp01696 | Hydraulic Circuit Depressurization | DMM (Doors Management Module) |
| sp01697 | Bleed Hydraulic Circuit | DMM (Doors Management Module) |
| sp01698 | MTA Proxi Configuration | DMM (Doors Management Module) |
| sp01699 | ECU Replacement With Value Transfer | DMM (Doors Management Module) |
| sp01700 | New Actuators | DMM (Doors Management Module) |
| sp01701 | Lock Doors Command | BCM (Body Control Module) |
| sp01702 | Wind Shield Wiper | BCM (Body Control Module) |
| sp01703 | Rear Window Washer Command | BCM (Body Control Module) |
| sp01704 | Unlock Doors Command | BCM (Body Control Module) |
| sp01705 | Rear Window Wiper Command | BCM (Body Control Module) |
| sp01706 | Siren Command | BCM (Body Control Module) |
| sp01707 | ECM Proxi Alignment | ECM (Engine Control Module) |
| sp01708 | Reset Adaptative Parameter | ECM (Engine Control Module) |
| sp01709 | Vehicle Configuration Reset | ECM (Engine Control Module) |
| sp01710 | Self Learning Throttle Body Activation | ECM (Engine Control Module) |
| sp01711 | General Stop Actuator | ECM (Engine Control Module) |
| sp01712 | Reset Functions Self Learned | TCM (Transmission Control Module) |
| sp01713 | Disabling All Actuators | TCM (Transmission Control Module) |
| sp01714 | Shutdown Actuators | TCM (Transmission Control Module) |
| sp01715 | Learn Clutches Contact Point | TCM (Transmission Control Module) |
| sp01716 | Quick Learn | TCM (Transmission Control Module) |
| sp01717 | Hydraulic Circuit Depressurization | TCM (Transmission Control Module) |

| | | |
|---------|--|--------------------------------------|
| sp01718 | Bleed Hydraulic Circuit | TCM (Transmission Control Module) |
| sp01719 | MTA Proxi Configuration | TCM (Transmission Control Module) |
| sp01720 | ECU Replacement With Value Transfer | TCM (Transmission Control Module) |
| sp01721 | New Actuators | TCM (Transmission Control Module) |
| sp01722 | Reset TPMS Calibration | ABS (Anti Lock Brakes) |
| sp01723 | ORC Proxi Alignment | ORC (Occupant Restraint) |
| sp01724 | Reset Parameter. | LTM (Low Telematic Module) |
| sp01725 | Reset Parameter. | ETM (Entertainment Telematic Module) |
| sp01726 | Reset Parameter | ETM (Entertainment Telematic Module) |
| sp01727 | Reset Functions Self Learned | DMM (Doors Management Module) |
| sp01728 | Disabling All Actuators | DMM (Doors Management Module) |
| sp01729 | Shutdown Actuators | DMM (Doors Management Module) |
| sp01730 | Learn Clutches Contact Point | DMM (Doors Management Module) |
| sp01731 | Quick Learn | DMM (Doors Management Module) |
| sp01732 | Hydraulic Circuit Depressurization | DMM (Doors Management Module) |
| sp01733 | Bleed Hydraulic Circuit | DMM (Doors Management Module) |
| sp01734 | MTA Proxi Configuration | DMM (Doors Management Module) |
| sp01735 | ECU Replacement With Value Transfer | DMM (Doors Management Module) |
| sp01736 | New Actuators | DMM (Doors Management Module) |
| sp01737 | Lock Doors Command | BCM (Body Control Module) |
| sp01738 | Wind Shield Wiper | BCM (Body Control Module) |
| sp01739 | Rear Window Washer Command | BCM (Body Control Module) |
| sp01740 | Unlock Doors Command | BCM (Body Control Module) |
| sp01741 | Rear Window Wiper Command | BCM (Body Control Module) |
| sp01742 | Siren Command | BCM (Body Control Module) |
| sp01743 | ECM Proxi Alignment | ECM (Engine Control Module) |
| sp01744 | Reset Adaptative Parameter | ECM (Engine Control Module) |
| sp01745 | Vehicle Configuration Reset | ECM (Engine Control Module) |
| sp01746 | Self Learning Throttle Body Activation | ECM (Engine Control Module) |
| sp01747 | General Stop Actuator | ECM (Engine Control Module) |
| sp01748 | Reset Functions Self Learned | TCM (Transmission Control Module) |
| sp01749 | Disabling All Actuators | TCM (Transmission Control Module) |
| sp01750 | Shutdown Actuators | TCM (Transmission Control Module) |
| sp01751 | Learn Clutches Contact Point | TCM (Transmission Control Module) |
| sp01752 | Quick Learn | TCM (Transmission Control Module) |
| sp01753 | Hydraulic Circuit Depressurization | TCM (Transmission Control Module) |
| sp01754 | Bleed Hydraulic Circuit | TCM (Transmission Control Module) |
| sp01755 | MTA Proxi Configuration | TCM (Transmission Control Module) |
| sp01756 | ECU Replacement With Value Transfer | TCM (Transmission Control Module) |
| sp01757 | New Actuators | TCM (Transmission Control Module) |
| sp01758 | Reset TPMS Calibration | ABS (Anti Lock Brakes) |
| sp01759 | ORC Proxi Alignment | ORC (Occupant Restraint) |
| sp01760 | Reset Parameter. | LTM (Low Telematic Module) |

| | | |
|---------|--|--------------------------------------|
| sp01761 | Reset Parameter. | ETM (Entertainment Telematic Module) |
| sp01762 | Reset Parameter | ETM (Entertainment Telematic Module) |
| sp01763 | Reset Functions Self Learned | DMM (Doors Management Module) |
| sp01764 | Disabling All Actuators | DMM (Doors Management Module) |
| sp01765 | Shutdown Actuators | DMM (Doors Management Module) |
| sp01766 | Learn Clutches Contact Point | DMM (Doors Management Module) |
| sp01767 | Quick Learn | DMM (Doors Management Module) |
| sp01768 | Hydraulic Circuit Depressurization | DMM (Doors Management Module) |
| sp01769 | Bleed Hydraulic Circuit | DMM (Doors Management Module) |
| sp01770 | MTA Proxi Configuration | DMM (Doors Management Module) |
| sp01771 | ECU Replacement With Value Transfer | DMM (Doors Management Module) |
| sp01772 | New Actuators | DMM (Doors Management Module) |
| sp01773 | Lock Doors Command | BCM (Body Control Module) |
| sp01774 | Wind Shield Wiper | BCM (Body Control Module) |
| sp01775 | Rear Window Washer Command | BCM (Body Control Module) |
| sp01776 | Unlock Doors Command | BCM (Body Control Module) |
| sp01777 | Rear Window Wiper Command | BCM (Body Control Module) |
| sp01778 | Siren Command | BCM (Body Control Module) |
| sp01779 | ECM Proxi Alignment | ECM (Engine Control Module) |
| sp01780 | Reset Adaptative Parameter | ECM (Engine Control Module) |
| sp01781 | Vehicle Configuration Reset | ECM (Engine Control Module) |
| sp01782 | Self Learning Throttle Body Activation | ECM (Engine Control Module) |
| sp01783 | General Stop Actuator | ECM (Engine Control Module) |
| sp01784 | Reset Functions Self Learned | TCM (Transmission Control Module) |
| sp01785 | Disabling All Actuators | TCM (Transmission Control Module) |
| sp01786 | Shutdown Actuators | TCM (Transmission Control Module) |
| sp01787 | Learn Clutches Contact Point | TCM (Transmission Control Module) |
| sp01788 | Quick Learn | TCM (Transmission Control Module) |
| sp01789 | Hydraulic Circuit Depressurization | TCM (Transmission Control Module) |
| sp01790 | Bleed Hydraulic Circuit | TCM (Transmission Control Module) |
| sp01791 | MTA Proxi Configuration | TCM (Transmission Control Module) |
| sp01792 | ECU Replacement With Value Transfer | TCM (Transmission Control Module) |
| sp01793 | New Actuators | TCM (Transmission Control Module) |
| sp01794 | Reset TPMS Calibration | ABS (Anti Lock Brakes) |
| sp01795 | ORC Proxi Alignment | ORC (Occupant Restraint) |
| sp01796 | Reset Parameter. | LTM (Low Telematic Module) |
| sp01797 | Reset Parameter. | ETM (Entertainment Telematic Module) |
| sp01798 | Reset Parameter | ETM (Entertainment Telematic Module) |
| sp01799 | Reset Functions Self Learned | DMM (Doors Management Module) |
| sp01800 | Disabling All Actuators | DMM (Doors Management Module) |
| sp01801 | Shutdown Actuators | DMM (Doors Management Module) |
| sp01802 | Learn Clutches Contact Point | DMM (Doors Management Module) |
| sp01803 | Quick Learn | DMM (Doors Management Module) |

| | | |
|---------|--|---|
| sp01804 | Hydraulic Circuit Depressurization | DMM (Doors Management Module) |
| sp01805 | Bleed Hydraulic Circuit | DMM (Doors Management Module) |
| sp01806 | MTA Proxi Configuration | DMM (Doors Management Module) |
| sp01807 | ECU Replacement With Value Transfer | DMM (Doors Management Module) |
| sp01808 | New Actuators | DMM (Doors Management Module) |
| sp01809 | Lock Doors Command | BCM (Body Control Module) |
| sp01810 | Wind Shield Wiper | BCM (Body Control Module) |
| sp01811 | Rear Window Washer Command | BCM (Body Control Module) |
| sp01812 | Unlock Doors Command | BCM (Body Control Module) |
| sp01813 | Rear Window Wiper Command | BCM (Body Control Module) |
| sp01814 | Siren Command | BCM (Body Control Module) |
| sp01815 | Impone AF Gasoline | ECM (Engine Control Module) |
| sp01816 | Impone AF Learning | ECM (Engine Control Module) |
| sp01817 | ECM Proxi Alignment | ECM (Engine Control Module) |
| sp01818 | Vehicle Configuration Reset | ECM (Engine Control Module) |
| sp01819 | Self Learning Throttle Body Activation | ECM (Engine Control Module) |
| sp01820 | General Stop Actuator | ECM (Engine Control Module) |
| sp01821 | Impone AF Alcool | ECM (Engine Control Module) |
| sp01822 | Fuel Circuit Purge | ECM (Engine Control Module) |
| sp01823 | Purge Fuel Circuit Reset | ECM (Engine Control Module) |
| sp01824 | Clutch Pedal Learning | ECM (Engine Control Module) |
| sp01825 | Reset Adaptative Parameter | ECM (Engine Control Module) |
| sp01826 | Reset Functions Self Learned | TCM (Transmission Control Module) |
| sp01827 | Disabling All Actuators | TCM (Transmission Control Module) |
| sp01828 | Shutdown Actuators | TCM (Transmission Control Module) |
| sp01829 | Learn Clutches Contact Point | TCM (Transmission Control Module) |
| sp01830 | Quick Learn | TCM (Transmission Control Module) |
| sp01831 | Hydraulic Circuit Depressurization | TCM (Transmission Control Module) |
| sp01832 | Bleed Hydraulic Circuit | TCM (Transmission Control Module) |
| sp01833 | MTA Proxi Configuration | TCM (Transmission Control Module) |
| sp01834 | ECU Replacement With Value Transfer | TCM (Transmission Control Module) |
| sp01835 | New Actuators | TCM (Transmission Control Module) |
| sp01836 | Reset TPMS Calibration | ABS (Anti-Lock Braking System) |
| sp01837 | ORC Proxi Alignment | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01838 | Lock Doors Command | BCM (Body Control Module) |
| sp01839 | Wind Shield Wiper | BCM (Body Control Module) |
| sp01840 | Rear Window Washer Command | BCM (Body Control Module) |
| sp01841 | Unlock Doors Command | BCM (Body Control Module) |
| sp01842 | Rear Window Wiper Command | BCM (Body Control Module) |
| sp01843 | Siren Command | BCM (Body Control Module) |
| sp01844 | Reset Functions Self Learned | DMM (Doors Management Module) |
| sp01845 | Disabling All Actuators | DMM (Doors Management Module) |
| sp01846 | Shutdown Actuators | DMM (Doors Management Module) |

| | | |
|---------|--|---|
| sp01847 | Learn Clutches Contact Point | DMM (Doors Management Module) |
| sp01848 | Quick Learn | DMM (Doors Management Module) |
| sp01849 | Hydraulic Circuit Depressurization | DMM (Doors Management Module) |
| sp01850 | Bleed Hydraulic Circuit | DMM (Doors Management Module) |
| sp01851 | MTA Proxi Configuration | DMM (Doors Management Module) |
| sp01852 | ECU Replacement With Value Transfer | DMM (Doors Management Module) |
| sp01853 | New Actuators | DMM (Doors Management Module) |
| sp01854 | Impone AF Gasoline | ECM (Engine Control Module) |
| sp01855 | Impone AF Learning | ECM (Engine Control Module) |
| sp01856 | ECM Proxi Alignment | ECM (Engine Control Module) |
| sp01857 | Vehicle Configuration Reset | ECM (Engine Control Module) |
| sp01858 | Self Learning Throttle Body Activation | ECM (Engine Control Module) |
| sp01859 | General Stop Actuator | ECM (Engine Control Module) |
| sp01860 | Impone AF Alcool | ECM (Engine Control Module) |
| sp01861 | Fuel Circuit Purge | ECM (Engine Control Module) |
| sp01862 | Purge Fuel Circuit Reset | ECM (Engine Control Module) |
| sp01863 | Clutch Pedal Learning | ECM (Engine Control Module) |
| sp01864 | Reset Adaptative Parameter | ECM (Engine Control Module) |
| sp01865 | Reset Functions Self Learned | TCM (Transmission Control Module) |
| sp01866 | Disabling All Actuators | TCM (Transmission Control Module) |
| sp01867 | Shutdown Actuators | TCM (Transmission Control Module) |
| sp01868 | Learn Clutches Contact Point | TCM (Transmission Control Module) |
| sp01869 | Quick Learn | TCM (Transmission Control Module) |
| sp01870 | Hydraulic Circuit Depressurization | TCM (Transmission Control Module) |
| sp01871 | Bleed Hydraulic Circuit | TCM (Transmission Control Module) |
| sp01872 | MTA Proxi Configuration | TCM (Transmission Control Module) |
| sp01873 | ECU Replacement With Value Transfer | TCM (Transmission Control Module) |
| sp01874 | New Actuators | TCM (Transmission Control Module) |
| sp01875 | Reset TPMS Calibration | ABS (Anti-Lock Braking System) |
| sp01876 | ORC Proxi Alignment | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01877 | Lock Doors Command | BCM (Body Control Module) |
| sp01878 | Wind Shield Wiper | BCM (Body Control Module) |
| sp01879 | Rear Window Washer Command | BCM (Body Control Module) |
| sp01880 | Unlock Doors Command | BCM (Body Control Module) |
| sp01881 | Rear Window Wiper Command | BCM (Body Control Module) |
| sp01882 | Siren Command | BCM (Body Control Module) |
| sp01883 | Reset Functions Self Learned | DMM (Doors Management Module) |
| sp01884 | Disabling All Actuators | DMM (Doors Management Module) |
| sp01885 | Shutdown Actuators | DMM (Doors Management Module) |
| sp01886 | Learn Clutches Contact Point | DMM (Doors Management Module) |
| sp01887 | Quick Learn | DMM (Doors Management Module) |
| sp01888 | Hydraulic Circuit Depressurization | DMM (Doors Management Module) |
| sp01889 | Bleed Hydraulic Circuit | DMM (Doors Management Module) |

| | | |
|---------|--|---|
| sp01890 | MTA Proxi Configuration | DMM (Doors Management Module) |
| sp01891 | ECU Replacement With Value Transfer | DMM (Doors Management Module) |
| sp01892 | New Actuators | DMM (Doors Management Module) |
| sp01893 | Impone AF Gasoline | ECM (Engine Control Module) |
| sp01894 | Impone AF Learning | ECM (Engine Control Module) |
| sp01895 | ECM Proxi Alignment | ECM (Engine Control Module) |
| sp01896 | Vehicle Configuration Reset | ECM (Engine Control Module) |
| sp01897 | Self Learning Throttle Body Activation | ECM (Engine Control Module) |
| sp01898 | General Stop Actuator | ECM (Engine Control Module) |
| sp01899 | Impone AF Alcool | ECM (Engine Control Module) |
| sp01900 | Fuel Circuit Purge | ECM (Engine Control Module) |
| sp01901 | Purge Fuel Circuit Reset | ECM (Engine Control Module) |
| sp01902 | Clutch Pedal Learning | ECM (Engine Control Module) |
| sp01903 | Reset Adaptative Parameter | ECM (Engine Control Module) |
| sp01904 | Reset Functions Self Learned | TCM (Transmission Control Module) |
| sp01905 | Disabling All Actuators | TCM (Transmission Control Module) |
| sp01906 | Shutdown Actuators | TCM (Transmission Control Module) |
| sp01907 | Learn Clutches Contact Point | TCM (Transmission Control Module) |
| sp01908 | Quick Learn | TCM (Transmission Control Module) |
| sp01909 | Hydraulic Circuit Depressurization | TCM (Transmission Control Module) |
| sp01910 | Bleed Hydraulic Circuit | TCM (Transmission Control Module) |
| sp01911 | MTA Proxi Configuration | TCM (Transmission Control Module) |
| sp01912 | ECU Replacement With Value Transfer | TCM (Transmission Control Module) |
| sp01913 | New Actuators | TCM (Transmission Control Module) |
| sp01914 | Reset TPMS Calibration | ABS (Anti-Lock Braking System) |
| sp01915 | ORC Proxi Alignment | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01916 | Lock Doors Command | BCM (Body Control Module) |
| sp01917 | Wind Shield Wiper | BCM (Body Control Module) |
| sp01918 | Rear Window Washer Command | BCM (Body Control Module) |
| sp01919 | Unlock Doors Command | BCM (Body Control Module) |
| sp01920 | Rear Window Wiper Command | BCM (Body Control Module) |
| sp01921 | Siren Command | BCM (Body Control Module) |
| sp01922 | Reset Functions Self Learned | DMM (Doors Management Module) |
| sp01923 | Disabling All Actuators | DMM (Doors Management Module) |
| sp01924 | Shutdown Actuators | DMM (Doors Management Module) |
| sp01925 | Learn Clutches Contact Point | DMM (Doors Management Module) |
| sp01926 | Quick Learn | DMM (Doors Management Module) |
| sp01927 | Hydraulic Circuit Depressurization | DMM (Doors Management Module) |
| sp01928 | Bleed Hydraulic Circuit | DMM (Doors Management Module) |
| sp01929 | MTA Proxi Configuration | DMM (Doors Management Module) |
| sp01930 | ECU Replacement With Value Transfer | DMM (Doors Management Module) |
| sp01931 | New Actuators | DMM (Doors Management Module) |
| sp01932 | Impone AF Gasoline | ECM (Engine Control Module) |

| | | |
|---------|--|---|
| sp01933 | Impone AF Learning | ECM (Engine Control Module) |
| sp01934 | ECM Proxi Alignment | ECM (Engine Control Module) |
| sp01935 | Vehicle Configuration Reset | ECM (Engine Control Module) |
| sp01936 | Self Learning Throttle Body Activation | ECM (Engine Control Module) |
| sp01937 | General Stop Actuator | ECM (Engine Control Module) |
| sp01938 | Impone AF Alcool | ECM (Engine Control Module) |
| sp01939 | Fuel Circuit Purge | ECM (Engine Control Module) |
| sp01940 | Purge Fuel Circuit Reset | ECM (Engine Control Module) |
| sp01941 | Clutch Pedal Learning | ECM (Engine Control Module) |
| sp01942 | Reset Adaptative Parameter | ECM (Engine Control Module) |
| sp01943 | Reset Functions Self Learned | TCM (Transmission Control Module) |
| sp01944 | Disabling All Actuators | TCM (Transmission Control Module) |
| sp01945 | Shutdown Actuators | TCM (Transmission Control Module) |
| sp01946 | Learn Clutches Contact Point | TCM (Transmission Control Module) |
| sp01947 | Quick Learn | TCM (Transmission Control Module) |
| sp01948 | Hydraulic Circuit Depressurization | TCM (Transmission Control Module) |
| sp01949 | Bleed Hydraulic Circuit | TCM (Transmission Control Module) |
| sp01950 | MTA Proxi Configuration | TCM (Transmission Control Module) |
| sp01951 | ECU Replacement With Value Transfer | TCM (Transmission Control Module) |
| sp01952 | New Actuators | TCM (Transmission Control Module) |
| sp01953 | Reset TPMS Calibration | ABS (Anti-Lock Braking System) |
| sp01954 | ORC Proxi Alignment | SRS (Supplemental Inflatable Restraint System, ORC) |
| sp01955 | Lock Doors Command | BCM (Body Control Module) |
| sp01956 | Wind Shield Wiper | BCM (Body Control Module) |
| sp01957 | Rear Window Washer Command | BCM (Body Control Module) |
| sp01958 | Unlock Doors Command | BCM (Body Control Module) |
| sp01959 | Rear Window Wiper Command | BCM (Body Control Module) |
| sp01960 | Siren Command | BCM (Body Control Module) |
| sp01961 | Reset Functions Self Learned | DMM (Doors Management Module) |
| sp01962 | Disabling All Actuators | DMM (Doors Management Module) |
| sp01963 | Shutdown Actuators | DMM (Doors Management Module) |
| sp01964 | Learn Clutches Contact Point | DMM (Doors Management Module) |
| sp01965 | Quick Learn | DMM (Doors Management Module) |
| sp01966 | Hydraulic Circuit Depressurization | DMM (Doors Management Module) |
| sp01967 | Bleed Hydraulic Circuit | DMM (Doors Management Module) |
| sp01968 | MTA Proxi Configuration | DMM (Doors Management Module) |
| sp01969 | ECU Replacement With Value Transfer | DMM (Doors Management Module) |
| sp01970 | New Actuators | DMM (Doors Management Module) |
| sp01971 | Impone AF Gasoline | ECM (Engine Control Module) |
| sp01972 | Impone AF Learning | ECM (Engine Control Module) |
| sp01973 | ECM Proxi Alignment | ECM (Engine Control Module) |
| sp01974 | Vehicle Configuration Reset | ECM (Engine Control Module) |
| sp01975 | Self Learning Throttle Body Activation | ECM (Engine Control Module) |

| | | |
|---------|---|-----------------------------------|
| sp01976 | General Stop Actuator | ECM (Engine Control Module) |
| sp01977 | Impone AF Alcool | ECM (Engine Control Module) |
| sp01978 | Fuel Circuit Purge | ECM (Engine Control Module) |
| sp01979 | Purge Fuel Circuit Reset | ECM (Engine Control Module) |
| sp01980 | Clutch Pedal Learning | ECM (Engine Control Module) |
| sp01981 | Reset Adaptative Parameter | ECM (Engine Control Module) |
| sp01982 | Reset Functions Self Learned | TCM (Transmission Control Module) |
| sp01983 | Disabling All Actuators | TCM (Transmission Control Module) |
| sp01984 | Shutdown Actuators | TCM (Transmission Control Module) |
| sp01985 | Learn Clutches Contact Point | TCM (Transmission Control Module) |
| sp01986 | Quick Learn | TCM (Transmission Control Module) |
| sp01987 | Hydraulic Circuit Depressurization | TCM (Transmission Control Module) |
| sp01988 | Bleed Hydraulic Circuit | TCM (Transmission Control Module) |
| sp01989 | MTA Proxi Configuration | TCM (Transmission Control Module) |
| sp01990 | ECU Replacement With Value Transfer | TCM (Transmission Control Module) |
| sp01991 | New Actuators | TCM (Transmission Control Module) |
| sp01992 | Reset TPMS Calibration | ABS (Anti Lock Brakes) |
| sp01993 | ORC Proxi Alignment | ORC (Occupant Restraint) |
| sp01994 | Reset Functions Self Learned | DMM (Doors Management Module) |
| sp01995 | Disabling All Actuators | DMM (Doors Management Module) |
| sp01996 | Shutdown Actuators | DMM (Doors Management Module) |
| sp01997 | Learn Clutches Contact Point | DMM (Doors Management Module) |
| sp01998 | Quick Learn | DMM (Doors Management Module) |
| sp01999 | Hydraulic Circuit Depressurization | DMM (Doors Management Module) |
| sp02000 | Bleed Hydraulic Circuit | DMM (Doors Management Module) |
| sp02001 | MTA Proxi Configuration | DMM (Doors Management Module) |
| sp02002 | ECU Replacement With Value Transfer | DMM (Doors Management Module) |
| sp02003 | New Actuators | DMM (Doors Management Module) |
| sp02004 | Lock Doors Command | BCM (Body Control Module) |
| sp02005 | Wind Shield Wiper | BCM (Body Control Module) |
| sp02006 | Rear Window Washer Command | BCM (Body Control Module) |
| sp02007 | Unlock Doors Command | BCM (Body Control Module) |
| sp02008 | Rear Window Wiper Command | BCM (Body Control Module) |
| sp02009 | Siren Command | BCM (Body Control Module) |
| sp02010 | Deactivation Of The Power Limitation Function | ECM (Engine Control Module) |
| sp02011 | Fan Cooling Activation | ECM (Engine Control Module) |
| sp02012 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp02013 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp02014 | Gearbox Replacement | TCM (Transmission Control Module) |
| sp02015 | Lever Release Solenoid Command | TCM (Transmission Control Module) |
| sp02016 | Static Test | ABS (Anti-Lock Braking System) |
| sp02017 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp02018 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |

| | | |
|---------|---|---|
| sp02019 | Reset Odometer | IC (Instrument Cluster) |
| sp02020 | Reset Service Information | IC (Instrument Cluster) |
| sp02021 | Disable Seat Belts Reminder | IC (Instrument Cluster) |
| sp02022 | Enable Seat Belts Reminder | IC (Instrument Cluster) |
| sp02023 | Last Service Date | IC (Instrument Cluster) |
| sp02024 | Actuator Calibration Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp02025 | Fire Protection System Activate | BCM (Body Control Module) |
| sp02026 | Deactivation Of The Power Limitation Function | ECM (Engine Control Module) |
| sp02027 | Fan Cooling Activation | ECM (Engine Control Module) |
| sp02028 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |
| sp02029 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp02030 | Gearbox Replacement | TCM (Transmission Control Module) |
| sp02031 | Lever Release Solenoid Command | TCM (Transmission Control Module) |
| sp02032 | Static Test | ABS (Anti-Lock Braking System) |
| sp02033 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp02034 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp02035 | Reset Odometer | IC (Instrument Cluster) |
| sp02036 | Reset Service Information | IC (Instrument Cluster) |
| sp02037 | Disable Seat Belts Reminder | IC (Instrument Cluster) |
| sp02038 | Enable Seat Belts Reminder | IC (Instrument Cluster) |
| sp02039 | Last Service Date | IC (Instrument Cluster) |
| sp02040 | Actuator Calibration Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp02041 | Fire Protection System Activate | BCM (Body Control Module) |
| sp02042 | Fire Protection System Activate | BCM (Body Control Module) |
| sp02043 | Reset Adaptative Parameters | PCM (Powertrain Control Module) |
| sp02044 | Reset Phases Front | PCM (Powertrain Control Module) |
| sp02045 | Self Learning Throttle Body | PCM (Powertrain Control Module) |
| sp02046 | Tunnel Lever Replacement | TCM (Transmission Control Module) |
| sp02047 | Pump Relay Replacement | TCM (Transmission Control Module) |
| sp02048 | Self-Learnt Functions Reset | TCM (Transmission Control Module) |
| sp02049 | Static Test | ABS (Anti-Lock Braking System) |
| sp02050 | Enable Tow Hook Presence | PTS (Parktronics) |
| sp02051 | Disable Tow Hook Presence | PTS (Parktronics) |
| sp02052 | Reset Odometer | IC (Instrument Cluster) |
| sp02053 | Reset Service Information | IC (Instrument Cluster) |
| sp02054 | Disable Seat Belts Reminder | IC (Instrument Cluster) |
| sp02055 | Last Service Date | IC (Instrument Cluster) |
| sp02056 | Enable Seat Belts Reminder | IC (Instrument Cluster) |
| sp02057 | Flap Actuators Learning Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp02058 | Injector Codes Read | ECM (Engine Control Module) |
| sp02059 | Rail Pressure Sensor Replacement | ECM (Engine Control Module) |
| sp02060 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp02061 | Replacement Lambda Sensor | ECM (Engine Control Module) |

| | | |
|---------|---|---|
| sp02062 | Cylinder 1 Injector Replacement | ECM (Engine Control Module) |
| sp02063 | Cylinder 2 Injector Replacement | ECM (Engine Control Module) |
| sp02064 | Cylinder 3 Injector Replacement | ECM (Engine Control Module) |
| sp02065 | Injector Replacement (Per Bank) | ECM (Engine Control Module) |
| sp02066 | Rail Pressure Sensor And Injector/S Replacement | ECM (Engine Control Module) |
| sp02067 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp02068 | Tunnel Lever Replacement | TCM (Transmission Control Module) |
| sp02069 | Levers At Wheel Replacement | TCM (Transmission Control Module) |
| sp02070 | Pump Relay Replacement | TCM (Transmission Control Module) |
| sp02071 | Self-Learnt Functions Reset | TCM (Transmission Control Module) |
| sp02072 | Longitudinal And Lateral Sensor Decalibration | ABS (Anti-Lock Braking System) |
| sp02073 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp02074 | Static Test | ABS (Anti-Lock Braking System) |
| sp02075 | Alarms Deletion | TPMS (Tire Pressure Monitoring System) |
| sp02076 | Antenna Replacement | TPMS (Tire Pressure Monitoring System) |
| sp02077 | Control Unit Activation | TPMS (Tire Pressure Monitoring System) |
| sp02078 | Control Unit Deactivation | TPMS (Tire Pressure Monitoring System) |
| sp02079 | Manual System Configuration | TPMS (Tire Pressure Monitoring System) |
| sp02080 | Automatic Configuration Read | TPMS (Tire Pressure Monitoring System) |
| sp02081 | Wheel Transmitters Learning | TPMS (Tire Pressure Monitoring System) |
| sp02082 | Automatic Configuration Write | TPMS (Tire Pressure Monitoring System) |
| sp02083 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp02084 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp02085 | Enable Seat Belts Reminder | IC (Instrument Cluster) |
| sp02086 | Disable Seat Belts Reminder | IC (Instrument Cluster) |
| sp02087 | Reset Odometer | IC (Instrument Cluster) |
| sp02088 | Reset Service Information | IC (Instrument Cluster) |
| sp02089 | Last Service Date | IC (Instrument Cluster) |
| sp02090 | Self Learning Motor Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp02091 | ECU Restart Routine | CTM (Convergence Telematic Module) |
| sp02092 | Fire Protection System Activate | BCM (Body Control Module) |
| sp02093 | Differential Pressure Sensor Replac. | ECM (Engine Control Module) |
| sp02094 | Oil Change | ECM (Engine Control Module) |
| sp02095 | Injector Replacement (Per Bank) | ECM (Engine Control Module) |
| sp02096 | Injector Codes Read | ECM (Engine Control Module) |
| sp02097 | Rail Pressure Sensor Replacement | ECM (Engine Control Module) |
| sp02098 | Cylinder 3 Injector Replacement | ECM (Engine Control Module) |
| sp02099 | Cylinder 2 Injector Replacement | ECM (Engine Control Module) |
| sp02100 | Cylinder 1 Injector Replacement | ECM (Engine Control Module) |
| sp02101 | Phonic Wheel Replacement | ECM (Engine Control Module) |
| sp02102 | Replacement Lambda Sensor | ECM (Engine Control Module) |
| sp02103 | Neutral Signal Learn | ECM (Engine Control Module) |
| sp02104 | EGR Valve Test | ECM (Engine Control Module) |

| | | |
|---------|---|------------------------------------|
| sp02105 | Glow Plug Preheating Circuit Test | ECM (Engine Control Module) |
| sp02106 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp02107 | Resetting Distance Travelled With Water In Diesel W.Lamp ON | ECM (Engine Control Module) |
| sp02108 | Throttle Valve Test | ECM (Engine Control Module) |
| sp02109 | Resetting Distance Travelled With Water Temperature Warning Lamp ON | ECM (Engine Control Module) |
| sp02110 | Fan Cooling Activation | ECM (Engine Control Module) |
| sp02111 | Speed Limit Setting | ECM (Engine Control Module) |
| sp02112 | Tunnel Lever Replacement | TCM (Transmission Control Module) |
| sp02113 | Pump Relay Replacement | TCM (Transmission Control Module) |
| sp02114 | Self-Learnt Functions Reset | TCM (Transmission Control Module) |
| sp02115 | Longitudinal And Lateral Sensor Decalibration | ABS (Anti-Lock Braking System) |
| sp02116 | Longitudinal And Lateral Sensor Calibration | ABS (Anti-Lock Braking System) |
| sp02117 | Static Test | ABS (Anti-Lock Braking System) |
| sp02118 | Reset Odometer | IC (Instrument Cluster) |
| sp02119 | Enable Seat Belts Reminder | IC (Instrument Cluster) |
| sp02120 | Disable Seat Belts Reminder | IC (Instrument Cluster) |
| sp02121 | ECU Restart Routine | CTM (Convergence Telematic Module) |
| sp02122 | Trailer Hook Presence Disabling | AHM (Additional Heater Module) |
| sp02123 | Trailer Hook Presence Enabling | AHM (Additional Heater Module) |
| sp02124 | Fuel Circuit Purge | ECM (Engine Control Module) |
| sp02125 | General Stop Actuator | ECM (Engine Control Module) |
| sp02126 | Reset Adaptative Parameter | ECM (Engine Control Module) |
| sp02127 | Reset Purge Fuel Circuit | ECM (Engine Control Module) |
| sp02128 | Reset Phonic Wheel Tooth Learn | ECM (Engine Control Module) |
| sp02129 | Reset Camshaft Adaptative | ECM (Engine Control Module) |
| sp02130 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp02131 | Clear TPM Sensor Audit | RFH (Radio Frequency Hub) |
| sp02132 | Clear TPM Sensor Warnings | RFH (Radio Frequency Hub) |
| sp02133 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp02134 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp02135 | Reset Odometer | IPC (Instrument Panel Cluster) |
| sp02136 | Self Learning Motors Test | HVAC (Heat, Ventilation And A/C) |
| sp02137 | Service Single Pole Calibration | HALF (Haptical Lane Feedback) |
| sp02138 | Proxi Alignment Procedure | ESM (Electronic Shifter Module) |
| sp02139 | Factory VIN code lock | ESM (Electronic Shifter Module) |
| sp02140 | Driver Mirror Axis X Command | DMM (Doors Management Module) |
| sp02141 | Driver Mirror Axis Y Command | DMM (Doors Management Module) |
| sp02142 | Fire Protection System Activate | BCM (Body Control Module) |
| sp02143 | Lock Doors Command | BCM (Body Control Module) |
| sp02144 | Unlock Doors Command | BCM (Body Control Module) |
| sp02145 | Check Siren | BCM (Body Control Module) |
| sp02146 | Siren Command | BCM (Body Control Module) |
| sp02147 | Cargo Unlock Relay | BCM (Body Control Module) |

| | | |
|---------|---------------------------------|----------------------------------|
| sp02148 | Cargo Lock Relay | BCM (Body Control Module) |
| sp02149 | Fuel Circuit Purge | ECM (Engine Control Module) |
| sp02150 | General Stop Actuator | ECM (Engine Control Module) |
| sp02151 | Reset Adaptive Parameter | ECM (Engine Control Module) |
| sp02152 | Reset Purge Fuel Circuit | ECM (Engine Control Module) |
| sp02153 | Reset Phonic Wheel Tooth Learn | ECM (Engine Control Module) |
| sp02154 | Reset Camshaft Adaptive | ECM (Engine Control Module) |
| sp02155 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp02156 | Clear TPM Sensor Audit | RFH (Radio Frequency Hub) |
| sp02157 | Clear TPM Sensor Warnings | RFH (Radio Frequency Hub) |
| sp02158 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp02159 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp02160 | Reset Odometer | IPC (Instrument Panel Cluster) |
| sp02161 | Self Learning Motors Test | HVAC (Heat, Ventilation And A/C) |
| sp02162 | Service Single Pole Calibration | HALF (Haptical Lane Feedback) |
| sp02163 | Proxi Alignment Procedure | ESM (Electronic Shifter Module) |
| sp02164 | Factory VIN code lock | ESM (Electronic Shifter Module) |
| sp02165 | Driver Mirror Axis X Command | DMM (Doors Management Module) |
| sp02166 | Driver Mirror Axis Y Command | DMM (Doors Management Module) |
| sp02167 | Fire Protection System Activate | BCM (Body Control Module) |
| sp02168 | Lock Doors Command | BCM (Body Control Module) |
| sp02169 | Unlock Doors Command | BCM (Body Control Module) |
| sp02170 | Check Siren | BCM (Body Control Module) |
| sp02171 | Siren Command | BCM (Body Control Module) |
| sp02172 | Cargo Unlock Relay | BCM (Body Control Module) |
| sp02173 | Cargo Lock Relay | BCM (Body Control Module) |
| sp02174 | Fuel Circuit Purge | ECM (Engine Control Module) |
| sp02175 | General Stop Actuator | ECM (Engine Control Module) |
| sp02176 | Reset Adaptive Parameter | ECM (Engine Control Module) |
| sp02177 | Reset Purge Fuel Circuit | ECM (Engine Control Module) |
| sp02178 | Reset Phonic Wheel Tooth Learn | ECM (Engine Control Module) |
| sp02179 | Reset Camshaft Adaptive | ECM (Engine Control Module) |
| sp02180 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp02181 | Clear TPM Sensor Audit | RFH (Radio Frequency Hub) |
| sp02182 | Clear TPM Sensor Warnings | RFH (Radio Frequency Hub) |
| sp02183 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp02184 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp02185 | Reset Odometer | IPC (Instrument Panel Cluster) |
| sp02186 | Self Learning Motors Test | HVAC (Heat, Ventilation And A/C) |
| sp02187 | Service Single Pole Calibration | HALF (Haptical Lane Feedback) |
| sp02188 | Proxi Alignment Procedure | ESM (Electronic Shifter Module) |
| sp02189 | Factory VIN code lock | ESM (Electronic Shifter Module) |
| sp02190 | Driver Mirror Axis X Command | DMM (Doors Management Module) |

| | | |
|---------|---------------------------------|----------------------------------|
| sp02191 | Driver Mirror Axis Y Command | DMM (Doors Management Module) |
| sp02192 | Fire Protection System Activate | BCM (Body Control Module) |
| sp02193 | Lock Doors Command | BCM (Body Control Module) |
| sp02194 | Unlock Doors Command | BCM (Body Control Module) |
| sp02195 | Check Siren | BCM (Body Control Module) |
| sp02196 | Siren Command | BCM (Body Control Module) |
| sp02197 | Cargo Unlock Relay | BCM (Body Control Module) |
| sp02198 | Cargo Lock Relay | BCM (Body Control Module) |
| sp02199 | Fuel Circuit Purge | ECM (Engine Control Module) |
| sp02200 | General Stop Actuator | ECM (Engine Control Module) |
| sp02201 | Reset Adaptive Parameter | ECM (Engine Control Module) |
| sp02202 | Reset Purge Fuel Circuit | ECM (Engine Control Module) |
| sp02203 | Reset Phonic Wheel Tooth Learn | ECM (Engine Control Module) |
| sp02204 | Reset Camshaft Adaptive | ECM (Engine Control Module) |
| sp02205 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp02206 | Clear TPM Sensor Audit | RFH (Radio Frequency Hub) |
| sp02207 | Clear TPM Sensor Warnings | RFH (Radio Frequency Hub) |
| sp02208 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp02209 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp02210 | Reset Odometer | IPC (Instrument Panel Cluster) |
| sp02211 | Self Learning Motors Test | HVAC (Heat, Ventilation And A/C) |
| sp02212 | Service Single Pole Calibration | HALF (Haptical Lane Feedback) |
| sp02213 | Proxi Alignment Procedure | ESM (Electronic Shifter Module) |
| sp02214 | Factory VIN code lock | ESM (Electronic Shifter Module) |
| sp02215 | Driver Mirror Axis X Command | DMM (Doors Management Module) |
| sp02216 | Driver Mirror Axis Y Command | DMM (Doors Management Module) |
| sp02217 | Fire Protection System Activate | BCM (Body Control Module) |
| sp02218 | Lock Doors Command | BCM (Body Control Module) |
| sp02219 | Unlock Doors Command | BCM (Body Control Module) |
| sp02220 | Check Siren | BCM (Body Control Module) |
| sp02221 | Siren Command | BCM (Body Control Module) |
| sp02222 | Cargo Unlock Relay | BCM (Body Control Module) |
| sp02223 | Cargo Lock Relay | BCM (Body Control Module) |
| sp02224 | Fuel Circuit Purge | ECM (Engine Control Module) |
| sp02225 | General Stop Actuator | ECM (Engine Control Module) |
| sp02226 | Reset Adaptive Parameter | ECM (Engine Control Module) |
| sp02227 | Reset Purge Fuel Circuit | ECM (Engine Control Module) |
| sp02228 | Reset Phonic Wheel Tooth Learn | ECM (Engine Control Module) |
| sp02229 | Reset Camshaft Adaptive | ECM (Engine Control Module) |
| sp02230 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp02231 | Clear TPM Sensor Audit | RFH (Radio Frequency Hub) |
| sp02232 | Clear TPM Sensor Warnings | RFH (Radio Frequency Hub) |
| sp02233 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |

| | | |
|---------|---|---|
| sp02234 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp02235 | Reset Odometer | IPC (Instrument Panel Cluster) |
| sp02236 | Self Learning Motors Test | HVAC (Heat, Ventilation And A/C) |
| sp02237 | Service Single Pole Calibration | HALF (Haptical Lane Feedback) |
| sp02238 | Proxi Alignment Procedure | ESM (Electronic Shifter Module) |
| sp02239 | Factory VIN code lock | ESM (Electronic Shifter Module) |
| sp02240 | Driver Mirror Axis X Command | DMM (Doors Management Module) |
| sp02241 | Driver Mirror Axis Y Command | DMM (Doors Management Module) |
| sp02242 | Fire Protection System Activate | BCM (Body Control Module) |
| sp02243 | Lock Doors Command | BCM (Body Control Module) |
| sp02244 | Unlock Doors Command | BCM (Body Control Module) |
| sp02245 | Check Siren | BCM (Body Control Module) |
| sp02246 | Siren Command | BCM (Body Control Module) |
| sp02247 | Cargo Unlock Relay | BCM (Body Control Module) |
| sp02248 | Cargo Lock Relay | BCM (Body Control Module) |
| sp02249 | Fuel Circuit Purge | ECM (Engine Control Module) |
| sp02250 | General Stop Actuator | ECM (Engine Control Module) |
| sp02251 | Reset Adaptative Parameter | ECM (Engine Control Module) |
| sp02252 | Reset Purge Fuel Circuit | ECM (Engine Control Module) |
| sp02253 | Reset Phonic Wheel Tooth Learn | ECM (Engine Control Module) |
| sp02254 | Reset Camshaft Adaptative | ECM (Engine Control Module) |
| sp02255 | Clear Self Learning Data | TCM (Transmission Control Module) |
| sp02256 | Neutral Position Self-Learning | TCM (Transmission Control Module) |
| sp02257 | Exit Shipping Mode | BCM (Body Control Module) |
| sp02258 | Lock Doors Command | BCM (Body Control Module) |
| sp02259 | Unlock Doors Command | BCM (Body Control Module) |
| sp02260 | Siren Command | BCM (Body Control Module) |
| sp02261 | Fire Protection System Activate | BCM (Body Control Module) |
| sp02262 | Reset Service Information | IC (Instrument Cluster) |
| sp02263 | Clear TPM Sensor Audit | RFH (Radio Frequency Hub) |
| sp02264 | Clear TPM Sensor Warnings | RFH (Radio Frequency Hub) |
| sp02265 | Service Single Pole Calibration | HALF (Haptical Lane Feedback) |
| sp02266 | Driver Mirror Axis X Command | DMM (Doors Management Module) |
| sp02267 | Driver Mirror Axis Y Command | DMM (Doors Management Module) |
| sp02268 | Steering Angle Sensor | EPS (Electric Power Steering) |
| sp02269 | Trailer Hook Presence Disabling | PAM (Parking Assistant Module) |
| sp02270 | Trailer Hook Presence Enabling | PAM (Parking Assistant Module) |
| sp02271 | Self Learning Motors Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp02272 | Proxi Alignment Procedure | ESM (Electronic Shifter Module) |
| sp02273 | Factory VIN code lock | ESM (Electronic Shifter Module) |
| sp02274 | Deactivation Of The Power Limitation Function | ECM (Engine Control Module) |
| sp02275 | Fan Cooling Activation | ECM (Engine Control Module) |
| sp02276 | Self-Adaptive Parameters Reset | ECM (Engine Control Module) |

| | | |
|---------|--|---|
| sp02277 | Self-Learnt Functions Reset | ECM (Engine Control Module) |
| sp02278 | Gearbox Replacement | TCM (Transmission Control Module) |
| sp02279 | Lever Release Solenoid Command | TCM (Transmission Control Module) |
| sp02280 | Static Test | ABS (Anti-Lock Braking System) |
| sp02281 | Trailer Hook Presence Disabling | PAM (Parking Aid Module) |
| sp02282 | Trailer Hook Presence Enabling | PAM (Parking Aid Module) |
| sp02283 | Reset Odometer | IC (Instrument Cluster) |
| sp02284 | Reset Service Information | IC (Instrument Cluster) |
| sp02285 | Disable Seat Belts Reminder | IC (Instrument Cluster) |
| sp02286 | Enable Seat Belts Reminder | IC (Instrument Cluster) |
| sp02287 | Last Service Date | IC (Instrument Cluster) |
| sp02288 | Actuator Calibration Test | HVAC (Heating Ventilation Air-Conditioning And Cooling) |
| sp02289 | Fire Protection System Activate | BCM (Body Control Module) |
| sp02290 | Cam Crank Relearn | PCM (Powertrain Control Module) |
| sp02291 | Check PCM Odometer | PCM (Powertrain Control Module) |
| sp02292 | Quicklearn (62TE) | PCM (Powertrain Control Module) |
| sp02293 | Quicklearn (Non-RFE) | PCM (Powertrain Control Module) |
| sp02294 | Reset Memory | PCM (Powertrain Control Module) |
| sp02295 | EGR System Test | PCM (Powertrain Control Module) |
| sp02296 | ETC Throttle Follower Test | PCM (Powertrain Control Module) |
| sp02297 | Set Engine RPM | PCM (Powertrain Control Module) |
| sp02298 | Shift Lever Position Test (62TE) | PCM (Powertrain Control Module) |
| sp02299 | Shift Lever Position Test (Non-RFE) | PCM (Powertrain Control Module) |
| sp02300 | ABS Initialization | ABS (Anti Lock Brakes) |
| sp02301 | Bleed Brakes | ABS (Anti Lock Brakes) |
| sp02302 | Activate Driver And Passenger Head Restraint | ORC (Occupant Restraint) |
| sp02303 | Program Tire Sensor ID With TPM Tool | WCM (Wireless Control) |
| sp02304 | Reset Odometer | PDM (Passenger Door Module) |
| sp02305 | Reset Service Information | PDM (Passenger Door Module) |
| sp02306 | Disable Seat Belts Reminder | PDM (Passenger Door Module) |
| sp02307 | Enable Seat Belts Reminder | PDM (Passenger Door Module) |
| sp02308 | Actuator Calibration Test | HVAC (Heat, Ventilation And A/C) |
| sp02309 | Auto Door Lock | CCN (Instrument Cluster/Cabin Compartment Node) |
| sp02310 | Auto Door Unlock | CCN (Instrument Cluster/Cabin Compartment Node) |
| sp02311 | Seatbelt Alert Minder | CCN (Instrument Cluster/Cabin Compartment Node) |
| sp02312 | Update Measurement Unit | CCN (Instrument Cluster/Cabin Compartment Node) |
| sp02313 | Seatbelt Alert Minder | CCN (Instrument Cluster/Cabin Compartment Node) |
| sp02314 | Self Test | CCN (Instrument Cluster/Cabin Compartment Node) |
| sp02315 | Cam Crank Relearn | PCM (Powertrain Control Module) |
| sp02316 | Check PCM Odometer | PCM (Powertrain Control Module) |
| sp02317 | Quicklearn (62TE) | PCM (Powertrain Control Module) |
| sp02318 | Quicklearn (Non-RFE) | PCM (Powertrain Control Module) |
| sp02319 | Reset Memory | PCM (Powertrain Control Module) |

| | | |
|---------|-------------------------------------|---------------------------------|
| sp02320 | EGR System Test | PCM (Powertrain Control Module) |
| sp02321 | ETC Throttle Follower Test | PCM (Powertrain Control Module) |
| sp02322 | Set Engine RPM | PCM (Powertrain Control Module) |
| sp02323 | Shift Lever Position Test (62TE) | PCM (Powertrain Control Module) |
| sp02324 | Shift Lever Position Test (Non-RFE) | PCM (Powertrain Control Module) |
| sp02325 | ABS Initialization | ABS (Anti Lock Brakes) |

XTOOL