



# Shenzhen Xtooltech Co., Ltd

## China service reset function list

Software version: 29.22

Automaker	Model	method	Year	Type
BAIC	BJ20	Auto reset	-2018	
BAIC	BJ20	Auto reset	2018	
BAIC	BJ40	Auto reset		
BAIC	BJ40 PLUS	Auto reset		
BAIC	BJ40L (2018)	Auto reset		Petrol
BAIC	BJ40L (2018)	Auto reset		Diesel
BAIC	BJ40L (2018)	Auto reset		City Hunter Edition
BAIC	BJ80C	Auto reset		
BAIC	BJ80J	Auto reset		
BAIC	E Series	Auto reset		
BAIC	U7	Auto reset		
BAIC	X3	Auto reset		
BAIC	X5	Auto reset		
BAIC	X7	Auto reset		
BAIC (Saab)	CC (C60F)	Auto reset		
BAIC (Saab)	D20 (C30D/C31D)	Auto reset		
BAIC (Saab)	D50 (C50E)	Auto reset		Type 1
BAIC (Saab)	D50 (C50E)	Auto reset		Type 2
BAIC (Saab)	D50 (C50E)	Manual reset	-2018	
BAIC (Saab)	D50 (C50E)	Manual reset	2018-	

BAIC (Saab)	New D50	Auto reset		
BAIC (Saab)	D60 (C60F)	Auto reset		
BAIC (Saab)	D70 (C70G)	Auto reset		Type 1
BAIC (Saab)	D70 (C70G)	Auto reset		Type 2
BAIC (Saab)	New D70	Auto reset		
BAIC (Saab)	D80 (C80G)	Auto reset		
BAIC (Saab)	X25 (C33D)	Auto reset	-2016	
BAIC (Saab)	X25 (C33D)	Auto reset	2016-2017	
BAIC (Saab)	X35 (C32B)	Auto reset	-2016	
BAIC (Saab)	X35 (C32B)	Auto reset	2016	
BAIC (Saab)	X55 (C51E)	Auto reset		Type 1
BAIC (Saab)	X55 (C51E)	Auto reset		Type 2
BAIC (Saab)	New X55	Auto reset		
BAIC (Saab)	X65 (C61X)	Auto reset		
BAIC (Saab)	ZhiDao	Auto reset		
BAIC (New Energy)	WeiWang 307	Auto reset	-2015	
BAIC (New Energy)	WeiWang 308 EV	Auto reset		
BAIC (New Energy)	EV150	Auto reset		
BAIC (New Energy)	EV160	Auto reset		
BAIC (New Energy)	EV200	Auto reset		
BAIC (New Energy)	EV300	Auto reset		
BAIC (New Energy)	EX200	Auto reset		
BAIC (New Energy)	EX260	Auto reset		
BAIC (New Energy)	EX360	Auto reset		
BAIC (New Energy)	EX3	Auto reset		
BAIC (New Energy)	EX5	Auto reset		
BAIC (New Energy)	EC3	Auto reset		
BAIC (New Energy)	EU220	Auto reset		
BAIC (New Energy)	EU260	Auto reset		

BAIC(New Energy)	EU300	Auto reset		
BAIC(New Energy)	EU400	Auto reset		
BAIC(New Energy)	EU5	Auto reset		
BAIC(New Energy)	EU5 PLUS	Auto reset		
BAIC(New Energy)	EU7	Auto reset		
BAIC(New Energy)	EH300	Auto reset		
BAIC(New Energy)	ARCFOX	Auto reset		
BAIC(New Energy)	ARCFOX (ADAS)	Auto reset		
BAIC(New Energy)	LITE	Auto reset		Basic
BAIC(New Energy)	LITE	Auto reset		ADAS
BAIC(New Energy)	LITE	Auto reset		300
BAIC(Wei Wang)	M50F	Auto reset		
BAIC(Wei Wang)	M60	Auto reset		
BAIC(Wei Wang)	S50	Auto reset		
Bao Jun	RS-5	Auto reset		
Bao Jun	RS-5	Manual reset		
BARGWARD	BX3	Auto reset		
BARGWARD	BX5	Auto reset		
BARGWARD	BX7	Auto reset		
BYD	E1	Manual reset		
BYD	E2	Manual reset		
BYD	E3	Manual reset		
BYD	E5	Manual reset		
BYD	E6 (E6A)	Manual reset		
BYD	E6 (E6A)	Manual reset		
BYD	E6 (E6H)	Manual reset		
BYD	E6 (E6Y)	Manual reset		
BYD	E6 (E6M)	Manual reset		
BYD	E6 (E6K)	Manual reset		

BYD	G5	Manual reset		
BYD	G6	Manual reset		
BYD	M3	Manual reset		
BYD	M6	Manual reset		
BYD	S6	Manual reset		
BYD	S7	Manual reset		
BYD	T3	Manual reset		
BYD	Surui	Manual reset		
BYD	Sirui	Manual reset		
BYD	Qin	Manual reset		Fuel version
BYD	Qin	Manual reset		Hybrid version
BYD	Qin	Manual reset	2016-2019	Pure electric version
BYD	Qin	Manual reset	2019-	Pure electric version
BYD	Qin (pro)	Manual reset		
BYD	Qin (PLUS)	Manual reset		
BYD	Tang	Manual reset	2018-	Fuel version
BYD	Tang	Manual reset	2015-2018	Hybrid version
BYD	Tang	Manual reset	2018-	Hybrid version
BYD	Tang	Manual reset		Pure electric version
BYD	Song	Manual reset	2015-2018	Fuel version
BYD	Song	Manual reset	2018-	Fuel version
BYD	Song	Manual reset		Hybrid version
BYD	Song	Manual reset		Pure electric version
BYD	Song (pro)	Manual reset		
BYD	Song (PLUS)	Manual reset		Pure electric version
BYD	Song (MAX)	Manual reset	2017-2019	Fuel version
BYD	Song (MAX)	Manual reset	2020-	Fuel version
BYD	Song (MAX)	Manual reset		Hybrid version
BYD	Song (MAX)	Manual reset		Pure electric version

BYD	Yuan	Manual reset		Fuel version
BYD	Yuan	Manual reset	-2021	Pure electric version
BYD	Yuan	Manual reset	2021-	Pure electric version
BYD	Yuan	Manual reset		Hybrid version
BYD	Han	Manual reset		Hybrid version
BYD	Han	Manual reset		Pure electric version
BYD	D1	Manual reset		Pure electric version
Chang An	CS15	Auto reset		
Chang An	CS15 EV	Auto reset		
Chang An	CS35	Auto reset	2017-	
Chang An	CS35 PLUS	Auto reset		
Chang An	CS55	Auto reset		Visteon Meters
Chang An	CS55 PLUS	Auto reset		
Chang An	CS75	Auto reset		China
Chang An	CS75	Auto reset		Other
Chang An	CS75 PHEV	Auto reset		
Chang An	CS85	Auto reset	-2020.11	
Chang An	CS85	Auto reset	2020.11-	
Chang An	EADO PLUS	Auto reset		
Chang An	BenBen	Auto reset		
Chang An	LINMAX	Auto reset		
Chang An	RAETON	Auto reset		
Chang An	RAETON CC	Auto reset		TianXing Meters
Chang An	NEW RAETON CC	Auto reset	-2020.06	TianXing Meters
Chang An	NEW RAETON CC	Auto reset	2021.07-	TianXing Meters
Chang An	UNI-K	Auto reset		
Chang An	UNI-T	Auto reset		
Chang An	UNI-V	Auto reset		
Chang An	KeSai 5	Auto reset		

Chang An	CS15	Manual reset		
Chang An	CS35	Manual reset		
Chang An	CS75	Manual reset		
Chang An	CS75 PLUS	Manual reset		
Chang An	CS95	Manual reset		
GREAT WALL	C30	Auto reset		
GREAT WALL	C30 (CH041E)	Auto reset		
GREAT WALL	C50	Auto reset		CHB012
GREAT WALL	C50	Auto reset		JZ40
GREAT WALL	C50	Manual reset		
GREAT WALL	FengJun 5	Manual reset		
GREAT WALL	Poer	Auto reset		Type 1
GREAT WALL	Poer	Auto reset		Type 2
GREAT WALL	F5	Auto reset		
GREAT WALL	F7	Auto reset		Type 1
GREAT WALL	F7	Auto reset		Type 2
GREAT WALL	F7X	Auto reset		
GREAT WALL	H1	Auto reset		
GREAT WALL	H2	Auto reset		
GREAT WALL	H2s	Auto reset		
GREAT WALL	H4	Auto reset		
GREAT WALL	H6	Auto reset	-2014	
GREAT WALL	H6	Auto reset	2015-2020	
GREAT WALL	H6	Auto reset	2021	
GREAT WALL	H6 COUPE	Auto reset	-2018	
GREAT WALL	H6 COUPE	Auto reset	2019-	Type 1
GREAT WALL	H6 COUPE	Auto reset	2019-	Type 2
GREAT WALL	H7	Auto reset		Type 1
GREAT WALL	H7	Auto reset		Type 2

GREAT WALL	H8	Auto reset		6AT
GREAT WALL	H8	Auto reset		8AT
GREAT WALL	H9	Auto reset		6AT
GREAT WALL	H9	Auto reset		8AT
GREAT WALL	H9	Auto reset	2020	
GREAT WALL	M6	Auto reset		
GREAT WALL	Jolion	Auto reset		
GREAT WALL	Dargo	Auto reset		
GREAT WALL	Rabbit	Auto reset		
GREAT WALL	P8	Auto reset		
GREAT WALL	VV5	Auto reset		Type 1
GREAT WALL	VV5	Auto reset		Type 2
GREAT WALL	VV6	Auto reset		
GREAT WALL	VV7	Auto reset	-2020	
GREAT WALL	VV7	Auto reset	2020/GT/PHEV	
GREAT WALL	Tank 300	Auto reset		
GREAT WALL	Mocha	Auto reset		
GREAT WALL	IQ	Auto reset		
GREAT WALL	R1	Auto reset		
GREAT WALL	R2	Auto reset		
GREAT WALL	IQ-420	Auto reset		
GREAT WALL	HaoMao	Auto reset		
GREAT WALL	C30EV	Auto reset		Type 1
GREAT WALL	C30EV	Auto reset		Type 2
GREAT WALL	C30EV	Auto reset		Type 3
GREAT WALL	FengJun 7	Auto reset		
Chang He	Q25	Auto reset		
Chang He	Q35	Auto reset		
Chang He	A6	Auto reset	-2019	

Chang He	A6	Auto reset	2019-	
Chang He	Q7	Auto reset		Type 1
Chang He	Q7	Auto reset		Type 2
ChangFeng	CS9	Manual reset		
ChangFeng	CS10	Manual reset		
DFFG	IX5	Manual reset		
DFFG	500	Manual reset		
DFFG	E1	Auto reset		
DFFG	E3	Auto reset		
DFFG	IX5	Auto reset		
DFFG	IX7	Auto reset		
DFFS	A30	Manual reset	2014-2016	
DFFS	AX3	Manual reset		Type 1
DFFS	AX3	Manual reset		Type 2
DFFS	AX4	Manual reset	2017-2018	
DFFS	AX4	Manual reset	2019	
DFFS	AX5	Manual reset		
DFFS	AX7	Manual reset	2015-2016	
DFFS	AX7	Manual reset	2017	
DFFS	AX7	Manual reset		A14T
DFFS	AX7	Manual reset		Other
DFFS	New AX7	Manual reset		Type 1
DFFS	New AX7	Manual reset		Type 2
DFFS	A60	Manual reset		
DFFS	A9	Manual reset	2016	
DFFS	E70	Manual reset		
DFFS	L60	Manual reset	2015	
DFFS	D53	Manual reset		
DFFS	AX5	Auto reset		



DFFX	CM7	Manual reset		
Soueast	A5	Manual reset		
Soueast	DX3	Manual reset		
Soueast	DX7	Manual reset		
Soueast	V5	Manual reset		
Venucia	D60	Manual reset	2017-	
Venucia	T60	Manual reset	2018	
Venucia	T70	Manual reset	2014-2018	
Venucia	T90	Manual reset	2016-2019	
Rising Auto	ER6	Manual reset		
FOTON	Tunland	Auto reset		
FOTON	Savanna (U201)	Auto reset		
Maple	30x	Auto reset		
Qoros	Qoros 3	Auto reset		
Qoros	Qoros 3s	Auto reset		
Qoros	Qoros 3 5-door version	Auto reset		
Qoros	Qoros 3 SUV	Auto reset		
Qoros	Qoros 3 Car	Auto reset		
Qoros	Qoros 3 GT	Auto reset		
Qoros	Qoros 5	Auto reset		
Qoros	Qoros 5s	Auto reset		
Qoros	Qoros 5 SUV	Auto reset		
Trumpchi	GS3	Manual reset		Type 1
Trumpchi	GS3	Manual reset		Type 2
Trumpchi	GS3	Manual reset		Type 3
Trumpchi	GS4 COUPE	Manual reset		Type 1
Trumpchi	GS4 COUPE	Manual reset		Type 2
Trumpchi	GS4 COUPE	Manual reset		Type 3
Trumpchi	GS4 PHEV	Manual reset		Type 1

Trumpchi	GS4 PHEV	Manual reset		Type 2
Trumpchi	GS4 PHEV	Manual reset		Type 3
Trumpchi	GS4 EV	Manual reset		Type 1
Trumpchi	GS4 EV	Manual reset		Type 2
Trumpchi	GS4 EV	Manual reset		Type 3
Trumpchi	GS4	Manual reset		Type 1
Trumpchi	GS4	Manual reset		Type 2
Trumpchi	GS4	Manual reset		Type 3
Trumpchi	GS5	Manual reset		Type 1
Trumpchi	GS5	Manual reset		Type 2
Trumpchi	GS5	Manual reset		Type 3
Trumpchi	GS8	Manual reset		Type 1
Trumpchi	GS8	Manual reset		Type 2
Trumpchi	GS8	Manual reset		Type 3
Trumpchi	GS8S	Manual reset		Type 1
Trumpchi	GS8S	Manual reset		Type 2
Trumpchi	GS8S	Manual reset		Type 3
Trumpchi	GM6	Manual reset		Type 1
Trumpchi	GM6	Manual reset		Type 2
Trumpchi	GM6	Manual reset		Type 3
Trumpchi	GM8/M8	Manual reset		Type 1
Trumpchi	GM8/M8	Manual reset		Type 2
Trumpchi	GM8/M8	Manual reset		Type 3
Trumpchi	GA3 PHEV	Manual reset		Type 1
Trumpchi	GA3 PHEV	Manual reset		Type 2
Trumpchi	GA3 PHEV	Manual reset		Type 3
Trumpchi	GA3/GS3S	Manual reset		Type 1
Trumpchi	GA3/GS3S	Manual reset		Type 2
Trumpchi	GA3/GS3S	Manual reset		Type 3

Trumpchi	GA4	Manual reset		Type 1
Trumpchi	GA4	Manual reset		Type 2
Trumpchi	GA4	Manual reset		Type 3
Trumpchi	GA5 PHEV	Manual reset		Type 1
Trumpchi	GA5 PHEV	Manual reset		Type 2
Trumpchi	GA5 PHEV	Manual reset		Type 3
Trumpchi	GA5	Manual reset		Type 1
Trumpchi	GA5	Manual reset		Type 2
Trumpchi	GA5	Manual reset		Type 3
Trumpchi	GA6	Manual reset		Type 1
Trumpchi	GA6	Manual reset		Type 2
Trumpchi	GA6	Manual reset		Type 3
Trumpchi	GA8	Manual reset		Type 1
Trumpchi	GA8	Manual reset		Type 2
Trumpchi	GA8	Manual reset		Type 3
Trumpchi	GE3	Manual reset		Type 1
Trumpchi	GE3	Manual reset		Type 2
Trumpchi	GE3	Manual reset		Type 3
Trumpchi	ShiRui	Manual reset		Type 1
Trumpchi	ShiRui	Manual reset		Type 2
Trumpchi	ShiRui	Manual reset		Type 3
Brilliance	Zhonghua V3(Third generation)	Auto reset		
Brilliance	Zhonghua V6	Auto reset		
Brilliance	Zhonghua V7	Auto reset		
Brilliance	Renault Gold Cup view	Auto reset		High configuration
Brilliance	Renault Gold Cup view	Auto reset		Low configuration
Han Teng	A45	Auto reset		
Han Teng	X5	Auto reset		
Han Teng	X5(M11G)	Auto reset		

Han Teng	X7	Auto reset		
Han Teng	X7 (B15G)	Auto reset		
Han Teng	X7S	Auto reset		
Han Teng	X5 (EV)	Auto reset		
Han Teng	X7 (PHEV)	Auto reset		
Hai Ma	M5	Auto reset		VIKEER ICM
Hai Ma	M8	Auto reset		VIKEER ICM
Hai Ma	S7	Auto reset		VIKEER ICM
Hai Ma	V70	Auto reset		VIKEER ICM
Hai Ma	F7	Auto reset		VIKEER ICM
Hai Ma	Family	Auto reset		
Hai Ma	8S (SG00)	Auto reset		ICM-SG00
Hai Ma	S5	Manual reset		
Geely	B0 RUI	Auto reset		
Geely	B0 RUI (GE)	Auto reset		-2019
Geely	B0 RUI (GE)	Auto reset		2019-
Geely	B0 YUE	Auto reset		-2019
Geely	B0 YUE	Auto reset		2019-
Geely	B0 YUE (PRO)	Auto reset		
Geely	B0 YUE (Million)	Auto reset		
Geely	VISION S1	Auto reset	-2019	
Geely	VISION S1	Auto reset	2019	
Geely	VISION X1	Auto reset		
Geely	VISION X3	Auto reset	-2018	
Geely	VISION X3	Auto reset	Type1	
Geely	VISION X3	Auto reset	Type2	
Geely	VISION X6	Auto reset	2016	
Geely	VISION X6	Auto reset	2018	
Geely	VISION X6	Auto reset	-2019	

Geely	VISION X6	Auto reset	2019-	
Geely	VISION X6	Auto reset	2020	
Geely	VISION X6 PRO	Auto reset		
Geely	New VISION	Auto reset	-2019	
Geely	New VISION	Auto reset	2019	
Geely	Emgrand (GL)	Auto reset		GL
Geely	Emgrand (GL)	Auto reset		GL-14T
Geely	Emgrand (GL)	Auto reset		GL-14T (Second generation)
Geely	Emgrand (GL)	Auto reset	-2019	
Geely	Emgrand (GL)	Auto reset	2019-	
Geely	Emgrand (GL)	Auto reset	2020	
Geely	Emgrand (GS)	Auto reset		GS
Geely	Emgrand (GS)	Auto reset		GS-14T (Second generation)
Geely	Emgrand (GS)	Auto reset	-2019	
Geely	Emgrand (GS)	Auto reset	2019-	
Geely	Emgrand (GS)	Auto reset	2020	
Geely	Emgrand (S)	Auto reset		
Geely	Emgrand (S1)	Auto reset		
Geely	Brand new Emgrand	Auto reset		Methanol car
Geely	Brand new Emgrand	Auto reset	2020	
Geely	Bin yue (PRO)	Auto reset	-2019	Traditional power/mild hybrid power
Geely	Bin yue (PRO)	Auto reset	2019-	Traditional power/mild hybrid power
Geely	Bin rui	Auto reset	-2019	
Geely	Bin rui	Auto reset	2019-	
Geely	Jia ji	Auto reset	-2019	
Geely	Jia ji	Auto reset	2019-	
Geely	Xing yue	Auto reset		

Geely	Xing rui	Auto reset		
Geely	Hao yue	Auto reset		
Geely	ICON	Auto reset		
Geely	OKAVANGO	Auto reset		
Geely	EX3	Auto reset		
Geely	Emgrand (EV/EV300/EV350/EV450/EV500)	Auto reset		
Geely	Emgrand (EV Pro)	Auto reset		
Geely	Emgrand (HEV)	Auto reset		
Geely	Emgrand (PHEV)	Auto reset		
Geely	Emgrand (GL PHEV)	Auto reset	-2019	
Geely	Emgrand (GL PHEV)	Auto reset	2019-	
Geely	Emgrand (GSE)	Auto reset		
Geely	Emgrand (GSE-Endurance version)	Auto reset		
Geely	Binyue ePRO (Plug-in hybrid)	Auto reset		
Geely	geometry A	Auto reset		
Geely	geometry C	Auto reset		
Geely	GX7	Auto reset		
Geely	GX9	Auto reset		
Geely	SX7	Auto reset		
Geely	Emgrand GL	Manual reset		
Geely	New VISION X6	Manual reset		
Geely	EmgrandEC7	Manual reset		
Geely	Vision X6-16/18/WanLiyang (V)	Manual reset		
Geely	GX7/GX9	Manual reset		
Geely	Emgrand (Million)	Manual reset		
Geely	Jia Ji	Manual reset		
Geely	Bin Yue	Manual reset		
Geely	ICON	Manual reset		
JETOUR	X70/X70M	Auto reset		

JETOUR	X70 Coupe	Auto reset		
JETOUR	X70 Plus	Auto reset		
JETOUR	X70S	Auto reset		
JETOUR	X90	Auto reset		
JETOUR	New X90	Auto reset		
JETOUR	X90 PLUS	Auto reset		
JETOUR	X95	Auto reset		
JETOUR	X70 (2018)	Manual reset		
JETOUR	X70S EV	Manual reset		TYPE 1
JETOUR	X70S EV	Manual reset		TYPE 2
JMC	New YuSheng (S350)	Auto reset		
JMC	WeiLong	Auto reset		
JMC	Transit	Manual reset		
JMC	X5	Manual reset		
JMC	X5 PLUS	Manual reset		
JMC	X7	Manual reset		Type 1
JMC	X7	Manual reset		Type 2
JAC	A60	Manual reset		
JAC	M3	Manual reset		
JAC	M4	Manual reset		Type 1
JAC	M4	Manual reset		Type 2
JAC	M5	Manual reset		
JAC	S2	Manual reset		
JAC	S3	Manual reset		
JAC	S5	Manual reset		
JAC	Heyue	Manual reset		
JAC	Yue Yue	Manual reset		
JAC	Jiayue A5	Manual reset		
JAC	Jiayue X4	Manual reset		

JAC	Jiayue X7	Manual reset		
JAC	Si Hao A5	Manual reset		
JAC	Si Hao X4	Manual reset		
JAC	Si Hao X7	Manual reset		
JAC	Si Hao X8	Manual reset		
JAC	Other	Manual reset		
Jun Ma	A40 (S70)	Auto reset		
Jun Ma	S301 (MEET3)	Auto reset		
Jun Ma	A40 (S70)	Manual reset		
Jun Ma	D50 (SEEK5)	Manual reset		High configuration
Jun Ma	D50 (SEEK5)	Manual reset		Low configuration
COWIN	Showjet	Auto reset		
COWIN	C3/C3R	Auto reset		
COWIN	V3 (MC22)	Auto reset		
COWIN	X3 (XC51)	Auto reset		
COWIN	S32 EV	Auto reset		
COWIN	E3	Auto reset		
COWIN	X5	Auto reset		
Li Fan	X80	Auto reset		
Suzuki	Vitara	Auto reset		
Suzuki	S-cross	Auto reset	2016-	
Suzuki	S-cross	Manual reset		
Suzuki	Xiao tu	Manual reset		
Suzuki	New Alto	Manual reset	2013-	
Suzuki	SX4	Manual reset	2013-	
Suzuki	Vitra	Manual reset		Type 1
Suzuki	Vitra	Manual reset		Type 2
Suzuki	Vitra	Manual reset		Type 3
Suzuki	Vitra XL-7	Manual reset	2007-2009	



Suzuki	Grand Vitara	Manual reset	2013	
Suzuki	Splash	Manual reset	2008-2011	
Suzuki	DF40	Manual reset		
LYNK&CO	01/02/03/05	Auto reset		
LYNK&CO	06	Auto reset		
LYNK&CO		Manual reset		
MG	CN6	Auto reset		
MG	GS	Auto reset		
MG	GS (EU)	Auto reset		
MG	New GS	Auto reset		
MG	GT (1.5L/1.4T)	Auto reset		
MG	HS	Auto reset	2019-	
MG	MG3	Auto reset		
MG	MG3 EU	Auto reset		
MG	MG3 Zero	Auto reset		
MG	MG3 Zero	Auto reset	2013	
MG	MG5	Auto reset		AP12
MG	MG5	Auto reset		AP13
MG	MG6	Auto reset		
MG	MG6	Auto reset	2013	
MG	MG6	Auto reset	2014	
MG	MG6-EU	Auto reset		
MG	MG6 TT	Auto reset		
MG	New MG6	Auto reset		
MG	MG7	Auto reset		Type 1
MG	MG7	Auto reset		Type 2
MG	MG7-L	Auto reset		
MG	MG7 750	Auto reset		
MG	MGTF	Auto reset		

MG	eZS	Auto reset		
MG	ZS (ZS11)	Auto reset		
MG	ZS (ZS12)	Auto reset		
MG		Manual reset		
NAVECO	NAVECO	Auto reset		
NAVECO	Yue Jin	Auto reset		
NAVECO	Chao Yue	Auto reset		
NAVECO	Daily	Manual reset		
Luxgen		Manual reset		Type 1
Luxgen		Manual reset		Type 2
NETA	N01			
QiNeng	GEV1	Manual reset		
CHERY	A1	Auto reset		ATECH
CHERY	A1	Auto reset		AMT Series
CHERY	A2	Auto reset		
CHERY	A3	Auto reset		
CHERY	A5/Cowin 3	Auto reset		ATECH
CHERY	A16	Auto reset		
CHERY	A19	Auto reset		
CHERY	E3	Auto reset		
CHERY	E5	Auto reset		
CHERY	QQ6/Cowin 1	Auto reset		ATECH
CHERY	QQ6/Cowin 1	Auto reset		AMT Series
CHERY	QQME	Auto reset		
CHERY	New QQ	Auto reset		
CHERY	Eastar/Cowin 5	Auto reset		
CHERY	Eastar cross	Auto reset		
CHERY	New Eastar	Auto reset		
CHERY	Fulwin 2	Auto reset		Type 1

CHERY	Fulwin 2	Auto reset		Type 2
CHERY	Tiggo 3/Tiggo Facelift	Auto reset		1.8 AMT
CHERY	Tiggo 3/Tiggo Facelift	Auto reset		1.6 VVT
CHERY	Tiggo 3X	Auto reset	-2019	
CHERY	Tiggo 3X	Auto reset	2019-	TYPE 1
CHERY	Tiggo 3X	Auto reset	2019-	TYPE 2
CHERY	Tiggo 3X PLUS	Auto reset		TYPE 1
CHERY	Tiggo 3X PLUS	Auto reset		TYPE 2
CHERY	Tiggo 5	Auto reset		
CHERY	Tiggo 5X	Auto reset		
CHERY	Tiggo 7	Auto reset		
CHERY	New Tiggo7	Auto reset		TYPE 1
CHERY	New Tiggo7	Auto reset		TYPE 2
CHERY	Tiggo 8	Auto reset		
CHERY	New Tiggo8	Auto reset		TYPE 1
CHERY	New Tiggo8	Auto reset		TYPE 2
CHERY	Tiggo 8 PLUS	Auto reset		TYPE 1
CHERY	Tiggo 8 PLUS	Auto reset		TYPE 2
CHERY	Arrizo 3	Auto reset		
CHERY	Arrizo 5	Auto reset		
CHERY	Arrizo 5 PLUS	Auto reset		
CHERY	Arrizo 7	Auto reset		
CHERY	Arrizo 7E	Auto reset		
CHERY	Arrizo 8	Auto reset		
CHERY	Arrizo M7	Auto reset		
CHERY	Arrizo EX/GX	Auto reset		
CHERY	M1	Auto reset		
CHERY	M2	Auto reset		
CHERY	M3	Auto reset		

CHERY	M5	Auto reset		
CHERY	X1	Auto reset		
CHERY	G2	Auto reset		
CHERY	G3	Auto reset		
CHERY	G6	Auto reset		
CHERY	H3	Auto reset		
CHERY	H5	Auto reset		
CHERY	V5	Auto reset		KWP
CHERY	V5	Auto reset		CAN
CHERY	V8	Auto reset		
CHERY	X5	Auto reset		
CHERY	Dolphin EV	Auto reset		
CHERY	V2	Auto reset		
CHERY	S22	Auto reset		
CHERY	K60 (KM23)	Auto reset		
CHERY	K60 EV	Auto reset		
CHERY	K60 1.5T	Auto reset		
CHERY	K60 2018	Auto reset		
CHERY	K50S (Q26FL)	Auto reset		
CHERY	QQ3	Auto reset		
CHERY	S18	Auto reset		
CHERY	eQ	Auto reset		
CHERY	eQ1 (S51EV)	Auto reset		
CHERY	eQ5	Auto reset		
CHERY	S32EV	Auto reset		
CHERY	Arrizo E	Auto reset		
CHERY	Arrizo 5E	Auto reset		
CHERY	Tiggo 3xe	Auto reset		
CHERY	Tiggo E	Auto reset		

CHERY	A1	Manual reset		
CHERY	B11	Manual reset		
CHERY	S21-QQ6	Manual reset		
CHERY	S11-QQ3	Manual reset		
CHERY	S16-QQme	Manual reset		
CHERY	S12-A1	Manual reset		
CHERY	T11-Tiggo	Manual reset		Type 1
CHERY	T11-Tiggo	Manual reset		Type 2
CHERY	A15-Cowin 2	Manual reset		
CHERY	A21-A5/Cowin 3	Manual reset		
CHERY	M11-A3	Manual reset		
CHERY	M12-A3	Manual reset		
CHERY	A13	Manual reset		
CHERY	J15	Manual reset		
CHERY	S22L	Manual reset		
CHERY	A18	Manual reset		
CHERY	Q26 (K50)	Manual reset		
ROEWE	350	Auto reset		
ROEWE	360 (1.4T)	Auto reset		
ROEWE	360 (1.5VCT/1.5T)	Auto reset		
ROEWE	550	Auto reset		
ROEWE	New 550	Auto reset		
ROEWE	750 (-2010)	Auto reset		
ROEWE	750 (2010-)	Auto reset		
ROEWE	New 750	Auto reset		
ROEWE	950	Auto reset		
ROEWE	i5	Auto reset		
ROEWE	i6 (IP31)	Auto reset		
ROEWE	RX3	Auto reset		

ROEWE	RX5	Auto reset		
ROEWE	E50	Auto reset		
ROEWE	Ei6 (IP34)	Auto reset		Type 1
ROEWE	Ei6 (IP34)	Auto reset		Type 2
ROEWE	New 550 HYBRID	Auto reset		
ROEWE	New 750 HYBRID	Auto reset		
ROEWE	E950	Manual reset		
ROEWE	Other	Manual reset		
Rover	75	Manual reset	1999-2005	
Rover	75	Manual reset	2002	
MAXUS	D60	Auto reset		
MAXUS	D90	Auto reset		
MAXUS	G50	Auto reset		
MAXUS	G50 PLUS	Auto reset		
MAXUS	G10	Auto reset		Type 1
MAXUS	G10	Auto reset		Type 2
MAXUS	G10	Manual reset	-2019	
MAXUS	G10	Manual reset	2020-	
MAXUS	G20	Auto reset		
MAXUS	T60	Auto reset		
MAXUS	T70	Auto reset		
MAXUS	T90	Auto reset		TYPE 1
MAXUS	T90	Auto reset		TYPE 2
MAXUS	V80 (2018-)	Auto reset		
MAXUS	V90	Auto reset		
MAXUS	EXTENDER	Auto reset		
MAXUS	RV63	Auto reset		
MAXUS	EG10	Auto reset		
MAXUS	EG50	Auto reset		

MAXUS	EV30	Auto reset		
MAXUS	EV90	Auto reset		
MAXUS	eDeliver 3	Auto reset		
MAXUS	EUNIQ5 (EV)	Auto reset		
MAXUS	EUNIQ5 PLUG-IN (PHEV)	Auto reset		
MAXUS	EUNIQ6 (EV)	Auto reset		
MAXUS	EUNIQ6 PLUG-IN (PHEV)	Auto reset		
MAXUS	T90 EV	Auto reset		
MAXUS		Manual reset		
SWM	X7	Manual reset		
TJFAW	A70	Auto reset		
TJFAW	D80	Auto reset		
EXEED	TX/TXL	Auto reset		
EXEED	LX	Auto reset		
EXEED	VX	Auto reset		
Ye ma	T70	Auto reset		
Ye ma	T70S	Auto reset		
Ye ma	T80	Auto reset		
Ye ma	SPICA	Auto reset		
Ye ma	Bo Jun	Auto reset		
Ye ma	E70/T70EV	Auto reset		
Ye ma	EC30	Auto reset		
FAW	B30	Auto reset		
FAW	B90	Auto reset		
FAW	X40	Auto reset	-2019	Type 1
FAW	X40	Auto reset	-2019	Type 2
FAW	X40	Auto reset	2019-	Type 1
FAW	X40	Auto reset	2019-	Type 2
FAW	X80	Auto reset		

FAW	T33	Auto reset		
FAW	T77	Auto reset		
FAW	T99	Auto reset		
FAW	B50	Manual reset		Type 1
FAW	B50	Manual reset		Type 2
FAW	New B50	Manual reset		Non-color screen
FAW	B90	Manual reset		Type 1
FAW	B90	Manual reset		Type 2
FAW	X80	Manual reset		old
FAW	X80	Manual reset		color screen
FAW	X80	Manual reset		Non-color screen
FAW	T77	Manual reset		color screen
FAW	T99	Manual reset	2019	color screen
FAW	X40	Manual reset		color screen
Faw HongQI	H5	Auto reset		
Faw HongQI	H7	Auto reset		
Faw HongQI	HS3	Auto reset		
Faw HongQI	HS5	Auto reset		
Faw HongQI	HS7	Auto reset		
Faw HongQI	H9	Auto reset		
Faw Daihatsu	R7	Auto reset		
Faw Daihatsu	R9	Auto reset		
ZOTYE	E20	Auto reset		
ZOTYE	G60	Auto reset		
ZOTYE	G60E	Auto reset		
ZOTYE	G60S	Auto reset		
ZOTYE	G70S	Auto reset		
ZOTYE	X5	Auto reset		
ZOTYE	X7	Auto reset		



ZOTYE	E30	Auto reset		
ZOTYE	SR7	Auto reset	-2017	
ZOTYE	SR7	Auto reset	2017-	
ZOTYE	SR9	Auto reset		
ZOTYE	L10	Auto reset		
ZOTYE	T300	Auto reset		
ZOTYE	T500	Auto reset		
ZOTYE	T600	Auto reset		
ZOTYE	T600 COUPE	Auto reset		
ZOTYE	T600	Auto reset		
ZOTYE	New T600 (2019)	Auto reset		
ZOTYE	T700	Auto reset		
ZOTYE	T800	Auto reset		
ZOTYE	Z100	Auto reset		
ZOTYE	Z200	Auto reset		
ZOTYE	Z300	Auto reset		
ZOTYE	Z360	Auto reset		
ZOTYE	Z500	Auto reset		
ZOTYE	Z560	Auto reset		
ZOTYE	Z700	Auto reset		
ZOTYE	A16	Auto reset		
ZOTYE	B21	Auto reset		
ZOTYE	M300	Auto reset		
ZOTYE	Han long	Auto reset		
ZOTYE	SR7 EV	Auto reset		
ZOTYE	T300EV	Auto reset		
ZOTYE	Z500 EV	Auto reset		
ZOTYE	T200	Manual reset		
ZOTYE	T300	Manual reset		

ZOTYE	T600	Manual reset		
ZOTYE	SR7	Manual reset		
ZOTYE	SR9	Manual reset		
ZOTYE	Z100	Manual reset		
ZOTYE	Z300	Manual reset		Type 1
ZOTYE	Z300	Manual reset		Type 2
ZOTYE	Z500	Manual reset		
ZOTYE	X5	Manual reset		
ZOTYE	X7	Manual reset		
ZOTYE	LangLang	Manual reset		
ZhengZhou Nissan	A17C	Auto reset		
ZhengZhou Nissan	Ruiqi 6	Auto reset		
ZhengZhou Nissan	Ruiqi 6EV	Auto reset		
ZhengZhou Nissan	MX5	Manual reset		
ZhengZhou Nissan	MX6	Manual reset		
ZhengZhou Nissan	NV200	Manual reset	2017	
ZXAUTO	Lord	Manual reset		
Know beans	Know beans 3	Auto reset		