

Immobiliser Function List

Software Version: 26.23

Automaker	Model	System	Function
CHANGFENG	CS6(Diesel)	Immobiliser	1.ECU identification 2.Read DTC 3.Clear DTC 4.Read data stream 5.Set security code 6.Program function
CHANGFENG	CS6(Gasoline)	Immobiliser	1.ECU identification 2.Read DTC 3.Clear DTC 4.Read data stream 5.Set security code 6.Program function
CHANGFENG	CS7	DIAS Immobiliser	1.ECU identification 2.Read DTC 3.Clear DTC 4.Read data stream 5.Program function 6.Actuation test
CHANGFENG	CS7	Delphi Immobiliser	1.ECU identification 2.Read DTC 3.Clear DTC 4.Read data stream 5.Set security code 6.Program function

CHANGFENG	CS7	Integrated Immobiliser system	<ul style="list-style-type: none"> 1.Password setting 2.Program code 3.Program the new key 4.Program the old key 5.Erase all key 6.Program VIN code 7.Program date 8.Date of diagnosis 9.Program ID 10.Reset IMMO 11.Reset EMS 12.Program EMS 13.Program IMMO 14.offline program immo 15.Change IMMO 16.Change EMS 17.Change key
CHANGFENG	CS7	Body Control system	<ul style="list-style-type: none"> 1.Remote number 2.Program remote
CHANGFENG	CS4	Integrated Immobiliser system	<ul style="list-style-type: none"> 1.Password setting 2.Program code 3.Program the new key 4.Program the old key 5.Erase all key 6.Program VIN code 7.Program date 8.Date of diagnosis 9.Program ID 10.Reset IMMO 11.Reset EMS 12.Program EMS 13.Program IMMO 14.offline program immo 15.Change IMMO 16.Change EMS 17.Change key
CHANGFENG	CS10	Integrated Immobiliser system	<ul style="list-style-type: none"> 1.Reset ECU 2.Configuration Information 3.Offline Configuration 4.Change Immobiliser and EMS 5.Change key

CHANGFENG	CS10	smart key system	<ol style="list-style-type: none">1.Read number key2.Add smart key3.Erase smart key4.Aftermarket program5.Program PEPS6.Program electronic steering7.Program EMS8.Read smart key status9.Reset EMS
-----------	------	------------------	--

XTOOL