

## Immobiliser Function List

**Software Version: 26.48**

Automaker	Model	System	Function
MG	GS(-2016)	Immobiliser	1. Add a key 2. Erase keys
MG	GS(2017)	Immobiliser	1.Add a key 2.Erase keys 3.Num. of keys in mem.
MG	GT	Immobiliser	1. Add a key 2. Erase keys 3.Unlock time remaning
MG	MG3	Immobiliser	1. Add a key 2. Erase keys 3.Unlock time remaning
MG	MG5	Immobiliser	1. Add a key 2. Erase keys 3.Unlock time remaning
MG	MG6(-2012)	Immobiliser	1. Add a key 2. Erase keys
MG	MG6(2013-)	Immobiliser	1. Add a key 2. Erase keys
MG	MG7(2014-)	Immobiliser	1. Add a key 2. Erase keys 3.Unlock time remaning
MG	GS	Smart key	1. Add a smart key 2. Erase smart keys
MG	MG3(By OBD)	Remote	1.Program remote 2.Delete remote 3.Read emergency password 4.Read VIN
MG	MG3(By Eeprom)	Remote	1.Read VIN
MG	MG7	Remote	1. Program remote 2. Read remote ID 3. Disable remote 4. Enable remote 5. Erase DTC