

## Injector coding Function List

Software Version:10.32

Automaker	Type1	Type2	Type3
BMW	Automatic scan		
BMW	Manual selection	1 series	E81/E82/E87/E88
BMW	Manual selection	1 series	F20
BMW	Manual selection	1 series	F21
BMW	Manual selection	2 series	F22
BMW	Manual selection	3 series	E90/E91/E92/E93
BMW	Manual selection	3 series	F30/F31/F34/F35
BMW	Manual selection	4 series	F32/F33
BMW	Manual selection	5 series	E60/E61
BMW	Manual selection	5 series	F07
BMW	Manual selection	5 series	F10/F11/F18
BMW	Manual selection	6 series	E63/E64
BMW	Manual selection	6 series	F06/F12/F13
BMW	Manual selection	7 series	E65/E66/E68
BMW	Manual selection	7 series	F01/F02/F04
BMW	Manual selection	I series	I01/I12
BMW	Manual selection	X series	X1 E84
BMW	Manual selection	X series	X3 F25
BMW	Manual selection	X series	X4 F26
BMW	Manual selection	X series	X5 E70
BMW	Manual selection	X series	X5 F15
BMW	Manual selection	X series	X6 E71
BMW	Manual selection	X series	X6 E72
BMW	Manual selection	X series	X5M E70
BMW	Manual selection	X series	X6M E71
BMW	Manual selection	Z series	Z4 E89

BMW	Manual selection	M series	M3 E90/E92/E93
BMW	Manual selection	M series	M5 E60
BMW	Manual selection	M series	M5 F10
BMW	Manual selection	M series	M6 E63/E64
BMW	Manual selection	M series	M6 F06
BMW	Manual selection	MINI	R55/R56/R57/R58/R59/R60/R61
BMW	Manual selection	MINI	F56

*XTOOL*