



# Shenzhen Xtooltech Co., Ltd.

## Transporter Function List V18.26

**NOTES:**

√ This function is supported.

\* This function is new added.

Model	Model Series	Control Unit Groups	System Name	Read ECU Informat	Read Trouble Code	Read Event fault	Clear Trouble Code	Live Data	Actuation Test	Special Functions
Sprinter	690.6	Body	AB-Airbag	√	√		√			
Sprinter	690.6	Body	ABW-Airbag with window airbag	√	√		√			
Sprinter	690.6	Body	ARS-All-wheel system	√	√		√	√		
Sprinter	690.6	Body	EDW2-Anti-theft alarm	√	√		√	√		
Sprinter	690.6	Body	HZR-Heating control	√	√		√	√		
Sprinter	690.6	Body	RFH backup assist	√	√		√	√		
Sprinter	690.6	Body	WSP immobilizer	√	√		√	√		
Sprinter	690.6	Body	ZV-Central locking system	√	√		√	√		
Sprinter	690.6	Chassis	ABS-Anti lock braking system	√	√		√	√		
Sprinter	690.6	Chassis	ESP-Electronic stability program	√	√		√	√		
Sprinter	690.6	Drive	CR-Common rail	√	√		√	√		
Sprinter	690.6	Drive	CR-Common rail	√	√		√	√		
Sprinter	690.6	Drive	EGS electronic transmission control	√	√	√	√	√		
Sprinter	690.6	Drive	EWM-Electronic selector lever module	√	√	√	√	√		
Sprinter	690.6	Drive	ME-Motor electronics	√	√		√	√		
Sprinter	690.6	Information and	APS-Auto pilot system	√	√		√	√		
Sprinter	690.6	Information and	AUDIO/APS-Auto pilot system	√	√		√	√		
Sprinter	690.6	Information and	KI-Instrument cluster	√	√	√	√	√		
Sprinter	690.6	Information and	Radio (SOUND series)	√	√		√	√		

Sprinter	901.6,902.6,9 03.6,904.6,90	Body	AB-Airbag	√	√		√			
Sprinter	901.6,902.6,9 03.6,904.6,90	Body	ABW-Airbag with window airbag	√	√		√			
Sprinter	901.6,902.6,9 03.6,904.6,90	Body	ARS-All-wheel system	√	√		√	√		
Sprinter	901.6,902.6,9 03.6,904.6,90	Body	EDW2-Anti-theft alarm	√	√		√	√		
Sprinter	901.6,902.6,9 03.6,904.6,90	Body	HZR-Heating control	√	√		√	√		
Sprinter	901.6,902.6,9 03.6,904.6,90	Body	RFH backup assist	√	√		√	√		
Sprinter	901.6,902.6,9 03.6,904.6,90	Body	WSP immobilizer	√	√		√	√		
Sprinter	901.6,902.6,9 03.6,904.6,90	Body	ZV-Central locking system	√	√		√	√		
Sprinter	901.6,902.6,9 03.6,904.6,90	Chassis	ABS-Anti lock braking system	√	√		√	√		
Sprinter	901.6,902.6,9 03.6,904.6,90	Chassis	ESP-Electronic stability program	√	√		√	√		
Sprinter	901.6,902.6,9 03.6,904.6,90	Drive	CR-Common rail	√	√		√	√		
Sprinter	901.6,902.6,9 03.6,904.6,90	Drive	CR-Common rail	√	√		√	√		
Sprinter	901.6,902.6,9 03.6,904.6,90	Drive	EGS electronic transmission control	√	√	√	√	√		
Sprinter	901.6,902.6,9 03.6,904.6,90	Drive	EWM-Electronic selector lever module	√	√	√	√	√		
Sprinter	901.6,902.6,9 03.6,904.6,90	Drive	ME-Motor electronics	√	√		√	√		
Sprinter	901.6,902.6,9 03.6,904.6,90	Information and	APS-Auto pilot system	√	√		√	√		
Sprinter	901.6,902.6,9 03.6,904.6,90	Information and	AUDIO/APS-Auto pilot system	√	√		√	√		
Sprinter	901.6,902.6,9 03.6,904.6,90	Information and	KI-Instrument cluster	√	√	√	√	√		
Sprinter	901.6,902.6,9 03.6,904.6,90	Information and	Radio (SOUND series)	√	√		√	√		

Sprinter	906	Air	KLA-Automatic air conditioning	√	√		√	√		√
Sprinter	906	Air	PTC-Heater booster	√	√	√	√	√		
Sprinter	906	Air	ZHE-Auxiliary heater	√	√	√	√	√		
Sprinter	906	Air	ZHZ-Heater booster	√	√	√	√	√		
Sprinter	906	Body	AAG-Trailer connection unit	√	√	√	√	√		
Sprinter	906	Body	ALWR-Headlamp range adjustment	√	√	√	√	√	√	√
Sprinter	906	Body	DBE-Overhead control panel	√	√	√	√	√	√	
Sprinter	906	Body	EZS-Electronic ignition switch	√	√	√	√	√		
Sprinter	906	Body	EZS-Electronic ignition switch	√	√	√	√	√		
Sprinter	906	Body	EZS-Electronic ignition switch	√	√	√	√	√		
Sprinter	906	Body	KE-Keyless Entry	√	√	√	√	√		
Sprinter	906	Body	MRM-Steering column module	√	√	√	√	√	√	
Sprinter	906	Body	OBF-Upper control panel	√	√	√	√	√		
Sprinter	906	Body	OBF2-Upper control panel	√	√	√	√	√		
Sprinter	906	Body	SAM-Signal acquisition and actuation module	√	√	√	√	√		
Sprinter	906	Body	SRS-Supplemental restraint system(LowLine)As of production month 12/2011	√	√		√	√		
Sprinter	906	Body	SRS-supplemental restraint system	√	√	√	√	√		
Sprinter	906	Chassis	ENR-Electronic rear axle level control	√	√	√	√	√		√
Sprinter	906	Chassis	ESP-Electronic stability program	√	√	√	√	√		√
Sprinter	906	Chassis	ESP9-Electronic stability program	√	√	√	√	√		
Sprinter	906	Chassis	RDK Tire pressure monitor(As of model year 2011)	√	√	√	√			
Sprinter	906	Chassis	RDK Tire pressure monitor(Up to model year 2010)	√	√	√	√			
Sprinter	906	Drive	CDI3-Common Rail Diesel Injection	√	√	√	√	√		
Sprinter	906	Drive	CDI4-Common Rail Diesel Injection	√	√	√	√	√		
Sprinter	906	Drive	CDI4-Common Rail Diesel Injection	√	√	√	√	√		
Sprinter	906	Drive	CDI6-Common Rail Diesel Injection	√	√	√	√	√		
Sprinter	906	Drive	CDI60-Common Rail Diesel Injection(OM642 EPA13)	√	√	√	√			
Sprinter	906	Drive	CDID2-Common Rail Diesel Injection	√	√	√	√	√		
Sprinter	906	Drive	EGS Electronic transmission control	√	√	√	√	√		√
Sprinter	906	Drive	EGS Electronic transmission control	√	√		√	√		
Sprinter	906	Drive	EWM-Electronic selector lever module	√	√	√	√	√		
Sprinter	906	Drive	FSCU-Fuel pump	√	√	√	√	√		
Sprinter	906	Drive	ME 97-Motor electronics 9.7	√	√	√	√	√		
Sprinter	906	Drive	ME-SFI-Motor electronics	√	√	√	√	√		√
Sprinter	906	Drive	NGT-Natural Gas Technology	√				√		

Sprinter	906	Drive	SCR-Selective Catalytic Reduction	✓	✓		✓	✓		
Sprinter	906	Drive	VG-Transfer case	✓	✓	✓	✓			
Sprinter	906	Information and	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	✓	✓	✓	✓	✓		
Sprinter	906	Information and	CDW-CD changer	✓	✓	✓	✓	✓		
Sprinter	906	Information and	COMAND or AUDIO	✓	✓		✓			
Sprinter	906	Information and	FSE Hands-free system (Bluetooth)	✓	✓		✓	✓		
Sprinter	906	Information and	KI-Instrument cluster	✓	✓		✓	✓		
Sprinter	906	Information and	MTCO-Modular tachograph	✓	✓	✓	✓			
Sprinter	906	Information and	NAVI-Navigation system (COMAND,SOUND 50)	✓	✓	✓	✓	✓		
Sprinter	906	Information and	PTS-Parktronic system	✓	✓	✓	✓	✓	✓	
Sprinter	906	Information and	RADIO Sound 20	✓	✓	✓	✓			
Sprinter	906	Information and	RADIO Sound 5	✓	✓	✓	✓			
Sprinter	906	Information and	SOUND 5NG	✓	✓	✓	✓	✓		
Sprinter	906	Information and	TEL-Telephone control unit	✓	✓	✓	✓	✓		
Sprinter	906	LIN Bus	PSM-Parameterizable Special Module	✓	✓	✓	✓	✓		
Sprinter	906	Seats and	STL-Left electric sliding door	✓	✓	✓	✓	✓		
Sprinter	906	Seats and	STR-Right electric sliding door	✓	✓	✓	✓	✓		
Sprinter	906	Seats and	TSG-Door control module front driver side	✓	✓	✓	✓	✓		
Sprinter	YD...,WD...,X D...	Body	AB-Airbag	✓	✓		✓			
Sprinter	YD...,WD...,X D...	Body	ABW-Airbag with window airbag	✓	✓		✓			
Sprinter	YD...,WD...,X D...	Body	ARS-All-wheel system	✓	✓		✓	✓		
Sprinter	YD...,WD...,X D...	Body	EDW2-Anti-theft alarm	✓	✓		✓	✓		

Sprinter	YD...,WD...,X D...	Body	HZR-Heating control	√	√		√	√		
Sprinter	YD...,WD...,X D...	Body	RFH backup assist	√	√		√	√		
Sprinter	YD...,WD...,X D...	Body	WSP immobilizer	√	√		√	√		
Sprinter	YD...,WD...,X D...	Body	ZV-Central locking system	√	√		√	√		
Sprinter	YD...,WD...,X D...	Chassis	ABS-Anti lock braking system	√	√		√	√		
Sprinter	YD...,WD...,X D...	Chassis	ESP-Electronic stability program	√	√		√	√		
Sprinter	YD...,WD...,X D...	Drive	CR-Common rail	√	√		√	√		
Sprinter	YD...,WD...,X D...	Drive	CR-Common rail	√	√		√	√		
Sprinter	YD...,WD...,X D...	Drive	EGS electronic transmission control	√	√	√	√	√		
Sprinter	YD...,WD...,X D...	Drive	EWM-Electronic selector lever module	√	√	√	√	√		
Sprinter	YD...,WD...,X D...	Drive	ME-Motor electronics	√	√		√	√		
Sprinter	YD...,WD...,X D...	Information and	APS-Auto pilot system	√	√		√	√		
Sprinter	YD...,WD...,X D...	Information and	AUDIO/APS-Auto pilot system	√	√		√	√		
Sprinter	YD...,WD...,X D...	Information and	KI-Instrument cluster	√	√	√	√	√		
Sprinter	YD...,WD...,X D...	Information and	Radio (SOUND series)	√	√		√	√		
VANEO	414	Body	HEAT/TAC-Automatic temperature control	√	√		√	√		
VANEO	414	Body	ABW-Airbag with window airbag	√	√		√			
VANEO	414	Body	ATA-Anti-theft alarm system	√	√		√	√		
VANEO	414	Body	DAS-Drive authorization system	√	√		√			
VANEO	414	Chassis	ESP-Electronic stability program	√	√		√	√		
VANEO	414	Drive	ACS-Automatic clutch system	√	√		√			
VANEO	414	Drive	CDI-Common Rail Diesel Injection	√	√		√	√		
VANEO	414	Drive	ECM-Engine control monolith	√	√		√	√		

VANEO	414	Drive	ESM-Electronic selector module	√	√		√	√		
VANEO	414	Drive	FTC-Front transmission control	√	√		√			
VANEO	414	Drive	FTC-Front transmission control	√	√		√	√		
VANEO	414	Information and	AUDIO/APS-Auto pilot system	√	√		√	√		
VANEO	414	Information and	CDC-CD changer	√	√		√			
VANEO	414	Information and	COMAND	√	√		√	√		
VANEO	414	Information and	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√		√	√		
VANEO	414	Information and	IC-Instrument cluster	√	√		√	√		
VANEO	414	Information and	PTS-Parktronic system	√	√		√	√		
VANEO	414	Information and	Radio (SOUND series)	√	√		√	√		
VANEO	414	Information and	UHI-Cellular telephone (fixed installation or portable)(D2B)	√	√		√	√		
VANEO	414	Seats and	CL-Central locking control unit	√	√		√	√		
VIIU/VIA	636	Air	AAC-Automatic air conditioning	√	√		√	√		
VIIU/VIA	636	Air	PTC-Heater booster	√	√	√	√	√		
VIIU/VIA	636	Air	PTC-Heater booster	√	√	√	√	√		
VIIU/VIA	636	Air	REAR AC-Rear air conditioning	√	√	√	√	√		
VIIU/VIA	636	Air	STH-Stationary heater	√	√	√	√	√		
VIIU/VIA	636	Body	AAG-Trailer connection unit	√	√	√	√	√		
VIIU/VIA	636	Body	ALWR-Headlamp range adjustment	√	√	√	√	√	√	√
VIIU/VIA	636	Body	EZS-Electronic ignition switch	√	√	√	√	√		
VIIU/VIA	636	Body	OBF2-Upper control panel	√	√	√	√	√		
VIIU/VIA	636	Body	OCP-Overhead control panel	√	√		√	√		
VIIU/VIA	636	Body	SAM-Signal acquisition and actuation module	√	√		√	√		
VIIU/VIA	636	Body	SAM-Signal acquisition and actuation module	√	√		√	√		
VIIU/VIA	636	Body	SDE-H-Rear sliding roof unit	√	√		√	√		
VIIU/VIA	636	Body	SRS-supplemental restraint system	√	√		√	√		
VIIU/VIA	636	Body	SRS-supplemental restraint system	√	√		√	√		
VIIU/VIA	636	Body	UCP-Upper control panel	√	√		√	√		
VIIU/VIA	636	Chassis	ENR-Electronic rear axle level control	√	√		√	√		

VITO/VIA NO	636	Chassis	ESP-Electronic stability program	✓	✓	✓	✓	✓		
VITO/VIA NO	636	Chassis	TPC-Tire pressure monitor	✓	✓	✓	✓	✓		
VITO/VIA NO	636	Drive	CDI-Common Rail Diesel Injection	✓	✓	✓	✓			
VITO/VIA NO	636	Drive	CDI4-Common Rail Diesel Injection	✓	✓	✓	✓	✓		
VITO/VIA NO	636	Drive	CDI6-Common Rail Diesel Injection	✓	✓	✓	✓	✓		
VITO/VIA NO	636	Drive	CDID2-Common Rail Diesel Injection	✓	✓	✓	✓	✓		
VITO/VIA NO	636	Drive	EGS Electronic transmission control	✓	✓	✓	✓	✓		✓
VITO/VIA NO	636	Drive	EGS electronic transmission control	✓	✓	✓	✓	✓		
VITO/VIA NO	636	Drive	ESM-Electronic selector module	✓	✓		✓	✓		
VITO/VIA NO	636	Drive	FSCU-Fuel pump	✓	✓	✓	✓	✓		
VITO/VIA NO	636	Drive	ME 97-Motor electronics 9.7	✓	✓	✓	✓	✓		
VITO/VIA NO	636	Drive	ME-SFI 2.8-Motor electronics 2.8	✓	✓		✓	✓		
VITO/VIA NO	636	Information and	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	✓	✓	✓	✓	✓		
VITO/VIA NO	636	Information and	AVN-Headlamp range adjustmen	✓	✓		✓	✓		
VITO/VIA NO	636	Information and	CDW-CD changer	✓	✓	✓	✓	✓		
VITO/VIA NO	636	Information and	COMAND or AUDIO	✓	✓		✓			
VITO/VIA NO	636	Information and	DTCO-Digital tachograph	✓	✓		✓			
VITO/VIA NO	636	Information and	FSE Hands-free system (Bluetooth)	✓	✓		✓	✓		
VITO/VIA NO	636	Information and	IC-Instrument cluster	✓	✓		✓	✓		
VITO/VIA NO	636	Information and	NAVI-Navigation system (COMAND,SOUND 50)	✓	✓	✓	✓	✓		
VITO/VIA NO	636	Information and	PTS-Parktronic system	✓	✓	✓	✓	✓		
VITO/VIA NO	636	Information and	RADIO Sound 20	✓	✓	✓	✓			
VITO/VIA NO	636	Information and	RADIO Sound 5	✓	✓	✓	✓			
VITO/VIA NO	636	Information and	SOUND 5NG	✓	✓	✓	✓	✓		

VITO/VIA NO	636	Information and	TEL-Telephone control unit	√	√	√	√	√		
VITO/VIA NO	636	LIN Bus	PSM-Parameterizable Special Module	√	√	√	√	√		
VITO/VIA NO	636	Seats and DoorS	DCM-FL-Door control module front left	√	√		√	√		
VITO/VIA NO	636	Seats and DoorS	DCM-FR-Door control module front right	√	√		√	√		
VITO/VIA NO	636	Seats and DoorS	ESA driver-Electric seat adjustment driver (with memory)	√	√		√	√		
VITO/VIA NO	636	Seats and DoorS	ESA passenger-Electric seat adjustment front passenger (with memory)	√	√		√	√		
VITO/VIA NO	636	Seats and DoorS	STE-L-ESD [STE] Left electric sliding door	√	√		√	√		
VITO/VIA NO	636	Seats and DoorS	STE-R-ESD [STE] Right electric sliding door	√	√		√	√		
VITO/VIA NO	639(2004- 2007)		ETC-Electronic transmission control	√	√		√	√		
VITO/VIA NO	639(2004- 2007)	Air conditioning	AAC-Automatic air conditioning	√	√		√	√		
VITO/VIA NO	639(2004- 2007)	Air conditioning	PTC-Heater booster	√	√	√	√	√		
VITO/VIA NO	639(2004- 2007)	Air conditioning	PTC-Heater booster	√	√	√	√	√		
VITO/VIA NO	639(2004- 2007)	Air conditioning	REAR AC-Rear air conditioning	√	√	√	√	√		
VITO/VIA NO	639(2004- 2007)	Air conditioning	STH-Stationary heater	√	√	√	√	√		
VITO/VIA NO	639(2004- 2007)	Body	AAG-Trailer connection unit	√	√	√	√	√		
VITO/VIA NO	639(2004- 2007)	Body	AHE-Trailer recognition	√	√		√	√		
VITO/VIA NO	639(2004- 2007)	Body	CGW-Central gateway	√	√	√	√			
VITO/VIA NO	639(2004- 2007)	Body	EZS-Electronic ignition switch	√	√	√	√	√		
VITO/VIA NO	639(2004- 2007)	Body	OCP-Overhead control panel	√	√		√	√		
VITO/VIA NO	639(2004- 2007)	Body	SAM-Signal acquisition and actuation module	√	√		√	√		
VITO/VIA NO	639(2004- 2007)	Body	SDE-H-Rear sliding roof unit	√	√		√	√		



VITO/VIA NO	639(2004-2007)	Body	SRS-supplemental restraint system	√	√		√	√		
VITO/VIA NO	639(2004-2007)	Body	SRS-supplemental restraint system	√	√		√	√		
VITO/VIA NO	639(2004-2007)	Body	UCP-Upper control panel	√	√		√	√		
VITO/VIA NO	639(2004-2007)	Chassis	ENR-Electronic rear axle level control	√	√		√	√		
VITO/VIA NO	639(2004-2007)	Chassis	ESP-Electronic stability program	√	√		√	√		
VITO/VIA NO	639(2004-2007)	Chassis	ESP-Electronic stability program	√	√	√	√	√		
VITO/VIA NO	639(2004-2007)	Chassis	TPC-Tire pressure monitor	√	√	√	√	√		
VITO/VIA NO	639(2004-2007)	Drive	CDI-Common Rail Diesel Injection	√	√	√	√			
VITO/VIA NO	639(2004-2007)	Drive	CDI-Common Rail Diesel Injection	√	√	√	√			
VITO/VIA NO	639(2004-2007)	Drive	CDI4-Common Rail Diesel Injection	√	√	√	√	√		
VITO/VIA NO	639(2004-2007)	Drive	CDI4-Common Rail Diesel Injection	√	√	√	√			
VITO/VIA NO	639(2004-2007)	Drive	EGS Electronic transmission control	√	√	√	√	√		√
VITO/VIA NO	639(2004-2007)	Drive	EGS electronic transmission control	√	√	√	√	√		
VITO/VIA NO	639(2004-2007)	Drive	ESM-Electronic selector module	√	√		√	√		
VITO/VIA NO	639(2004-2007)	Drive	ME-SFI 2.8-Motor electronics 2.8	√	√		√	√		
VITO/VIA NO	639(2004-2007)	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√	√		
VITO/VIA NO	639(2004-2007)	Information and communication	AUDIO/APS-Auto pilot system	√	√		√	√		
VITO/VIA NO	639(2004-2007)	Information and communication	AVN-Headlamp range adjustmen	√	√		√	√		

VITO/VIA NO	639(2004-2007)	information and communication	CDC-CD changer	✓	✓		✓			
VITO/VIA NO	639(2004-2007)	information and communication	CDW-CD changer	✓	✓	✓	✓	✓		
VITO/VIA NO	639(2004-2007)	information and communication	COMAND	✓	✓		✓	✓		
VITO/VIA NO	639(2004-2007)	information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	✓	✓		✓	✓		
VITO/VIA NO	639(2004-2007)	information and communication	HRA-Headlamp range adjustment	✓	✓	✓	✓			
VITO/VIA NO	639(2004-2007)	information and communication	IC-Instrument cluster	✓	✓		✓	✓		✓
VITO/VIA NO	639(2004-2007)	information and communication	IC-Instrument cluster	✓	✓		✓	✓		
VITO/VIA NO	639(2004-2007)	information and communication	NAVI-Navigation system (COMAND,SOUND 50)	✓	✓	✓	✓	✓		
VITO/VIA NO	639(2004-2007)	information and communication	PTS-Parktronic system	✓	✓	✓	✓	✓		
VITO/VIA NO	639(2004-2007)	information and communication	RADIO Sound 20	✓	✓	✓	✓			
VITO/VIA NO	639(2004-2007)	information and communication	RADIO Sound 5	✓	✓	✓	✓			
VITO/VIA NO	639(2004-2007)	information and communication	Radio (SOUND series)	✓	✓		✓	✓		
VITO/VIA NO	639(2004-2007)	information and communication	SOUND 5NG	✓	✓	✓	✓	✓		
VITO/VIA NO	639(2004-2007)	information and communication	TEL-Telephone control unit	✓	✓	✓	✓	✓		
VITO/VIA NO	639(2004-2007)	information and communication	TV-TV tuner	✓	✓		✓	✓		
VITO/VIA NO	639(2004-2007)	information and communication	UHI-Cellular telephone (fixed installation or portable)(D2B)	✓	✓		✓	✓		
VITO/VIA NO	639(2004-2007)	information and communication	VCS-Voice control system	✓	✓		✓	✓		
VITO/VIA NO	639(2004-2007)	LIN Bus	PSM-Parameterizable Special Module	✓	✓	✓	✓			

VITO/VIA NO	639(2004- 2007)	LIN Bus	PSM-Parameterizable Special Module	√	√	√	√	√		
VITO/VIA NO	639(2004- 2007)	Seats and DoorS	DCM-FL-Door control module front left	√	√		√	√		
VITO/VIA NO	639(2004- 2007)	Seats and DoorS	DCM-FR-Door control module front right	√	√		√	√		
VITO/VIA NO	639(2004- 2007)	Seats and DoorS	ESA driver-Electric seat adjustment driver (with memory)	√	√		√	√		
VITO/VIA NO	639(2004- 2007)	Seats and DoorS	ESA passenger-Electric seat adjustment front passenger (with memory)	√	√		√	√		
VITO/VIA NO	639(2004- 2007)	Seats and DoorS	STE-L-ESD [STE] Left electric sliding door	√	√		√	√		
VITO/VIA NO	639(2004- 2007)	Seats and DoorS	STE-R-ESD [STE] Right electric sliding door	√	√		√	√		
VITO/VIA NO	639(2008-)	Air conditioning	AAC-Automatic air conditioning	√	√		√	√		
VITO/VIA NO	639(2008-)	Air conditioning	PTC-Heater booster	√	√	√	√	√		
VITO/VIA NO	639(2008-)	Air conditioning	PTC-Heater booster	√	√	√	√	√		
VITO/VIA NO	639(2008-)	Air conditioning	REAR AC-Rear air conditioning	√	√	√	√	√		
VITO/VIA NO	639(2008-)	Air conditioning	STH-Stationary heater	√	√	√	√	√		
VITO/VIA NO	639(2008-)	Body	AAG-Trailer connection unit	√	√	√	√	√		
VITO/VIA NO	639(2008-)	Body	ALWR-Headlamp range adjustment	√	√	√	√	√	√	√
VITO/VIA NO	639(2008-)	Body	EZS-Electronic ignition switch	√	√	√	√	√		
VITO/VIA NO	639(2008-)	Body	OBF2-Upper control panel	√	√	√	√	√		
VITO/VIA NO	639(2008-)	Body	OCP-Overhead control panel	√	√		√	√		
VITO/VIA NO	639(2008-)	Body	SAM-Signal acquisition and actuation module	√	√		√	√		
VITO/VIA NO	639(2008-)	Body	SAM-Signal acquisition and actuation module	√	√		√	√		
VITO/VIA NO	639(2008-)	Body	SDE-H-Rear sliding roof unit	√	√		√	√		
VITO/VIA NO	639(2008-)	Body	SRS-supplemental restraint system	√	√		√	√		
VITO/VIA NO	639(2008-)	Body	SRS-supplemental restraint system	√	√		√	√		
VITO/VIA NO	639(2008-)	Body	UCP-Upper control panel	√	√		√	√		

VITO/VIA NO	639(2008-)	Chassis	ENR-Electronic rear axle level control	√	√		√	√		
VITO/VIA NO	639(2008-)	Chassis	ESP-Electronic stability program	√	√	√	√	√		
VITO/VIA NO	639(2008-)	Chassis	TPC-Tire pressure monitor	√	√	√	√	√		
VITO/VIA NO	639(2008-)	Drive	CDI-Common Rail Diesel Injection	√	√	√	√			
VITO/VIA NO	639(2008-)	Drive	CDI4-Common Rail Diesel Injection	√	√	√	√	√		
VITO/VIA NO	639(2008-)	Drive	CDI6-Common Rail Diesel Injection	√	√	√	√	√		
VITO/VIA NO	639(2008-)	Drive	CDID2-Common Rail Diesel Injection	√	√	√	√	√		
VITO/VIA NO	639(2008-)	Drive	EGS Electronic transmission control	√	√	√	√	√		√
VITO/VIA NO	639(2008-)	Drive	EGS electronic transmission control	√	√	√	√	√		
VITO/VIA NO	639(2008-)	Drive	ESM-Electronic selector module	√	√		√	√		
VITO/VIA NO	639(2008-)	Drive	FSCU-Fuel pump	√	√	√	√	√		
VITO/VIA NO	639(2008-)	Drive	ME 97-Motor electronics 9.7	√	√	√	√	√		
VITO/VIA NO	639(2008-)	Drive	ME-SFI 2.8-Motor electronics 2.8	√	√		√	√		
VITO/VIA NO	639(2008-)	Information	AGW-Audio gateway (MOST network management,	√	√	√	√	√		
VITO/VIA NO	639(2008-)	Information and	diagnosis gateway, radio tuner)	√	√		√	√		
VITO/VIA NO	639(2008-)	Information and	AVN-Headlamp range adjustmen	√	√		√	√		
VITO/VIA NO	639(2008-)	Information and	CDW-CD changer	√	√	√	√	√		
VITO/VIA NO	639(2008-)	Information and	COMAND or AUDIO	√	√		√			
VITO/VIA NO	639(2008-)	Information and	DTCO-Digital tachograph	√	√		√			
VITO/VIA NO	639(2008-)	Information and	FSE Hands-free system (Bluetooth)	√	√		√	√		
VITO/VIA NO	639(2008-)	Information and	IC-Instrument cluster	√	√		√	√		
VITO/VIA NO	639(2008-)	Information and	NAVI-Navigation system (COMAND,SOUND 50)	√	√	√	√	√		
VITO/VIA NO	639(2008-)	Information and	PTS-Parktronic system	√	√	√	√	√		
VITO/VIA NO	639(2008-)	Information and	RADIO Sound 20	√	√	√	√			
VITO/VIA NO	639(2008-)	Information and	RADIO Sound 5	√	√	√	√			
VITO/VIA NO	639(2008-)	Information and	SOUND 5NG	√	√	√	√	√		
VITO/VIA NO	639(2008-)	Information and	TEL-Telephone control unit	√	√	√	√	√		
VITO/VIA NO	639(2008-)	LIN Bus	PSM-Parameterizable Special Module	√	√	√	√	√		

VITO/VIA NO	639(2008-)	Seats and DoorS	DCM-FL-Door control module front left	✓	✓		✓	✓		
VITO/VIA NO	639(2008-)	Seats and DoorS	DCM-FR-Door control module front right	✓	✓		✓	✓		
VITO/VIA NO	639(2008-)	Seats and DoorS	ESA driver-Electric seat adjustment driver (with memory)	✓	✓		✓	✓		
VITO/VIA NO	639(2008-)	Seats and DoorS	ESA passenger-Electric seat adjustment front passenger (with memory)	✓	✓		✓	✓		
VITO/VIA NO	639(2008-)	Seats and DoorS	STE-L-ESD [STE] Left electric sliding door	✓	✓		✓	✓		
VITO/VIA NO	639(2008-)	Seats and DoorS	STE-R-ESD [STE] Right electric sliding door	✓	✓		✓	✓		

## Special Function

Sprinter	906	KLA-Automatic air conditioning	Initial startup
Sprinter	906	KLA-Automatic air conditioning	Teach-in of actuator motors
Sprinter	906	ALWR-Headlamp range adjustment	Calibrate control unit LWR
Sprinter	906	ENR-Electronic rear axle level control	A9/1m1 (Air compressor motor)
Sprinter	906	ENR-Electronic rear axle level control	Y36 (Level control valve unit)
Sprinter	906	ESP-Electronic stability program	B24/15 (Yaw rate, lateral and longitudinal acceleration sensor)
Sprinter	906	EGS Electronic transmission control	Adaptation values of shift 1-2
Sprinter	906	EGS Electronic transmission control	Adaptation values of shift 2-1
Sprinter	906	EGS Electronic transmission control	Adaptation values of shift 2-3
Sprinter	906	EGS Electronic transmission control	Adaptation values of shift 3-2
Sprinter	906	EGS Electronic transmission control	Adaptation values of shift 3-4
Sprinter	906	EGS Electronic transmission control	Adaptation values of shift 4-3
Sprinter	906	EGS Electronic transmission control	Adaptation values of shift 4-5
Sprinter	906	EGS Electronic transmission control	Adaptation values of shift 5-4
Sprinter	906	EGS Electronic transmission control	Display all adaptation data
Sprinter	906	EGS Electronic transmission control	Resetting of adaptation data
Sprinter	906	ME-SFI-Motor electronics	Correction programming of fuel quantity
Sprinter	906	ME-SFI-Motor electronics	Correction programming of ignition
Sprinter	906	ME-SFI-Motor electronics	Recirculated air flap

Sprinter	906	ME-SFI-Motor electronics	Resetting of sensor adaptation
Sprinter	906	ME-SFI-Motor electronics	Teach in of throttle valve stop
VITO/VIANO	636	ALWR-Headlamp range adjustment	Calibrate control unit LWR
VITO/VIANO	636	EGS Electronic transmission control	Adaptation values of shift 1-2
VITO/VIANO	636	EGS Electronic transmission control	Adaptation values of shift 2-1
VITO/VIANO	636	EGS Electronic transmission control	Adaptation values of shift 2-3
VITO/VIANO	636	EGS Electronic transmission control	Adaptation values of shift 3-2
VITO/VIANO	636	EGS Electronic transmission control	Adaptation values of shift 3-4
VITO/VIANO	636	EGS Electronic transmission control	Adaptation values of shift 4-3
VITO/VIANO	636	EGS Electronic transmission control	Adaptation values of shift 4-5
VITO/VIANO	636	EGS Electronic transmission control	Adaptation values of shift 5-4
VITO/VIANO	636	EGS Electronic transmission control	Display all adaptation data
VITO/VIANO	636	EGS Electronic transmission control	Resetting of adaptation data
VITO/VIANO	639(2004-2007)	EGS Electronic transmission control	Adaptation values of shift 1-2
VITO/VIANO	639(2004-2007)	EGS Electronic transmission control	Adaptation values of shift 2-1
VITO/VIANO	639(2004-2007)	EGS Electronic transmission control	Adaptation values of shift 2-3
VITO/VIANO	639(2004-2007)	EGS Electronic transmission control	Adaptation values of shift 3-2
VITO/VIANO	639(2004-2007)	EGS Electronic transmission control	Adaptation values of shift 3-4
VITO/VIANO	639(2004-2007)	EGS Electronic transmission control	Adaptation values of shift 4-3
VITO/VIANO	639(2004-2007)	EGS Electronic transmission control	Adaptation values of shift 4-5
VITO/VIANO	639(2004-2007)	EGS Electronic transmission control	Adaptation values of shift 5-4
VITO/VIANO	639(2004-2007)	EGS Electronic transmission control	Display all adaptation data

VITO/VIANO	639(2004-2007)	EGS Electronic transmission control	Resetting of adaptation data
VITO/VIANO	639(2004-2007)	IC-Instrument cluster	Maintenance light reset
VITO/VIANO	639(2008-)	ALWR-Headlamp range adjustment	Calibrate control unit LWR
VITO/VIANO	639(2008-)	EGS Electronic transmission control	Adaptation values of shift 1-2
VITO/VIANO	639(2008-)	EGS Electronic transmission control	Adaptation values of shift 2-1
VITO/VIANO	639(2008-)	EGS Electronic transmission control	Adaptation values of shift 2-3
VITO/VIANO	639(2008-)	EGS Electronic transmission control	Adaptation values of shift 3-2
VITO/VIANO	639(2008-)	EGS Electronic transmission control	Adaptation values of shift 3-4
VITO/VIANO	639(2008-)	EGS Electronic transmission control	Adaptation values of shift 4-3
VITO/VIANO	639(2008-)	EGS Electronic transmission control	Adaptation values of shift 4-5
VITO/VIANO	639(2008-)	EGS Electronic transmission control	Adaptation values of shift 5-4
VITO/VIANO	639(2008-)	EGS Electronic transmission control	Display all adaptation data
VITO/VIANO	639(2008-)	EGS Electronic transmission control	Resetting of adaptation data

*XT* **TOOL**